

PCFW-104 MM2-Series Radio Modem PC/104 Interface User's Manual

MICROBEE SYSTEMS CORPORATION

1429 Weatherly Road, Suite G

Huntsville, AL 35803

Tech. Support: 256-489-6671

www.microbee-systems.com

support@microbee-systems.com

CAGE Code 3DPE9

COPYRIGHT 2002-2013 MicroBee Systems Corporation.

All rights reserved.

However, any part of this document may be reproduced, provided that MicroBee Systems Corporation is cited as the source. The contents of this manual and the specifications herein may change without notice.

TRADEMARKS:

Windows® is a registered trademark of Microsoft Corporation.

ROM-DOS is a trademark of Datalight.

QNX is a trademark of QNX Software Systems, Ltd

NOTICE TO USER

The information contained in this manual is believed to be correct. However, MicroBee Systems assumes no responsibility for any of the circuits described herein, conveys no license under any patent or other right, and makes no representations that the circuits are free from patent infringement. MicroBee Systems makes no representation or warranty that such applications will be suitable for the use specified without further testing or modification.

MicroBee Systems Corporation general policy does not recommend the use of its products in life support applications where the failure or malfunction of a component may directly threaten life or injury. It is a Condition of Sale that the user of MicroBee Systems products in life support applications assumes the risk of such use and indemnifies MicroBee Systems against all damage.

Please read before installing your product.

MicroBee's products are designed to be high in performance while consuming very little power. In order to maintain this advantage, CMOS circuitry is used. CMOS chips have specific needs and some special requirements that the user must be aware of. Read the following to help avoid damage to your card from the use of CMOS chips.

Using CMOS Circuitry

Industrial Control originally used LSTTL circuits. Because many PC components are used in laptop computers, IC manufacturers are exclusively using CMOS technology. Both TTL and CMOS have failure mechanisms, but they are different. This section describes some of the common failures which are common to all manufacturers of CMOS equipment.

Improper power causes catastrophic failure.

If a card has had reverse polarity or high voltage applied, replacing a failed component is not an adequate fix. Other components probably have been partially damaged or a failure mechanism has been induced. Therefore, a failure will probably occur in the future. For such cards, MicroBee highly recommends that these cards be replaced.

Other over-voltage symptoms

In over-voltage situations, the programmable logic devices, EPROM's and CPU chips, usually fail in this order. The failed device may be hot to the touch. It is usually the case that only one IC will be overheated at a time.

Power sequencing

The possibility of failure can be caused by the external application of input voltage to the radio via the external B+ input while the PCFW-104 power is off. If you apply 5V to the input of a TTL chip with the power off, nothing will happen. Applying a 5V input to a CMOS card will cause the current to flow through the input and out the 5V power pin. This current attempts to power up the card. Most inputs are rated at 25 mA maximum. When this is exceeded, the chip may be damaged.

Failure on power-up

Even when there is not enough current to destroy an input described above, the chip may be destroyed when the power to the card is applied. This is due to the fact that the input current biases the IC so that it acts as a forward biased diode on power-up. This type of failure is typical on serial interface chips.

Hot insertion

Plugging cards into the card cage with the power on will usually not cause a problem. (MicroBee **urges that you do not** do this!)

However, the card may be damaged if the right sequence of pins contacts as the card is pushed into the socket. This usually damages bus driver chips and they may become hot when the power is applied. This is one of the most common failures of expansion cards.

PREFACE

This manual is a guide to the proper configuration, installation, and operation of your PCFW-104 Interface. For setup and operation of the FreeWave FGSM Radio Modem refer to the FreeWave Radio Users Manuals included with this product. You can use your PCFW-104 card in conjunction with other PC/104 expansion cards, tailoring your system for a wide variety of applications.

TECHNICAL SUPPORT

MicroBee Systems is committed to supporting our products. For this reason all FreeWave User manuals as well as this manual are always available online in PDF format at http://www.microbee-systems.com/user_manuals.htm.

This unit has been tested with a number of operating systems including MSDOS, Linux, QNX, Microsoft Windows 98, NT and 2000. Any operating systems supporting an ISA legacy device should operate normally with this product. MicroBee Systems does not guarantee operation with unusual or custom operating systems.

If you have a question about the PCFW-104 card and cannot find the answer in this manual, call Technical Support. They will be ready to give you the assistance you need.

- When you call, please have the following at hand:
- Your PCFW-104 Radio Modem Interface User's Manual and the FreeWave Radio Users Manual.
- A description of your problem.

The direct line to Technical Support is 256-489-6671

OVERVIEW

The PCFW-104 PC/104 FreeWave Data Radio is a PC/104 Bus Compliant 8 BIT interface that allows the FreeWave Model MM2-T series data radios to be easily installed on any PC-104 stack.

The PCFW-104 is fully PC/104 compliant in all aspects EXCEPT height. The PC/104 specifications calls for a height of 0.4 inches. The unit exceeds the recommended height by approximately 0.200 inch and is due to the RF Shield.

Once the unit is configured and installed it is treated like any other serial port on the stack. In other words, if it is configured for an address of 3F8 and IRQ 4 then it is as simple as using any device on COM 1.

The interface supports baud rates up to a maximum of 115,200.

The unit includes the 16 bit ISA connector so 16 bit devices can be placed on the stack after the radio. Also interrupts 10, 11, 14 and 15 are accessed thru this connector. The PCFW-104, being an 8 BIT interface, does not require a 16 bit ISA card be prior to the radio unless operation requires IRQ 10, 11, 12 or 15.

For more information on the PC-104 ISA bus please refer to the PC-104 specification at: <http://www.pc104.org/technology/PDF/PC104Specv246.pdf>

Operation

This unit is extremely easy to use and incorporates three jumper sets, JP1, JP2 and JP3. The PCFW-104 contains static sensitive CMOS components. The greatest danger occurs when the card is plugged into the PC/104 stack. The card becomes charged by the user and the static discharges to the I/O bus from the pin closest to the card connector. If that pin happens to be an input pin, even TTL inputs may be damaged. **Follow sound ESD practices!!!!**
To avoid damaging your card and its components:

1. Ground yourself before handling the PCFW-104 Radio Modem.
2. Disconnect power before removing or inserting the PCFW-104 Radio Modem.

OPERATING PRECAUTIONS

Be sure that your PC/104 stack and/or power supply has sufficient 5V current to supply the radio at the specified power setting.

TECHNICAL SPECIFICATIONS

Baud Rate

The PCFW-104 is fully 16C550A compliant and supports software selectable baud rates of 300, 1200, 2400, 4800, 9600, 19.2K, 38.4K, 56K and 115.2K.

Environmental

-40° to 85° C operating.
-50° to 90° C non-operating.
RH 5% to 95%, non-condensing.

Power Specification

5V +/- 5% at 750 mA max during active TX.

Size

3.6 in. x 3.8 in x 0.6 in. (91.4 mm X 96.5 mm x 15.2 mm)

Weight

4.4 oz, (124.7 gm)

INSTALLATION

Before installing the PCFW-104 Radio Modem, refer to Figure 1 for the location of various connectors and jumpers.

Interrupt Select Jumpers, JP1

JP1 is used to select the IRQ Level. IRQ's 3, 4,5,7, 10, 11, 14 and 15 are supported. Simply select the desired IRQ level by moving the jumper to the appropriate position.

From left to right:

IRQ 15,14,11, 10, 7, 5, 4, 3. Default configuration is IRQ4 which is standard for COM1 & COM3.

Warning:

Improper IRQ configuration can result in your CPU locking up due to an IRQ conflict. Most COM libraries allow for non-standard IRQ settings as will after market drivers. Windows 95, 98, ME, NT, 2000 and XP may limit your IRQ selection without aftermarket drivers. This is usually not required unless all IRQ's supported by the OS are already allocated.

Note:

PC/104 CPU manufacturers vary in implementation of the interrupt interface. Most use pull-ups on the interrupts. This allows a board to drive low or tristate float high the interrupt lines preventing damage if two boards conflict. The PCFW-104 uses the tristate scheme. On a few motherboards the manufacturers use pulldown resistors. The PCFW will not request a interrupt in this scheme since the tristated line cannot float high. In this case a pad is provided for installation of a pullup resistor, R8. The user should install a 1K 0805 resistor on this pad. Should this not work the largest value possible should be used to prevent excessive current draw. 250 ohms is a recommended minimum

Address Select Jumpers, JP2

For flexibility with most SW and Development libraries this unit will support any valid address between 0x000-0x007 and 0x7F8-0x7FF.

Most applications will use one of the common serial port addresses. The most common are: COM1 = 3F8, IRQ4, COM2 = 2F8, IRQ3 COM3 = 3E8, IRQ4 COM4 = 2E8, IRQ3
Most software development libraries for serial communication support non-standard address and/or IRQ assignments.

An excellent library is the COMM/DRV LIB from Willies Computer Software at <http://www.wcscnet.com/>

The default address is 3E8 which is COM3. To select the address you desire place jumpers on JP2 in the following order.

From left to right. Placing a jumper sets the address bit to 0 or low.

Addressing Examples:

Hex	A10	A9	A8	A7	A6	A5	A4	A3
2F8	X		X					
300	X			X	X	X	X	X
310	X			X	X	X		X
3E8	X						X	
3F8	X							
7F8								

X = jumper installed meaning bit = 0.

PC/104 Bus Power:

This device is powered directly from the PC/104 bus 5V rail. You must insure you have at least 1 AMP of additional power reserve for this device to operate at the full 1W RF output at high duty cycles.

Setup Switch

In order to access the FreeWave Radio setup menus it is necessary to drive the setup line on the radio low. This can be achieved two ways. One, the PCFW-104 incorporates a setup switch. Pressing this switch while in a terminal program such as Hyper Terminal will invoke the user setup menu and allow the radio to be configured for the user network.

Since the PCFW-104 is to be used in remote embedded applications inside a case Connector J5 is available to facilitate the installation of an external setup switch. Shorting the pins on J5 invokes the user setup menu. Never apply power of any type to J5.

As always the menu can be accessed via the diagnostic connector J7 using a FreeWave ASC2009 Diagnostic cable.

Testing Installation

NOTE:

Refer to the FreeWave Radio Users manuals for proper radio operation and setup.

Once the unit is installed it is recommended that the unit be tested using a simple communications program such as Hyper Terminal under windows.

Open the communications program and select the proper COM port. Set the communications parameters to 19,200 Baud, 8 Bits, No Parity, 1 Stop Bits (19200,N,8,1) and press the setup button. The FreeWave Setup Menu should come up on the screen.

1PPS Input

The optional 1PPS input is used to externally drive the FreeWave DTR pin with a TTL Level GPS 1PPS Pulse. This is used for Masterless TDMA Mode and Push To Talk Mode (PTT). For normal operation place the jumper JP4 on the INT position. This will route the DTR from the UART to the radio modem.

For Masterless TDMA move jumper JP4 to the EXT position. Also you must configure the modem for Masterless mode. Please review the FreeWave TDMA User Manual for operation.

Caution: The 1PPS input is TTL tolerant. Application of RS-232 level signals or signals exceeding the range of 0 to 5VDC will damage the radio.




Figure 1, PCFW-104

WARRANTY

MicroBee Systems Corporation (MicroBee), warrants that its standard hardware products will be free from defects in materials and workmanship under normal use and service a period of one year from date of purchase. MicroBee's obligation under this warranty shall not begin until Buyer returns the defective product, freight prepaid to MicroBee's facility or another specified location.

MicroBee's only responsibility under this warranty is, at its option, to replace or repair, free of charge, any defective component part of such products.

LIMITATIONS ON WARRANTY

The warranty set forth above does not extend to and shall not apply to:

1. Products, including software, which have been repaired or altered by other than MicroBee personnel, unless Buyer has properly altered or repaired the products in accordance with procedures previously approved in writing by MicroBee.
2. Products which have been subject to power supply reversal, misuse, neglect, accident, or improper installation.
3. The design, capability, capacity, or suitability for use of the Software. Software is licensed on an "AS IS" basis without warranty. The warranty and remedies set forth above are in lieu of all other warranties expressed or implied, oral or written, either in fact or by operation of law, statutory or otherwise, including warranties of merchantability and fitness for a particular purpose, which MicroBee specifically disclaims.
4. MicroBee neither assumes nor authorizes any other liability in connection with the sale, installation or use of its products. MicroBee shall have no liability for incidental or consequential damages of any kind arising out of the sale, delay in delivery, installation, or use of its products.

SERVICE POLICY

1. MicroBee's goal is to ship your product within 10 working days of receipt.
2. If a product should fail during the warranty period, it will be repaired free of charge. For out of warranty repairs, the customer will be invoiced for repair charges at current standard labor and materials rates.
3. Customers that return products for repairs, within the warranty period, and the product is found to be free of defect, may be liable for the minimum current repair charge.

RETURNING A PRODUCT FOR REPAIR

Upon determining that repair services are required, the customer must:

1. Obtain an RMA (Return Material Authorization) number from the Customer Service Department, 256-489-6671
2. If the request is for an out of warranty repair, a purchase order number or other acceptable information must be supplied by the customer.

3. Include a list of problems encountered along with your name, address, telephone, and RMA number.
4. Carefully package the product in an antistatic bag. (Failure to package in antistatic material will VOID all warranties.) Then package in a safe container for shipping.
5. Write RMA number on the outside of the box.

NOTE:

For products under warranty, the customer pays for shipping to MicroBee. MicroBee pays for shipping back to customer.

Other conditions and limitations may apply to international shipments.

NOTE:

PRODUCTS RETURNED TO MICROBEE FREIGHT COLLECT OR WITHOUT AN RMA NUMBER CANNOT BE ACCEPTED AND WILL BE RETURNED FREIGHT COLLECT.

RETURNS:

There will be a 15% restocking charge on returned product that is unopened and unused, if MicroBee accepts such a return. Returns will not be accepted 30 days after purchase. Opened and/ or used products, non-standard products, software and printed materials are not returnable without prior written agreement.

GOVERNING LAW:

This agreement is made in, governed by and shall be construed in accordance with the laws of the State of Alabama.

The information in this manual is provided for reference only. MicroBee Systems does not assume any liability arising out of the application or use of the information or products described in this manual.

This manual may contain or reference information and products protected by copyrights or patents. No license is conveyed under the rights of MicroBee Systems or others.