



Micro-Precision Apertures • Miniature Positioners • Controllers • Software

NATIONAL APERTURE, INC.



MC-5B Users Manual

National Aperture, Inc.

MC-5B Users Manual

Version 1.0

National Aperture, Inc.

16 Northwestern Drive

Salem, NH 03079-4810

Phone 603-893-7393

FAX 603-893-7857

www.nationalaperture.com

sales@nationalaperture.com

www.naimotion.com

sales@naimotion.com

Table of Contents

Section 1
 Overview 1

Section 2
 Setup3

Section 3
 Basic Menu Selections5

Section 4
 Key Functions9

Section 5
 Memory Locations and Program Flow13

Section 6
 Multi-Axis System17

Appendix A
 Specifications27

Appendix B
 Troubleshooting and Set-up Assistance28

Appendix C
 Examples, Servo Settings29

Appendix D
 Stage Resolution30

Appendix E
 Settings for Standard Stage Products31

Appendix F
 Motor Connector Pin Assignments32

Overview

The MC-5B Micro-Positioning Controller from National Aperture, Inc. was designed for ease of use and effortless integration into any application. The MC-5B is a low-cost, quick-setup solution for those applications requiring precise position control of motorized stages. Incorporated into this all-in-one controller is a keypad/display interface, a 750mA 12V linear DC motor amplifier, single ended (TTL) A/B quadrature encoder inputs, 5 volt limit switch inputs and a serial communication interface. The MC-5B functions seamlessly as a single axis, stand-alone system or as a multi-axis networked system. The peer to peer network architecture makes it possible for every MC-5B in a multi-axis system to control every axis in the motion system. No software development or complex wiring is required. The controllers themselves may be programmed to store and recall positions and to sequence through stored positions with looping, pausing and user/program interaction.

Benefits:

- Instant “Out-of-the-Box” Motion Control
- A Low Cost, Integrated Motion Solution
- No Need to Write Additional Motion Commands
- Perfect for:
 - Rapid Development
 - Prototyping
 - Proof-of-Concept
 - Small OEM Lots Where Delivery is Critical
 - Lab Development

Features:

- Control all nodes from any node on the motion network
- Broadcast Single or Multiple Motion Commands to one node or all nodes at the same time
- Configure each unit as a node on the network with a unique node number
- Original settings are retained
- Up to 99 MC-5B controllers can be configured on a single motion system

Setup

What You'll Need:

The MC-5B Controller comes with a 15 Volt power supply, and a User's Manual.

You'll also need a stage with a 6-12 volt DC motor (750 mA max) and single ended 5 Volt A/B quadrature incremental encoder. National Aperture, Inc. offers a broad selection of such stages. Remote joystick and dial encoder input devices are also available from National Aperture, Inc. as options.

Connections – Single Axis System:

Plug the 15V power supply in and connect it to the MC-5B's 15V power input. Plug the stage into the MTR/ENC/LIM input appropriate for the connector type. (Use one stage only per controller.) If you have joystick and/or dial encoder input devices, they may be plugged into the jacks labeled JOYSTK and ENCWHL.

Power Up and Configuration:

The controller(s) may be switched on with the on/off switch located on the back of the unit(s). Node ID's (addresses) may be set, starting at one, for all nodes in a networked system by holding down the shift key and pressing the ASGN NDS (assign nodes) key.

Default Setting:

The MC-5B comes with factory default settings so that you may start testing your stage and controller immediately. Please check these settings by referencing Section 3 for Basic Menu Selections and examples beginning on page 7 to ensure you are aware of the many options available on your MC-5B. Also refer to MC-5B Factory Settings, Appendix C on page 29.

Factory default settings can be reset from the keypad of the MC-5B by holding down the shift and reset buttons simultaneously and pressing the enter button twice.

Basic Menu Selections

Various operating parameters and configuration options may be set in the MC-5B's menu. The menu is entered by pressing any key in the menu box, and may be scrolled through (**with wrap-around**) using the up/down arrows in the menu box. The menu consists of a single column of 29 items, each item consisting of a two option selection and/or a single numeric parameter. You may select between one of two options for a menu item by pressing the SEL key. The ' > ' symbol marks the selected option. Numeric input should be followed by a menu scroll (menu arrow) input if you wish to remain in the menu. The ENTER key is used to exit the menu.

(Most National Aperture MM-3M linear stages may be operated without modifications to menu items.)



Menu Selection	Definition
Single Node Mode	When idle, numeric entries access positions stored in the corresponding memory location. Use jog keys to scroll through memory if desired. Press ENTER/GOTO to move.
Multi-Node Mode	When idle, numeric entries establish control of the axis with the entered node ID. Key commands and display information pertain to this Node. Enter another node number to change node or press ENTER to return to (default) local node.
Step Jog	Jogs in steps of size defined by "Step Base Increment" (in menu) and JOG RATE arrows. (HIGH SPEED JOG operates in velocity mode.)
VMode Jog	Jogs continuously with velocity defined by "JOG RATE" arrows and "Jog Vel Multplr" (in menu).
(Fwd Limit Value) Fwd Limit Off	Position for forward software limit (in encoder counts). Select to enable. Disables forward software limit.
(Rev Limit Value) Rev Limit Off	Position for reverse software limit (in encoder counts). Select to enable. Disables reverse software limit.
Store By Entry Sequential	STORE operation, prompts user for memory location (separate memory from sequence). STORE operation stores position in next memory location.
Rotary Motion	Configures controller for rotary motion. Units are angular. Reverse limit switch is not recognized.
Linear Motion	Configures controller for linear motion. Units are linear. Forward and reverse limit switches are recognized.
Locked Jog Free Jog	Stage is held In position following JOG - Remains in servo. Stage not held in position following JOG - Out of servo. Still in servo after MOVE, RECALL, etc
Home to Rev End Home to Fwd End	Stage is homed to reverse end (typically the end with no motor or gear). Stage is homed to forward end (typically the end with motor or gear).
Homing Offset	Stage is moved the specified distance from the limit before setting position to zero.
Final Homing Velocity	When homing, stage moves to limit at Base velocity (set with "SET VEL" key or in menu), moves back a short distance, then approaches the limit again (typically slowly for precision) at the final homing velocity. Default = 400 cts/s.
Reverse Display Normal Display	The Displayed Position is Reversed in Sign. The Displayed Position is not Reversed in Sign.
Reverse Encoder Normal	Controller is configured for an encoder that produces negative counts (B leads A) for a positive motor voltage. (CHECK!!!) Controller is configured for an encoder that produces positive counts (A leads B) for a positive motor voltage.

Menu Selection	Definition
Rev Backlash	Destination Position is Approached in the Negative Direction.
Normal	Destination Position is Approached in the Positive Direction. (see Backlash section bottom of page, and Backlash Comp menu item)
Reverse Dir Key	JOG Key Direction is Reversed.
Normal	JOG Key Direction is not Reversed.
Jog Vel Multplr (for “VMode Jog”)	Jog velocity is determined by the “JOG RATE” arrows and is scaled by the Jog Velocity Multiplier. (HIGHS SPEED not affected.)
OR	
Step Base Increment (for “Step Jog”)	Jog step size is determined by the “JOG RATE” arrows and is scaled by the “Step Base Increment.”
Dial Step	Specifies the number of encoder counts the stage will be stepped for a single click of the dial encoder input device.
Dial Step = Jog Step (Step Jog Mode Only)	Dial Encoder step determined by Jog Step (from “Step Base Increment” (in menu) and JOG RATE arrows).
Base velocity	Sets velocity for move commands (MOVE, REL) and homing. When the “STORE” key is used, the Base velocity (and accel) are stored in the specified memory location. The Base velocity can also be changed using the “SET VEL” key.
Base accel	Sets acceleration for move commands (MOVE, REL) and homing. When the STORE key is used, the Base acceleration (and velocity) are stored in the specified memory location. The Base acceleration can also be changed using the “SET ACC” key.
Jog Step Accel	Sets the acceleration used for step jogging.
Backlash Comp	When moving opposite the backlash direction, stage moves past the destination by the Backlash Compensation distance then returns to the destination. (see Backlash section and Rev Backlash menu item.)
Counts per Inch, cm or rev:	Sets the number of encoder counts per unit distance or angle. See Appendix D Stage Resolution.
Following Error	Motion is interrupted when the actual stage position differs from the commanded position by more than the specified following error (in encoder counts).
Enc Lns per Rev	Sets the number of lines on the encoder per motor revolution (not per rotary stage revolution). Encoder lines per revolution = (1/4)*Encoder counts per Revolution..
PID Kp	Proportional gain for the PID (proportional, integral, derivative) feedback controller. In most instances this need not be changed from the default value of 600.
PID Ki	Integral gain for the PID feedback controller. In most instances this need not be changed from the default value of 400.
PID Kd	Derivative gain for the PID feedback controller. In most instances this need not be changed from the default value of 1000.
PID iLimit	Limit applied to the integration sum in the PID Controller. Prevents the buildup of an excessive integral term and control signal when motion departs from the commanded velocity profile. In most instances this need not be changed from the default value of 1000.
PID Deriv tSamp	Sets the derivative sample period to the controller sample period times (1 + (PID Deriv tSamp)). In most instances this need not be changed from the default value of 0.
Node	Sets the controller's node ID (address) to a value from 1 to 99. The ID is used for communicating remotely from another MC-5B controller. The “ASGN NDS” key may be used to automatically assign node ID's to all of the controllers in a (properly connected) networked system. (See Setup Section.)
Backlash	
For many systems, mechanical play in gears, lead screws, nuts or other components can result in backlash, which can be defined as the actuated displacement that occurs without motion of the carriage after a change in the direction of motion. The backlash compensation distance is set to a value that is higher than the system's physical backlash. When moving in one direction, movement will be directly to the target position. When moving in the other direction, the target position will be “overshot” by the backlash compensation distance, so that the physical system backlash will be taken up in the final approach. With backlash compensation, target positions are always approached from the same direction, and from a distance that exceeds the physical backlash in the system. The final approach direction is selectable with the reverse backlash menu item. The amount of backlash compensation must be determined by an external measuring device.	

1. To Set Single Node Mode

- SEL** To Enter Menu
- SEL** To toggle between selections – select Single Node Mode
- Enter** To Exit menu

** The ">" symbol marks the selected option**

2. To Set Multi Node Mode

- SEL** To Enter Menu
- SEL** To toggle between selections – select Multi Node Mode
- Enter** To Exit menu



3 To Set Forward Limit Value

- SEL** To Enter Menu
- ↓** To scroll through menu selections (select ...)
- SEL** To toggle between selections
- Enter value
- SEL** To exit menu

4 To Set Forward Limit Off

- SEL** To Enter Menu
- ↓** To scroll through menu selections (select ...)
- SEL** To toggle between selections
- Enter** To exit Menu

-OR-

Another “shortcut” method to set Forward Limit Off is to press the following keys

- SHIFT** **8** To turn limit off/on

5. To set backlash compensation

- SEL** To Enter Menu
- ↓** To scroll through menu selections (select backlash comp)
- Enter value
- Enter** To Exit menu

KEY FUNCTIONS

Normal and Shift Functions:

Key functions marked in white (or black on white) are accessed by pressing the key. Key functions marked in red are accessed by pressing the key while holding down the SHIFT key.

Key	Function
STOP	Stop Motion, Cancel Entry
JOG	Move/Jog Stage (while pressed)
JOG HS	High Speed Jog (Press SHIFT & JOG)
JOG RATE	Adjust Jog Rate
HIGH RATE	Adjust High Speed Jog Rate
MOVE	Move to Absolute Position
REL	Relative Move of Specified Distance
STORE *	Store Position in Memory Location
RECALL **	Move to Position Stored in Memory Location
DELETE	Delete Position in Memory Location(s)
RUN ***	Run Stored Program
STEP ***	Single Step through Stored Program
SET 0	Set Current Position to Zero
SPECIFIED	Set Current Position to Specified Value
HOME	Home Stage (Stops when Released)
AUTO-HOME	Home Stage (Runs when Released)
HOT KEYS	Move All to Position Stored in Memory Location
STANDBY	Disable Amp and Enter Sleep Mode
ON/ID	Exit Sleep Mode and Show Node ID
UNITS	Change Units of Measure
SET VEL	Set Velocity (for MOVE, REL & STORE)
SET ACC	Set Accel (for Jog, MOVE, REL, STORE)
MEAS	Measure Distance from Start Position
MEAS REF	Set Start Position for Measurement
REV LMT	Rev Software Limit = Current Position
FWD LMT	Fwd Software Limit = Current Position
RLmtOnOff	Toggle Rev Software Limit On/Off
FLmtOnOff	Toggle Fwd Software Limit On/Off
ASGN NDS	Assign Node ID's to Networked Nodes
RESET	Reset Controller to Default Configuration

*To store a position, enter desired memory location at prompt. Valid locations are 0 (or 00) - 99. Current base velocity and acceleration are also stored.

**To recall a stored position with the RECALL key, enter desired memory location at prompt. A two digit entry ('01' for location 1) displays the stored position. Jog keys may be used to subsequently scroll through stored positions if desired. Press ENTER/GOTO to move the stage to the selected position.

***By default, runs through all consecutively programmed memory locations. See memory locations and program flow section for program sequence options.

1. To Reset Controller:

SHIFT **RESET** (Hold for a few seconds and release the Reset key to generate “reset Node ## ?” prompt.)

ENTER (To accept first question prompt)

ENTER (To accept “Cancel if not sure” second prompt)

2. To home:

SHIFT

AUTO-HOME

* Note, prior to performing an “auto-home”, ensure menu selections (See section 3) are correct for stage being controlled.

3. To change the displayed units:

SHIFT

UNITS

4. To move to -0.50 inches (units set to inches):

MOVE

-

.

5

ENTER

5. To set current position to zero:

SET 0

ENTER

6. To move 0.1 inch relative to current position:

REL

.

1

ENTER

7. To store the current position in memory location 1:

STORE

1

ENTER

8. To jog stage forward at jog rate:

JOG>

9. To jog stage backward at jog rate:

JOG<

10. To jog stage forward at high speed jog rate:

SHIFT JOG>

11. To jog stage backward at high speed jog rate:

SHIFT JOG<

12. To increase the jog rate:

JOG RATE ^

13. To increase the high speed jog rate:

SHIFT JOG RATE ^

14. To stop motion:

STOP

MEMORY LOCATIONS AND PROGRAM FLOW

Editing of the 100 program memory locations (00-99) is initiated by pressing any key in the "Edit Memory Location" box.

Navigation of memory locations is similar to Menu navigation with the added feature that memory locations may be scrolled through horizontally using the green jog keys.

Each memory location consists of the following parameters:

Parameter	Description
Location to Edit	Memory Location (0-99)
Execute/Skip Point	(as stated)
Coordinate	(as stated)
Velocity	(as stated)
Accel	(as stated)
Move Relative/Absolute	(as stated)
Pause/Wait	Pause for specified duration (0 for no pause) or wait for ENTER keystroke
Loop Count	Marks start of loop if $\neq 0$. Loop code is executed Loopcount + 1 times.
End Loop	Marks end of loop
End Program	Marks end of program

Program Execution

Use the RUN key to run or the STEP key to single step through programs. Execution progresses sequentially after the most recently accessed memory location and ends at the first End Program encountered.

Looping

Loops start at memory locations with Loop count $\neq 0$ and execution jumps to the start of the loop when an end loop is encountered. Loops are executed Loop count +1 times. Nesting is not supported.

End Program

Program execution ceases when an End Program is encountered.



General Programming Steps

1. To edit memory locations and Program flow:

Press any key in the Edit Memory Location box.

2. To run the stored program following the defined program flow:

SHIFT

RUN

(Execution starts after the last accessed memory location. Looping applies only when the start of loop location is $\geq$ the last accessed location.)

3. To single step through stored program following the defined program flow:

STEP

(Execution starts after the last accessed memory location. Looping applies only when the start of loop location is $\geq$ the first executed location.)

4. To stop motion:

STOP

Programming Memory Locations (Coordinates in Counts)

MEMORY LOCATION 00:

EXECUTE POINT	SKIP POINT
COORDINATE	-420
VELOCITY	13333
ACCEL	25600
MOVE RELATIVE	MOVE ABSOLUTE
PAUSE 0 SEC	WAIT
LOOP COUNT	0
END LOOP OFF	END LOOP ON
END PROGRAM OFF	END PROGRAM ON

MEMORY LOCATION 01:

EXECUTE POINT	SKIP POINT
COORDINATE	-600
VELOCITY	13333
ACCEL	25600
MOVE RELATIVE	MOVE ABSOLUTE
PAUSE 0 SEC	WAIT
LOOP COUNT	0
END LOOP OFF	END LOOP ON
END PROGRAM OFF	END PROGRAM ON


MEMORY LOCATION 02:

EXECUTE POINT	SKIP POINT
COORDINATE	-850
VELOCITY	13333
ACCEL	25600
MOVE RELATIVE	MOVE ABSOLUTE
PAUSE 0 SEC	WAIT
LOOP COUNT	0
END LOOP OFF	END LOOP ON
END PROGRAM OFF	END PROGRAM ON

MEMORY LOCATION 03:

EXECUTE POINT	SKIP POINT
COORDINATE	-200
VELOCITY	13333
ACCEL	25600
MOVE RELATIVE	MOVE ABSOLUTE
PAUSE 0 SEC	WAIT
LOOP COUNT	0
END LOOP OFF	END LOOP ON
END PROGRAM OFF	END PROGRAM ON

Program Flow



Programming Memory Locations with a loop (Coordinates in Counts)

MEMORY LOCATION 00:

EXECUTE POINT	SKIP POINT
COORDINATE	-420
VELOCITY	13333
ACCEL	25600
MOVE RELATIVE	MOVE ABSOLUTE
PAUSE 0 SEC	WAIT
LOOP COUNT	0
END LOOP OFF	END LOOP ON
END PROGRAM OFF	END PROGRAM ON

MEMORY LOCATION 01:

EXECUTE POINT	SKIP POINT
COORDINATE	-600
VELOCITY	13333
ACCEL	25600
MOVE RELATIVE	MOVE ABSOLUTE
PAUSE 0 SEC	WAIT
LOOP COUNT	2
END LOOP OFF	END LOOP ON
END PROGRAM OFF	END PROGRAM ON


MEMORY LOCATION 02:

EXECUTE POINT	SKIP POINT
COORDINATE	-850
VELOCITY	13333
ACCEL	25600
MOVE RELATIVE	MOVE ABSOLUTE
PAUSE 0 SEC	WAIT
LOOP COUNT	0
END LOOP OFF	END LOOP ON
END PROGRAM OFF	END PROGRAM ON

MEMORY LOCATION 03:

EXECUTE POINT	SKIP POINT
COORDINATE	-200
VELOCITY	13333
ACCEL	25600
MOVE RELATIVE	MOVE ABSOLUTE
PAUSE 0 SEC	WAIT
LOOP COUNT	0
END LOOP OFF	END LOOP ON
END PROGRAM OFF	END PROGRAM ON


Program Flow



Multi-Axis System

The MC-5B has the ability to be interconnected with multiple MC-5B's to form a multi-axis system. When more than one MC-5B's are connected, the user must make the "MultiNode Mode" menu selection on all the respective controllers and assign a unique node address from 1-99 (also a menu selection). Once the communication ports of the MC-5B's are physically connected (see illustration) and network addresses have been assigned, programming and control of any "node" may be performed from any one of the connected controllers.

Connections - Multi-Axis System



SYMBOL LEGEND

- M** Male 9 pin D-Sub Port
- F** Female 9 pin D-Sub Port
- MM** Male to Male 9 pin D-Sub Gender Changer
- LB** RS-232 "LOOPBACK"
- ①** RS-232 "STRAIGHT-THRU" Cable

Operating a Controller from the Keypad of Another Node

(Set to MultiNode Mode in Menu – see Menu section)

1. To assign node ID's to all nodes in the networked system, starting at 1:

SHIFT

ASGN NDS

2. To establish control of node 2 from a controller other than node 2 (node 1 for example):

2

Node 2's functionality will now be accessible from node 1.

("Node 2" will be displayed on the top line of node 1. If communication is successfully established, the current position of node 2 will be displayed on the second line of node 1. Node 2 will also display the text "C1" to signify that it is under the control of node 1. If node 2's current position is not displayed on the second line of node 1, review Setup section and connections.)

0 is the broadcast address, and most commands may be sent to all nodes using the 0 node broadcast address. Once control of a given node has been established, it is not necessary to use the node ID as a prefix to subsequent commands.

3. To relinquish remote control of node 2 and re-establish control of the local node:

ENTER

4. To jog node 2 remotely from node 1:

2

JOG

5. To change the units on node 2 to inches (from node 1):

2

SHIFT

UNITS

(repeat until inches are displayed)

6. To move node 3 to 0.3 inches, node 2 to 0.2 inches and node 1 to 0.1 inches (from node 1):
Change units of all nodes to inches, then

3

MOVE

.

3

ENTER

2

MOVE

.

2

ENTER

1

MOVE

.

1

ENTER

7. To store the current positions of all nodes at each one's respective memory location 25:

0

STORE

2

5

ENTER

8. To jog node 2 remotely from node 1, store the final position in node 2's memory location 6 and reestablish control of the local node 1:

2

JOG

STORE

6

ENTER

ENTER

9. To change node 2's mode from VMode Jog to Step Jog from node 1:

2

MENU SEL

MENU V (down)

MENU SEL

ENTER

10. To edit node 2's memory location 4 velocity and end program parameters:

2

EDIT

Then press

JOG>

or

JOG<

until 4 is displayed, or enter **4** at the Location to Edit prompt.

(Do not press ENTER now.)

Next press

EDIT V (down)

3 times to scroll to the velocity parameter. Key in the desired velocity in the units displayed, then press

EDIT V (down)

6 times to scroll to the end program parameter. Press

EDIT SEL

to set the end program parameter to ON, then press

ENTER

to conclude the editing process for node 2.

ENTER

relinquishes remote control of node 2

11. To home:

SHIFT

AUTO-HOME

12. To change the displayed units:

SHIFT

UNITS

APPENDIX

Specifications

MC-5B Controller

Display:	Two-line, 20 character alphanumeric LCD
Control:	Keypad
Optional Accessories:	Communication Kit Remote Dial Encoder Wheel, Remote Joystick
Motor Load:	Any 6-12 VDC brush type motor (750mA max.)
Encoder Interface:	Single ended, 5VDC TTL compatible A/B Quadrature Encoder Input
Remote Communication:	RS232
Dimensions:	5.2 x 7.5 x 2.5 inches.
Weight:	2.75 lbs.
Operating Temp:	20° C (Ambient)
Fuse:	2 Amp Bussman model ABC-2 (or equivalent)

MC-5B Power Supply

Input Voltage:	100~240Vac
Input Frequency	47 to 63Hz
Input Current:	0.6A max.
Output Voltage:	15 VDC
Output Current:	1.4 A
Operating Temp:	20°C (Ambient)
Dimension:	4.35 x 1.95 x 1.2 inches
Weight:	0.5 Pounds

Troubleshooting and Set-Up Assistance

APPENDIX

B

Problem	Possible Cause and remedy
Stage runs at full speed out of control to one end.	Encoder direction (menu item) reversed: either because of menu control accident or use with motor of convention other than NAI stages.
Memory Locations do not store where you want to put them	“Sequential” storage mode engaged; use “Store By Entry” mode
Sluggish takeoff and landing	Low base acceleration setting
Sluggish jog steps	Low Jog Step Acceleration setting
Erratic jog steps	Jog Step Acceleration set too high for the jog step size.
Stops abruptly	Excessive base acceleration
Stage stops before move is completed, re-starts when GoTo is pressed	Following error related: a) Possible obstruction to motion, including lubrication problems. b) Acceleration and/or velocity too high for current gear-load combination or following error allowance. c) Following error set too low; stall threshold may vary “day-to-day”
Limits don't stop the stage	Wires to stage limits disconnected or reversed. Conductor # 10 (if ribbon), or black conductor (if round cable) should have continuity to fwd (motor) end of stage by way of connecting stage rail.
Stage overshoots destination before arriving	PID parameters need to be adjusted. Integral (I term) possibly set too high.
Grinding Noise	Check the PID tuning parameters.
Not Homing	Acceleration value set too high.

Examples, Servo Settings

Suggested for MC-5B with typical NAI stage configurations.

APPENDIX

C

Menu Settings

	Rotary or Linear	Homing Offset	VMode Jog x 1,4	Base Velocity	Base Accel.	Backlash Comp.	Counts per inch	Counts per rev.	Following Error	PID Kp	PID Ki
MM-3M-F, EX 1 inch travel 10 mm motor 16:1 gear	Linear	25,600	1	13,333	25,600	20	51,200		1,000	600	400
MM-3M-F, EX 1 inch travel 10 mm motor 64:1 gear	Linear	102,400	4	13,333	25,600	35	204,800		1,000	600	400
MM-3M-F, EX, AB 1 inch travel 10 mm motor 64:1 gear Anti-Backlash, High Linearity	Linear						204,800				
MM-3M-R Rotary 16:1 gear	Rotary							51,200			
MM-3M-R Rotary 64:1 gear	Rotary							204,800			
MM-3M-R Rotary Ultra-low Wobble 16:1 gear	Rotary							51,200			
MM-3M-R Rotary Ultra-low Wobble 64:1 gear	Rotary							204,800			
MM-4M-F, 25 mm travel 10 mm motor 16:1 gear	Linear						51,200				
MM-4M-EX 1 inch travel 13 mm motor ~14:1 gear	Linear						70,634				
MM-4M-R Rotary 13 mm motor ~14:1 gear	Rotary							79,464			

Note: The table shows encoder count units, but the data on the MC-5B display will be in the units chosen.

Please request updates for more data.

Stage Resolution

Linear Stages

Counts per Inch = 4 * (Encoder Lines/Motor Rev) * Motor Gear Ratio * (Lead Screw Turns/Inch)

Stage	Enc. Gear	Enc. Lines	turns/in	Counts/In
MM3M	16:1	10	80	51,200
MM3M	64:1	10	80	204,800
MM3M	256:1	10	80	819,200
MM3M	1024:1	10	80	3,276,800
MM4M	3.71:1	16	80	19,017
MM4M	14:1	16	80	70,635
MM4M	43:1	16	80	219,754
MM4M	66:1	16	80	339,048
MM4M	134:1	16	80	683,678

Rotary Stages

Counts per Rev = 4 * (Encoder Lines/Motor Rev) * Motor Gear Ratio * Stage Gear Teeth

Stage	Motor Gear	Enc. Lines	Stg. Gr. Teeth	Counts/Rev
MM3MR	16:1	10	80	51,200
MM3MR	64:1	10	80	204,800
MM3MR	256:1	10	80	819,200
MM3MR	1024:1	10	80	3,276,800
MM4MR	3.71:1	16	90	21,394
MM4MR	14:1	16	90	79,464
MM4MR	43:1	16	90	247,223
MM4MR	66:1	16	90	381,430
MM4MR	134:1	16	90	769,138

Settings for Standard Stage Product

Linear Stages:

MM-3M-EX, MM-3M-F, MM-3M-ST and MM-4M-F

(10mm Motor, 10 Position Encoder and 80 TPI Lead Screw)

<u>Gear Head</u>	<u>Counts Per Inch</u>	<u>Counts Per Centimeter</u>
16:1	51,200	20,157
64:1	204,800	80,630
256:1	819,200	322,520
1,024:1	3,276,800	1,290,079

Maxon Motor - 10mm

12 position encoder x 4 (quadrature) = 48 counts/mtr Rev.

Gearhead = 16:1

$$\left(\frac{48 \text{ counts}}{1 \text{ mtr Rev}} \right) \cdot \left(\frac{16 \text{ mtr Rev}}{1 \text{ GH Rev}} \right) \cdot \left(\frac{1 \text{ GH Rev}}{0.0125 \text{ in.}} \right) = 61,440 \text{ counts/inch}$$

Micro Mo - 10mm

10 position encoder x 4 (quadrature) = 40 counts/mtr Rev

Gearhead = 16:1

$$\left(\frac{40 \text{ counts}}{1 \text{ mtr Rev}} \right) \cdot \left(\frac{16 \text{ mtr Rev}}{1 \text{ GH Rev}} \right) \cdot \left(\frac{1 \text{ GH Rev}}{0.0125 \text{ in.}} \right) = 51,200 \text{ counts/inch}$$

MM-4M-EX

(13mm Motor, 16 Position Encoder and 80TPI Lead Screw)

<u>Gear Head Nominal</u>	<u>Gear Head Actual</u>	<u>Counts Per Inch</u>	<u>Counts Per Centimeter</u>
14:1	13.795918367:1	70,635	27,809

Rotary Stages:

MM-3M-R

(10mm Motor, 10 Position Encoder and 80:1 Table)

<u>Gear Head</u>	<u>Counts Per 360 Degrees</u>
64:1	204,800
256:1	819,200
1,024:1	3,276,800

MM-4M-R

(13mm Motor, 16 Position Encoder and 90:1 Table)

<u>Gear Head Nominal</u>	<u>Gear Head Actual</u>	<u>Counts Per 360 Degrees</u>
14:1	13.795918367:1	79,465

Motor Connector Pin Assignments:

APPENDIX

F


Motor Type: DC, Brush Type

Connector Type: 10 pin IDC (female) or 9 pin mini DIN (male)

10 pin IDC Connector Pin Assignments

Pin #	Name	Pin #	Name
1	Motor (-)	6	Motor (+)
2	Encoder Supply	7	Limit ground
3	Encoder Ch A	8	Limit VCC + 5V
4	Encoder Ch B	9	Reverse limit
5	Case Ground	10	Forward limit


10 Pin IDC Connector



9 Pin Mini DIN Pin Assignments

Pin#	Name	Pin #	Name
1	Motor (-)	6	Motor (+)
2	Encoder Supply	7	Limit Ground
3	Encoder Ch A	8	Forward Limit
4	Encoder Ch B	9	Reverse limit
5	Encoder/Case Ground		

9 Pin Mini DIN Connector



I N D E X

B

Backlash	6
Backlash Comp	6
Base accel	6
Base velocity	6
Basic Menu Selections	5
Benefits	1

C

Connections - Multi Axis System	17
Connections – Single Axis System	3
Counts per Inch, cm or rev	6

D

Default Setting	3
Dial Step	6
Dial Step = Jog Step	6

E

Enc Lns per Rev	6
End Program	13
Examples, Servo Settings	25

F

Features	1
Final Homing Velocity	5
Following Error	6
Free Jog	5
Fwd Limit Off	5
Fwd Limit Value	5

G

General Programming Steps	14
---------------------------------	----

H

Home to Fwd End	5
Home to Rev End	5
Homing Offset	5

J

Jog Step Accel	6
Jog Vel Multplr	6

K

Key Function Examples	10
KEY FUNCTIONS	9

L

Linear Motion	5
Locked Jog	5
Looping	13

M

Memory Locations and Program Flow	13
Motor Connector Pin Assignments:	28
Multi-Axis System	17
Multi-Node Mode	5

N

Node	6
Normal	5, 6
Normal and Shift Functions	9
Normal Display	5

O

Overview	1
----------------	---

P

PID Deriv tSamp	6
PID iLimit	6
PID Kd	6
PID Ki	6
PID Kp	6
Power Up and Configuration	3
Program Execution	13
Programming Memory Locations	15

R

Rev Backlash	6
Rev Limit Off	5
Rev Limit Value	5
Reverse Dir Key	6
Reverse Display	5
Rotary Motion	5

S

Sequential	5
Settings for Standard Stage Product	27
Setup	3
Single Node Mode	5
Specifications	23
Stage Resolution	26
Step Base Increment	6
Step Jog	5
Store By Entry	5

T

To set backlash compensation	7
To Set Forward Limit Off	7
To Set Forward Limit Value	7
To Set Multi Node Mode	7
To Set Single Node Mode	7
Troubleshooting and Set-Up Assistance	24

V

VMode Jog	5
-----------------	---

W

What You'll Need	3
------------------------	---