



Product Overview

The Catalyst 3750 family of switches—also referred to as the *switches*—are stackable Ethernet switches to which you can connect devices like Cisco IP Phones, Cisco Wireless Access Points workstations, and other network devices such as servers, routers, and other switches. This chapter provides a functional overview of the Catalyst 3750 switch models. These topics are included:

- [Features, page 1-1](#)
- [Front Panel Description, page 1-3](#)
- [Rear Panel Description, page 1-20](#)
- [Management Options, page 1-23](#)

Features

The switches can be deployed as backbone switches, aggregating 10BASE-T, 100BASE-TX, and 1000BASE-T Ethernet traffic from other network devices. See the switch software configuration guide for examples showing how you might deploy the switches in your network.

[Figure 1-2](#) through [Figure 1-13](#) show the Catalyst 3750 switches.

These are the switch features:

- Fast Ethernet Configurations
 - Catalyst 3750-24FS switch—24 100BASE-FX ports and 2 small form-factor pluggable (SFP) module slots
 - Catalyst 3750-24TS switch—24 10/100 Ethernet ports and 2 SFP module slots
 - Catalyst 3750-48TS switch—48 10/100 Ethernet ports and 4 SFP module slots
 - Catalyst 3750-24PS switch—24 10/100 Power over Ethernet (PoE) ports and 2 SFP module slots
 - Catalyst 3750-48PS switch—48 10/100 PoE ports and 4 SFP module slots
- Gigabit Ethernet Configurations
 - Catalyst 3750G-24T switch—24 10/100/1000 Ethernet ports
 - Catalyst 3750G-24TS switch—1.5 rack units (RU)—24 10/100/1000 Ethernet ports and 4 SFP module slots
 - Catalyst 3750G-24TS-1U switch—1 RU—24 10/100/1000 Ethernet ports and 4 SFP module slots

- Catalyst 3750G-48TS switch—48 10/100/1000 Ethernet ports and 4 SFP module slots
- Catalyst 3750G-12S switch—12 SFP module slots
- Catalyst 3750G-24PS switch—24 10/100/1000 PoE ports and 4 SFP module slots
- Catalyst 3750G-48PS switch—48 10/100/1000 PoE ports and 4 SFP module slots
- 10-Gigabit Ethernet Configuration
 - Catalyst 3750G-16TD switch—16 10/100/1000 Ethernet ports and 1 10-Gigabit Ethernet XENPAK module slot



Note The 10-Gigabit Ethernet XENPAK modules are referred to as 10-Gigabit Ethernet module ports in the software documentation.

- The switches support these SFP modules:
 - 100BASE-FX multimode fiber (MMF)
 - 1000BASE-SX
 - 1000BASE-LX
 - 1000BASE-ZX
 - 1000BASE-T
 - 1000BASE-BX
 - Coarse wavelength-division multiplexing (CWDM)



Note When installed in Catalyst 3750 switches, 1000BASE-T SFP modules can either operate at 10, 100, or 1000 Mbps in full-duplex mode or in half-duplex mode at 10 or 100 Mbps.

- For a list of the XENPAK modules that the Catalyst 3750G-16TD switch supports, see the [Table 1-1 on page 1-12](#).
- Configuration
 - For 10/100 ports, autonegotiates the speed and duplex settings
 - For 10/100/1000 ports, autonegotiates the speed and supports only full-duplex mode



Note You can configure duplex mode to half, full, or autonegotiate on Gigabit Ethernet interfaces if the speed is set to 10 or 100 Mbps. You cannot configure half-duplex mode on Gigabit Ethernet interfaces if the interface speed is 1000 Mbps.

- The Catalyst 3750 switches support stacking. You can stack up to nine switches in a stack by cabling the StackWise ports. StackWise ports are not user-configurable.
- Switches are hot-swappable.
- Connection for optional Cisco RPS 675 redundant power system that operates on AC input and supplies backup DC power output to the Catalyst 3750 switches.

Front Panel Description

These sections describe the Fast Ethernet and Gigabit Ethernet switches:

- [Fast Ethernet Front Panel Switches, page 1-3](#)
- [Gigabit Ethernet Switch Front Panel Descriptions, page 1-6](#)
- [10/100 and 10/100/1000 Ports, page 1-10](#)
- [SFP Module Slots, page 1-12](#)
- [XENPAK Module Slot, page 1-12](#)
- [LEDs, page 1-13](#)

Fast Ethernet Front Panel Switches


These sections describe the front panels for the Catalyst 3750 Fast Ethernet switches:

- [Catalyst 3750-24FS Switch Front Panel Description, page 1-3](#)
- [Catalyst 3750-24TS Switch Front Panel Description, page 1-4](#)
- [Catalyst 3750-48TS Switch Front Panel Description, page 1-4](#)
- [Catalyst 3750-24PS Switch Front Panel Description, page 1-5](#)
- [Catalyst 3750-48PS Switch Front Panel Description, page 1-5](#)

Catalyst 3750-24FS Switch Front Panel Description

The Catalyst 3750-24FS 00BASE-FX ports are numbered 1 through 24, as shown in [Figure 1-1](#). The SFP modules slots are numbered 1 (left) and 2 (right).

Figure 1-1 Catalyst 3750-24FS Front Panel




1	10/100 ports	2	SFP module slots
---	--------------	---	------------------

Catalyst 3750-24TS Switch Front Panel Description

The Catalyst 3750-24TS 10/100 ports are numbered 1 through 24. The ports are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-2](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 1 (left) and 2 (right).

Figure 1-2 Catalyst 3750-24TS Front Panel




1	10/100 ports	2	SFP module slots
----------	--------------	----------	------------------

Catalyst 3750-48TS Switch Front Panel Description

The Catalyst 3750-48TS 10/100 ports are numbered 1 through 48. The ports are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-3](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 1 to 4.

Figure 1-3 Catalyst 3750-48TS Front Panel




1	10/100 ports	2	SFP module slots
----------	--------------	----------	------------------

Catalyst 3750-24PS Switch Front Panel Description

The 10/100 PoE ports on the Catalyst 3750-24PS switch are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-4](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 1 and 2.

Figure 1-4 Catalyst 3750-24PS Switch Front Panel




1	10/100 PoE ports	2	SFP module slots
---	------------------	---	------------------

Catalyst 3750-48PS Switch Front Panel Description

The 10/100 PoE ports on the Catalyst 3750-48PS switch are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-5](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 1 to 4.

Figure 1-5 Catalyst 3750-48PS Switch Front Panel



1	10/100 PoE ports	2	SFP module slots
---	------------------	---	------------------

Gigabit Ethernet Switch Front Panel Descriptions


These sections describe the front panels for the Gigabit Ethernet switches:

- [Catalyst 3750-24T, 3750G-24TS, and 3750G-24TS-1U Switch Front Panel Descriptions, page 1-6](#)
- [Catalyst 3750G-12S Front Panel Description, page 1-7](#)
- [Catalyst 3750G-48TS Front Panel Description, page 1-8](#)
- [Catalyst 3750G-24PS Switch Front Panel, page 1-8](#)
- [Catalyst 3750G-48PS Switch Front Panel Description, page 1-9](#)
- [Catalyst 3750G-16TD Switch Front Panel Description, page 1-9](#)

Catalyst 3750-24T, 3750G-24TS, and 3750G-24TS-1U Switch Front Panel Descriptions


The 10/100/1000 ports on the Catalyst 3750G-24T, 3750G-24TS, and 3750G-24TS-1U switches are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-6](#), [Figure 1-7](#), and [Figure 1-8](#). Port 3 is above port 4, and so on. In [Figure 1-7](#) and [Figure 1-8](#), the SFP module slots are numbered 25 to 28.

Figure 1-6 Catalyst 3750G-24T Front Panel




1	10/100/1000 ports
---	-------------------

Figure 1-7 Catalyst 3750G-24TS Front Panel



1	10/100/1000 ports	2	SFP module slots
---	-------------------	---	------------------

Figure 1-8 Catalyst 3750G-24TS-1U Front Panel




1	10/100/1000 ports	2	SFP module slots
---	-------------------	---	------------------

Catalyst 3750G-12S Front Panel Description

The Catalyst 3750G-12S SFP module slots are numbered 1 through 12. The slots are grouped in three sets of four, as shown in Figure 1-9.

Figure 1-9 Catalyst 3750G-12S Front Panel




1	SFP module slots
---	------------------

Catalyst 3750G-48TS Front Panel Description

The Catalyst 3750G-48TS 10/100/1000 ports are numbered 1 through 48. The ports are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-10](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 49 to 52.

Figure 1-10 Catalyst 3750G-48TS Front Panel




1	10/100/1000 ports	2	SFP module slots
----------	-------------------	----------	------------------

Catalyst 3750G-24PS Switch Front Panel

The 10/100/1000 PoE ports on the Catalyst 3750G-24PS switch are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-11](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 25 to 28.

Figure 1-11 Catalyst 3750G-24PS Switch Front Panel




1	10/100/1000 PoE ports	2	SFP module slots
----------	-----------------------	----------	------------------

Catalyst 3750G-48PS Switch Front Panel Description

The 10/100/1000 PoE ports on the Catalyst 3750G-48PS switch are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-12](#). Port 3 is above port 4, and so on. The SFP module slots are numbered 49 to 52.

Figure 1-12 Catalyst 3750G-48PS Switch Front Panel



1	10/100/1000 PoE ports	2	SFP module slots
---	-----------------------	---	------------------

Catalyst 3750G-16TD Switch Front Panel Description


The 10/100/1000 ports on the Catalyst 3750G-16TD switch are grouped in pairs. The first member of the pair (port 1) is above the second member (port 2), as shown in [Figure 1-13](#). Port 3 is above port 4, and so on. The XENPAK module slot is numbered 1.



Note

The 10-Gigabit Ethernet XENPAK modules are referred to as 10-Gigabit Ethernet module ports in the software documentation.

Figure 1-13 Catalyst 3750G-16TD Switch Front Panel



1	10/100/1000 ports	2	XENPAK module slot
---	-------------------	---	--------------------

10/100 and 10/100/1000 Ports

You can set the 10/100 ports on the Catalyst 3750 switches to operate in any combination of half duplex, full duplex, 10 Mbps, or 100 Mbps. You can set the 10/100/1000 ports to operate in 10 or 100 Mbps in half or full duplex, or in 1000 Mbps in full duplex.

You can set both the 10/100 and the 10/100/1000 ports for speed and duplex autonegotiation, in compliance with IEEE 802.3AB. (The default setting is autonegotiate.)



Note

You can configure duplex mode to half, full, or autonegotiate on Gigabit Ethernet interfaces if the speed is set to 10 or 100 Mbps. You cannot configure half-duplex mode on Gigabit Ethernet interfaces if the interface speed is 1000 Mbps.

When set for autonegotiation, the port senses the speed and duplex settings of the attached device and advertises its own capabilities. If the connected device also supports autonegotiation, the switch port negotiates the best connection (the fastest line speed that both devices support and full-duplex transmission if the attached device supports it) and configures itself accordingly. In all cases, the attached device must be within 328 feet (100 meters).



Warning

Voltages that present a shock hazard may exist on Power over Ethernet (PoE) circuits if interconnections are made using uninsulated exposed metal contacts, conductors, or terminals. Avoid using such interconnection methods, unless the exposed metal parts are located within a restricted access location and users and service people who are authorized within the restricted access location are made aware of the hazard. A restricted access area can be accessed only through the use of a special tool, lock and key or other means of security. Statement 1072

The 10/100 ports on the Catalyst 3750-24PS and 3750-48PS switches and the 10/100/1000 ports on the Catalyst 3750G-24PS and 3750G-48PS switches provide PoE support for devices compliant with IEEE 802.3af and also provide Cisco pre-standard PoE support for Cisco IP Phones and Cisco Aironet Access Points.

Each of the Catalyst 3750G-24PS switch 10/100 ports or the Catalyst 3750G-24PS switch 10/100/1000 ports can deliver up to 15.4 W of PoE. On the Catalyst 3750-48PS or 3750G-48PS switches, any 24 of the 48 10/100 or 10/100/1000 ports can deliver 15.4 W of PoE, or any combination of the ports can deliver an average of 7.7 W of PoE at the same time, up to a maximum switch power output of 370 W.

On a per-port basis, you can control whether or not a Catalyst 3750 PoE port automatically provides power when an IP phone or an access point is connected. The device manager and the CLI provide two PoE settings for each 10/100 or 10/100/1000 PoE port: Auto and Never.

When you select the Auto setting, the port provides power only if a valid powered device, such as an IEEE 802.3af-compliant powered device, a Cisco pre-standard IP phone, or a Cisco pre-standard Cisco access point, is connected to it. The Auto setting is the default. However, when you select the Never setting, the port does not provide power even if a Cisco IP phone or an access point is connected to it. For information about configuring and monitoring PoE ports, see the device manager online help and the switch software configuration guide.

Cisco enhanced power negotiation allows some powered devices, such as the Cisco 7970G IP Phone, to operate in high-power mode on Catalyst 3750 PoE switches. The powered device and the switch negotiate through power-negotiation Cisco Discovery Protocol (CDP) messages for an agreed-upon power-consumption level. The negotiation allows a high-power Cisco powered device that consumes more than 7 W to operate at its highest power mode. The powered device first boots up in low-power

mode, consumes less than 7 W, and negotiates to obtain enough power to operate in high-power mode. The device changes to high-power mode only when it receives confirmation from the switch. High-power devices can operate in low-power mode on switches that do not support power-negotiation CDP.

For information about configuring and monitoring PoE ports, see the device manager online help and the switch software configuration guide.

**Note**

You also can connect a Cisco IP Phone or Cisco Aironet Access Point to a Catalyst 3750 PoE switch 10/100 or 10/100/1000 port and to an AC power source for redundant power. The powered device might change to the AC power source as its primary power source when connected to it. In that case, the PoE port becomes the backup power source for the powered device.

If the primary source fails, the second power source becomes the primary power source to the powered device. During the power transfer, an IP Phone might reboot or reestablish link with the switch.

For information about Cisco IP Phones and Cisco Aironet Access Points, see the documentation that came with your IP phone or access point.

**Note**

100BASE-TX and 1000BASE-T traffic requires Category 5 cable. 10BASE-T traffic can use Category 3 or Category 4 cables.

When connecting the switch to workstations, servers, routers, and Cisco IP Phones, be sure that the cable is a straight-through cable. When connecting the switch to switches or hubs, use a crossover cable. When using a straight-through or crossover cable for 1000BASE-T connections, be sure to use a twisted four-pair, Category 5 cable for proper operation. Pinouts for the cables are described in [Appendix A, “Technical Specifications.”](#)

**Note**

You can use the **mdix auto** interface configuration command in the CLI to enable the automatic medium-dependent interface crossover (Auto-MDIX) feature. When the Auto-MDIX feature is enabled, the switch detects the required cable type for copper Ethernet connections and configures the interfaces accordingly. Therefore, you can use either a crossover or a straight-through cable for connections to a copper 10/100, 10/100/1000, or 1000BASE-T SFP module port on the switch, regardless of the type of device on the other end of the connection.

The Auto-MDIX feature is enabled by default on switches running Cisco IOS Release 12.2(18)SE or later. For releases between Cisco IOS Release 12.1(14)EA1 and 12.2(18)SE, the Auto-MDIX feature is disabled by default. For configuration information for this feature, see the switch software configuration guide or the switch command reference.

**Note**

Many legacy powered devices, including older Cisco IP phones and access points that do not fully support IEEE 802.3af, might not support PoE when connected to the switches by a crossover cable.

100BASE-FX Ports

The 100BASE-FX ports use 50/125- or 62.5/125-micron multimode fiber-optic cabling. In full-duplex mode, the cable length from a switch to an attached device cannot exceed 6,562 feet (2 kilometers).

The 100BASE-FX ports operate only at 100 Mbps in either full- or half-duplex mode and do not support autonegotiation. The half-duplex mode is the default setting.

You can connect a 100BASE-FX port to an SC or ST port on a target device by using one of the MT-RJ fiber-optic patch cables listed in [Table B-1 on page B-3](#).

SFP Module Slots

Catalyst 3750 switches with SFP module slots support these SFP modules:

- 1000BASE-SX
- 1000BASE-LX
- 1000BASE-ZX
- 100BASE-FX (MMF)
- 1000BASE-T
- CWDM

For a list of the SFP modules that the switches support, see the Catalyst 3750 release notes.

SFP Modules

The Catalyst 3750 switch uses Gigabit Ethernet SFP modules to establish connections to other devices. These transceiver modules are field-replaceable, providing the uplink interfaces when inserted in an SFP module slot. You can use the SFP modules for Gigabit uplink connections to other switches. You use fiber-optic cables with LC or MT-RJ connectors to connect to a fiber-optic SFP module. You use Category 5 cable with RJ-45 connectors to connect to a copper SFP module.

For more information about these SFP modules, see your SFP module documentation.

XENPAK Module Slot

The Catalyst 3750G-16TD switch uses 10-Gigabit Ethernet XENPAK modules to establish connections to networks. The modules are installed in the module slot in the switch front panel.

[Table 1-1](#) lists the XENPAK modules that the Catalyst 3750G-16TD switch supports.

Table 1-1 Catalyst 3750G-16TD Switch Supported XENPAK Modules

XENPAK	Wavelength	Connector and Cable Type	Maximum Distance
XENPAK-10GB-LR	1310 nm	SC, SMF	6.2 miles (10 km)
XENPAK-10GB-ER	1550 nm	SC, SMF	24.85 miles (40 km)
XENPAK-10GB-CX4	—	Infiniband	49 feet (15 m)

Table 1-1 Catalyst 3750G-16TD Switch Supported XENPAK Modules (continued)

XENPAK	Wavelength	Connector and Cable Type	Maximum Distance
XENPAK-10GB-SR	850 nm	SC; FDDI ¹ grade MMF SC; OM3 MMF	85.3 feet (26 m) 984.25 feet (300 m)
XENPAK-10GB-LX4	1310 nm	SC; MMF	984.25 feet (300 m)

1. FDDI = fiber distributed data interface

For more information about XENPAK modules, see your XENPAK module documentation.

**Note**


The 10-Gigabit Ethernet XENPAK modules are referred to as 10-Gigabit Ethernet module ports in the software documentation.

LEDs

You can use the switch LEDs to monitor switch activity and its performance. [Figure 1-14](#) shows the Catalyst 3750 switch LEDs and the Mode button that you use to select one of the port modes.

All LEDs are visible through the GUI management applications—the Network Assistant application for multiple switches and the device manager GUI for a single switch. The switch software configuration guide describes how to use the command-line interface (CLI) to configure and monitor individual switches and switch clusters.


Figure 1-14 Catalyst 3750-24TS, 3750G-24T, 3750G-12S, 3750G-16TD, 3750-48TS, 3750G-48TS, 3750G-24TS, and 3750G-24TS-1U Switch LEDs



86545

1	Mode button	6	Master LED
2	Stack LED	7	RPS LED
3	Speed LED	8	System LED
4	Duplex LED	9	Port LED
5	Status LED		

Figure 1-15 Catalyst 3750-24PS, 3750G-24PS, 3750-48PS, and 3750G-48PS Switch LEDs



104062

1	Mode button	6	Status LED
2	PoE LED	7	Master LED
3	Stack LED	8	RPS LED
4	Speed LED	9	System LED
5	Duplex LED		

System LED

The System LED shows whether the system is receiving power and is functioning properly. [Table 1-2](#) lists the LED colors and their meanings.

Table 1-2 System LED

Color	System Status
Off	System is not powered on.
Green	System is operating normally.
Amber	System is receiving power but is not functioning properly.

For information on the System LED colors during power-on self-test (POST), see the “[Powering On the Switch and Running POST](#)” section on page 2-7.

RPS LED

The RPS LED shows the RPS status. [Table 1-3](#) lists the LED colors and their meanings.

Table 1-3 RPS LED

Color	RPS Status
Off	RPS is off or not properly connected.
Green	RPS is connected and ready to provide back-up power, if required.
Flashing green	RPS is connected but is unavailable because it is providing power to another device (redundancy has been allocated to a neighboring device).
Amber	The RPS is in standby mode or in a fault condition. Press the Standby/Active button on the RPS, and the LED should turn green. If it does not, the RPS fan could have failed. Contact Cisco Systems.
Flashing amber	The internal power supply in a switch has failed, and the RPS is providing power to the switch (redundancy has been allocated to this device).

For more information about the Cisco RPS 675, see the *Cisco RPS 675 Redundant Power System Hardware Installation Guide*.

Master LED

The Master LED shows the stack master status. [Table 1-3](#) lists the LED colors and their meanings.

Table 1-4 Master LED

Port Mode	Description
Off	Switch is not the stack master.
Green	Switch is the stack master or a standalone switch.
Amber	An error occurred when the switch was selecting the stack master switch or a stack error.

Port LEDs and Modes

Each RJ-45 port, SFP module slot, and XENPAK module slot has a port LED. These port LEDs, as a group or individually, display information about the switch and about the individual ports. The port modes determine the type of information displayed through the port LEDs. [Table 1-5](#) lists the mode LEDs and their associated port mode and meaning.

To select or change a mode, press the Mode button until the desired mode is highlighted. When you change port modes, the meanings of the port LED colors also change. [Table 1-7](#) explains how to interpret the port LED colors in different port modes.

If your switches are stacked and you press the Mode button on any one of the switches in the stack, all the switches in the stack change to display the same selected mode. For example, if you press the mode button on the stack master to display SPEED, all the other switches in the stack also display SPEED.

Table 1-5 Port Mode LEDs

Mode LED	Port Mode	Description
STAT	Port status	The port status. This is the default mode.
DUPLX	Port duplex mode	The port duplex mode: full duplex or half duplex. Note The 10/100/1000 ports operate only in full-duplex mode.
SPEED	Port speed	The port operating speed: 10, 100, or 1000 Mbps.
STACK	Stack member status	The stack member status.
	StackWise port status	The StackWise port status. See the “Stack LED” section on page 1-18 for more information.
PoE ¹	10/100 and 10/100/1000 PoE port power	The PoE status.

1. The PoE LED is on the Catalyst 3750-24PS, 3750G-24PS, 3750-48PS, and 3750G-48PS switches.

Even if PoE mode is not selected on a Catalyst 3750-24PS, 3750G-24PS, 3750-48PS, or 3750G-48PS switch, the PoE LED still shows PoE problems when they are detected.

[Table 1-6](#) lists the PoE LED colors and their meanings.

Table 1-6 PoE Mode LED

Color	PoE Status
Off	PoE mode is not selected. None of the 10/100 or 10/100/1000 ports have been denied power or are in a fault condition.
Green	PoE mode is selected, and the PoE status is shown on the port LEDs.
Blinking amber	PoE mode is not selected. At least one of the 10/100 or 10/100/1000 ports has been denied power, or at least one of the 10/100 or 10/100/1000 ports has a PoE fault.

Table 1-7 lists the LED colors in different modes and their meanings.

Table 1-7 *Meaning of LED Colors in Different Modes on the Switch*

Port Mode	Port LED Color	Meaning
PoE ¹	Off	PoE is off. If the powered device is receiving power from an AC power source, the port LED is off even if the powered device is connected to the switch port.
	Green	PoE is on. The port LED is green only when the switch port is providing power.
	Alternating green and amber	PoE is denied because providing power to the powered device will exceed the 370 W switch power capacity.
	Blinking amber	PoE is off due to a fault.  Caution PoE faults are caused when noncompliant cabling or powered devices are connected to a PoE port. Only standard-compliant cabling can be used to connect Cisco pre-standard IP Phones and wireless access points or IEEE 802.3af-compliant devices to PoE ports. A cable or device that causes a PoE fault must be removed from the network.
	Amber	PoE for the port has been disabled. Note PoE is enabled by default.
STAT (port status)	Off	No link, or port was administratively shut down.
	Green	Link present.
	Flashing green	Activity. Port is sending or receiving data.
	Alternating green-amber	Link fault. Error frames can affect connectivity, and errors such as excessive collisions, CRC errors, and alignment and jabber errors are monitored for a link-fault indication.
	Amber	Port is blocked by Spanning Tree Protocol (STP) and is not forwarding data. Note After a port is reconfigured, the port LED can remain amber for up to 30 seconds as STP checks the switch for possible loops.
	Flashing amber	Port is blocked by STP and is transmitting or receiving packets.
DUPLX (duplex)	Off	Port is operating in half duplex.
	Green	Port is operating in full duplex.

Table 1-7 *Meaning of LED Colors in Different Modes on the Switch (continued)*


Port Mode	Port LED Color	Meaning
SPEED	10/100 and 10/100/1000 ports	
	Off	Port is operating at 10 Mbps.
	Green	Port is operating at 100 Mbps.
	Flashing green	Port is operating at 1000 Mbps.
	SFP ports	
	Off	Port is operating at 10 Mbps.
	Green	Port is operating at 100 Mbps.
	Flashing green	Port is operating at 1000 Mbps.
		Note When installed in Catalyst 3750 switches, 1000BASE-T SFP modules can operate at 10, 100, or 1000 Mbps in full-duplex mode or at 10 or 100 Mbps in half-duplex mode.
	XENPAK port	
STACK (stack member)	Off	Port is not operating.
	Flashing green	Port is operating at up to 10 Gbps.
	Off	No stack member corresponding to that member number.
	Flashing green	Stack member number.
	Green	Member numbers of other stack member switches.

1. The PoE LED is only on the Catalyst 3750-24PS and 3750-48PS switches.

Stack LED

The stack LED shows the sequence of member switches in a stack. Up to nine switches can be members of a stack. The first nine port LEDs show the member number of a switch in a stack. [Figure 1-16](#) shows the LEDs on the first switch, which is stack member number 1. For example, if you press the Mode button and select Stack, the LED for port 1 flashes green. The LEDs for port 2 and 3 are solid green, as these represent the member numbers of other switches in the stack. The other port LEDs are off because there are no more members in the stack.

Figure 1-16 Stack LED



1	Stack member 1	3	Stack member 3
2	Stack member 2		

When you select the Stack LED, the representative Stack LEDs are green when the StackWise ports (on the switch rear panel) are up, and the representative Stack LEDs are amber when the ports are down:

- SFP port LEDs 1 and 2 on the Catalyst 3750-24TS switch show the status for StackWise ports 1 and 2, respectively.
- SFP port LEDs 3 and 4 on the Catalyst 3750-48TS switch show the status for StackWise ports 1 and 2, respectively.
- SFP port LEDs 51 and 52 on the Catalyst 3750G-48TS and 3750G-48PS switches show the status for StackWise ports 1 and 2, respectively.
- SFP port LEDs 27 and 28 on the Catalyst 3750G-24TS, 3750G-24TS-1U, and 3750G-24PS switches show the status for StackWise ports 1 and 2, respectively.
- The 10/100/1000 port LEDs 23 and 24 on the Catalyst 3750G-24T switch show the status for StackWise ports 1 and 2, respectively.
- SFP port LEDs 11 and 12 on the Catalyst 3750G-12S switch show the status for StackWise ports 1 and 2, respectively.



Note

If the port LEDs are green on all the switches in the stack, the stack is operating at full bandwidth (32 Gbps). If any of the port LEDs are not green, the stack is not operating at full bandwidth.


Rear Panel Description

These sections describe the rear panels for the Catalyst 3750 Fast Ethernet switches:

- [StackWise Ports](#), page 1-22
- [Power Connectors](#), page 1-22
- [Console Port](#), page 1-23


The switch rear panels have an AC power connector, an RPS connector, an RJ-45 console port, and two StackWise ports. (See [Figure 1-17](#) through [Figure 1-21](#).)

Figure 1-17 Catalyst 3750-24TS, 3750G-24T, 3750G-12S, 3750G-16TD, and 3750-48TS Rear Panel




1	StackWise ports	4	AC power connector
2	RJ-45 console port	5	RPS connector
3	Fan exhaust		


Figure 1-18 Catalyst 3750G-24TS Rear Panel




1	StackWise ports	4	AC power connector
2	RJ-45 console port	5	RPS connector
3	Fan exhaust		

Figure 1-19 Catalyst 3750-24FS Rear Panel

1	StackWise ports	4	RPS connector
2	RJ-45 console port	5	AC power connector
3	Fan exhaust		

Figure 1-20 Catalyst 3750-24PS and 3750-48PS Rear Panel

1	StackWise ports	4	AC power connector
2	RJ-45 console port	5	RPS connector
3	Fan exhaust		

Figure 1-21 Catalyst 3750G-24PS, 3750G-24TS-1U, 3750G-48PS, and 3750G-48TS Rear Panel

1	StackWise ports	4	RPS connector
2	RJ-45 console port	5	AC power connector
3	Fan exhaust		

StackWise Ports

The Catalyst 3750 switch ships with a 0.5-meter StackWise cable (72-2632-XX CABASY) that you can use to connect the StackWise ports.



Caution

Use only approved cables (CAB-STACK-50CM, CAB-STACK-1M, or CAB-STACK-3M), and connect only to similar Cisco equipment. Equipment might be damaged if connected to other nonapproved Cisco cables or equipment.

You can order these StackWise cables from your Cisco sales representative:

- CAB-STACK-50CM= (0.5-meter cable)
- CAB-STACK-1M= (1-meter cable)
- CAB-STACK-3M= (3-meter cable)

Power Connectors

The switch is powered through the internal power supply. You can also connect the Cisco RPS 675 to provide backup power if the switch internal power supply should fail.



Note

The Catalyst 3750 switch and the Cisco RPS 675 should be connected to the same AC power source.

Internal Power Supply Connector

The internal power supply is an autoranging unit that supports input voltages between 100 and 240 VAC. Use the supplied AC power cord to connect the AC power connector to an AC power outlet.

Cisco RPS Connector

The Cisco RPS 675 (model PWR675-AC-RPS-N1=) supports the Catalyst 3750 family of switches.

Cisco RPS 675

The Cisco RPS 675 has two output levels: –48 V and 12 V with a total maximum output power of 675 W. Use the supplied RPS connector cable to connect the RPS to the switch.



Warning

Attach only the Cisco RPS (model PWR675-AC-RPS-N1=) to the RPS receptacle.

The RPS is a redundant power system that can support six external network devices and provides power to one failed device at a time. It automatically senses when the internal power supply of a connected device fails and provides power to the failed device, preventing loss of network traffic. For more information on the Cisco RPS 675, see the *Cisco RPS 675 Redundant Power System Hardware Installation Guide*.

Console Port

You can connect the switch to a PC by means of the console port and the supplied RJ-45-to-DB-9 female cable. If you want to connect the switch console port to a terminal, you need to provide an RJ-45-to-DB-25 female DTE adapter. You can order a kit (part number ACS-DSBUASYN=) containing that adapter from Cisco. For console port and adapter pinout information, see the “[Connector and Cable Specifications](#)” section on page B-1.

Management Options

The Catalyst 3750 switches offer several management options:

- Network Assistant

Cisco Network Assistant is a PC-based network management GUI application optimized for LANs of small and medium-sized businesses. Cisco Network Assistant offers centralized management of Cisco switches ranging from Cisco Catalyst 2950 through Cisco Catalyst 4506. Through a user-friendly GUI, users can configure and manage switch clusters or standalone switches. Cisco Network Assistant is available at no cost and can be downloaded from this URL:

<http://www.cisco.com/go/networkassistant>

For information on starting the Network Assistant application, see the *Getting Started with Cisco Network Assistant* guide on Cisco.com.

- Device manager

You can use the device manager, which is in the switch memory, to manage individual and standalone switches. This is an easy-to-use web interface that offers quick configuration and monitoring. You can access the device manager from anywhere in your network through a web browser. For more information, see the device manager online help.

- Cisco IOS command-line interface (CLI)

The switch CLI is based on Cisco IOS software and is enhanced to support desktop-switching features. You can fully configure and monitor the switch and switch cluster members from the CLI. You can access the CLI either by connecting your management station directly to the switch console port or by using Telnet from a remote management station. See the *Catalyst 3750 Switch Command Reference* on Cisco.com for more information.

- CiscoView application

The CiscoView device-management application displays the switch image that you can use to set configuration parameters and to view switch status and performance information. The CiscoView application, which you purchase separately, can be a standalone application or part of a Simple Network Management Protocol (SNMP) platform. See the CiscoView documentation for more information.

- SNMP network management

You can manage switches from a SNMP-compatible management station that is running platforms such as HP OpenView or SunNet Manager. The switch supports a comprehensive set of Management Information Base (MIB) extensions and four Remote Monitoring (RMON) groups. See the switch software configuration guide on Cisco.com and the documentation that came with your SNMP application for more information.

Network Configurations

See the switch software configuration guide on Cisco.com for network configuration concepts and examples of using the switch to create dedicated network segments and interconnecting the segments through Gigabit Ethernet connections.