

Sample Program Guide

Revision. 1.0
October 25, 2007

Introduction

This guide explains how to use this sample program.

Usage

Supported camera

D3, D300

Environment

The sample program is command prompt, runs on Windows2000 and later, MacOSX 10.3.9 and later.

Supported Environment

OS type	Version
Windows	Windows2000
	Windows XP
	Windows Vista
Macintosh	MacOSX 10.3.9(PowerPC)
	MacOS 10.4.x(PowerPC/IntelMac)

■Restriction of Windows

The windows sample program project file supports “Microsoft Visual C++ 6.0”, “Microsoft Visual Studio .Net 2003”.

■Restriction of Macintosh

- The macintosh sample program project file needs MacOSX 10.4 and later, to open project. Because this project file is created with Xcode 2.4, and Xcode 2.4 will require on MacOSX 10.4 and later.
- GCC Version is 4.0.
- The macintosh sample program is universal application.

Files

The sample program needs following files. Copy these files on the appropriate folder and use it.

Windows 2000 (camera body is set to PTP mode.)

File Name	Folder
Type0001.md3	Same as this sample program
NkdPTPDi.dll	Same as Type0001.md3
NkCamUSD.dll	WINDOWS\SYSTEM32

- If you want to change the folder of Type0001.md3, you should modify Search_Module() function of Function.c.
- The meaning of WINDOWS is the directory where OS is installed. (Windows, Winnt etc.)
- You have to install NkCamUSD.dll by NkCtrlPTP.inf.

Windows XP, Vista (camera body is set to PTP mode.)

File Name	Folder
Type0001.md3	Same as this sample program
NkdPTP.dll	Same as Type0001.md3

- If you want to change the folder of Type0001.md3, you should modify Search_Module() function of Function.c.

MacOS X (camera body is set to PTP mode)

File Name	Folder
Type0001 Module.dundle (Universal Binary)	Same as this sample program
libNkPTPDriver.dylib (Universal Binary)	SYSTEM/Library/Application Support/Nikon/Camera Control Modules/

- If you want to change the folder of Type0001 Module.dundle, you should modify Search_Module() function of Function.c.
- The meaning of SYSTEM is the directory where OS is installed.

Main Menu

When you start the sample program, it loads module and opens module object. Then main menu is shown.

1) Select Device

If some devices are connected to PC, you can choose which device will be used. Then sub menu 1 is shown.

2) AsyncRate

Show a recommended interval of Command_Async.(refer to 9.1 kNkMAIDCapability_AsyncRate in MAID3.PDF)

3) IsAlive

Show the status of Module object.(refer to 9.6 kNkMAIDCapability_IsAlive in MAID3.PDF)

4) Name

Show the name of Module object.(refer to 9.9 kNkMAIDCapability_Name in MAID3.PDF)

5) ModuleType

Show the type of Module object.(refer to 9.53 kNkMAIDCapability_ModuleType in MAID3.PDF)

6) Version

Show version of MAID supported by the module.

(refer to 9.57 kNkMAIDCapability_Version in MAID3.PDF)

Sub Menu 1

You can read or write the settings of the source object.

1) Select Item Object

If some pictures are stored in camera, you can choose which item object will be used. Then sub menu 2 is shown. (When this menu returns the message “There is no item” though Capture command is succeeded, please retry this menu until new item object is detected.)

2) Camera settings(1)

You can change some camera settings. Sub menu 3 will be shown.

3) Camera settings(2)

You can change other camera settings. Sub menu 4 will be shown.

4) Shooting Menu

You can change photography settings. Sub menu 5 will be shown.

5) Custom Menu

You can change custom settings. Sub menu 6 will be shown.

6) Async

Send kNkMAIDCommand_Async to detect in camera condition.

(refer to 8.1 kNkMAIDCommand_Async in MAID3.PDF)

7) Autofocus

Perform auto focus. (refer to 3.27 kNkMAIDCapability_AutoFocus in MAID3Type0001.PDF)

8) Capture

Take a picture. (refer to 3.17 kNkMAIDCapability_Capture in MAID3Type0001.PDF)

9) PreCapture

Take a picture for presetting white balance.

(refer to 2.177 kNkMAIDCapability_PreCapture in MAID3Type0001.PDF)

10) CameraType

Show the camera type connected the present.

(refer to 2.189 kNkMAIDCapability_CameraType in MAID3Type0001.PDF)

Sub Menu 2

You can read or write the settings of the item object.

1) Select Data Object

You can choose preview or data object. If preview is selected, preview data will be get. Display information will be saved as like "Preview001_H.dat" and preview image will be saved as like "Preview001.jpg" in application folder in windows, or in home directory in macintosh.(refer to 2.185 kNkMAIDCapability_GetPreviewImageLow, 2.186 kNkMAIDCapability_GetPreviewImageNormal in MAID3Type0001.PDF)

If image object is selected, sub menu 7 will be shown. If thumbnail object is selected, sub menu 8 will be shown.

2) Delete

Delete the DRAM image of Item object.

(refer to 2.182 kNkMAIDCapability_DeleteDramImage in MAID3Type0001.PDF)

3) IsAlive

Show the status of this Item object.(refer to 9.6 kNkMAIDCapability_IsAlive in MAID3.PDF)

4) Name

Show the name of this Item object.(refer to 9.9 kNkMAIDCapability_Name in MAID3.PDF)

5) DataTypes

Show the data types supported by this Item object.

(refer to 9.12 kNkMAIDCapability_DataTypes in MAID3.PDF)

6) DateTime

Show the date and time when this Item was created.

(refer to 9.13 kNkMAIDCapability_DateTime in MAID3.PDF)

7) StoredBytes

Show the file size of this Item in bytes.

(refer to 9.14 kNkMAIDCapability_StoredBytes in MAID3.PDF)

Sub Menu 3

You can read and write the detailed settings (1) of the source object.

1) IsAlive

Show the status of this Source object.(refer to 9.6 kNkMAIDCapability_IsAlive in MAID3.PDF)

2) Name

Show the name of this Source object.(refer to 9.9 kNkMAIDCapability_Name in MAID3.PDF)

3) Interface

Show the physical interface of this Source object.

(refer to 9.11 kNkMAIDCapability_Interface in MAID3.PDF)

4) DataTypes

Show the data types supported by this Item object.

(refer to 9.12 kNkMAIDCapability_DataTypes in MAID3.PDF)

5) BatteryLevel

Show battery level. (refer to 3.47 kNkMAIDCapability_BatteryLevel in MAID3Type0001.PDF)

6) FlashMode

Set the flash mode of this source. (refer to 9.52 kNkMAIDCapability_FlashMode in MAID3.PDF)

7) LockFocus

Set the status of focus lock.

(refer to 2.157 kNkMAIDCapability_LockFocus in MAID3Type0001.PDF)

8) LockExposure

Set the status of exposure lock.

(refer to 2.156 kNkMAIDCapability_LockExposure in MAID3Type0001.PDF)

9) ExposureStatus

Show the exposure value measured by camera.

(refer to 2.161 kNkMAIDCapability_ExposureStatus in MAID3Type0001.PDF)

10) ExposureMode

Set the exposure mode of camera.

(refer to 2.142 kNkMAIDCapability_ExposureMode in MAID3Type0001.PDF)

11) ShutterSpeed

Set the exposure time of camera.

(refer to 2.137 kNkMAIDCapability_ShutterSpeed in MAID3Type0001.PDF)

12) Aperture

Set the aperture of camera. (refer to 2.140 kNkMAIDCapability_Aperture in MAID3Type0001.PDF)

13) FlexibleProgram

Set the flexible program of camera.

(refer to 2.138 kNkMAIDCapability_FlexibleProgram in MAID3Type0001.PDF)

14) ExposureComp

Set the exposure compensation of camera.

(refer to 2.143 kNkMAIDCapability_ExposureComp in MAID3Type0001.PDF)

15) MeteringMode

Set the metering mode of camera.

(refer to 2.141 kNkMAIDCapability_MeteringMode in MAID3Type0001.PDF)

16) FocusMode

Show focus mode(MF/AF-S/AF-C).

(refer to 2.164 kNkMAIDCapability_FocusMode in MAID3Type0001.PDF)

17) FocusAreaMode

Set focus area mode(Dynamic/Single/Auto).

(refer to 2.146 kNkMAIDCapability_FocusAreaMode in MAID3Type0001.PDF)

18) FocusPreferredArea

Change focusing point.

(refer to 2.139 kNkMAIDCapability_FocusPreferredArea in MAID3Type0001.PDF)

19) FocalLength

Show focal length(unit: mm).

(refer to 2.163 kNkMAIDCapability_FocalLength in MAID3Type0001.PDF)

20) ClockDateTime

Adjust internal clock.

(refer to 2.133 kNkMAIDCapability_ClockDateTime in MAID3Type0001.PDF)

21) CustomSettings

Select a custom setting from A, B, C, D.

(refer to 2.48 kNkMAIDCapability_CustomSettings in MAID3Type0001.PDF)

Sub Menu 4

You can read and write the detailed settings (2) of the source object.

1) LockCamera

Keep the camera from direct operation(not through host computer).

(refer to 2.188 kNkMAIDCapability_LockCamera in MAID3Type0001.PDF)

2) LensInfo

Show lens information(focal length and aperture).

(refer to 2.174 kNkMAIDCapability_LensInfo in MAID3Type0001.PDF)

3) UserComment

Set characters which will be written in a new picture file.

(refer to 2.130 kNkMAIDCapability_UserComment in MAID3Type0001.PDF)

4) EnableComment

Enable to add UserComment to an image file.

(refer to 2.131 kNkMAIDCapability_EnableComment in MAID3Type0001.PDF)

5) IsoControl

Set whether auto sensitivity control is used when you take a picture.

(refer to 2.33 kNkMAIDCapability_IsoControl in MAIDType0001.PDF)

6) NoiseReduction

Set whether noise reduction is used when you take a picture.

(refer to 2.34 kNkMAIDCapability_NoiseReduction in MAIDType0001.PDF)

Sub Menu 5

You can read and write settings concerned with photography.

1) MenuBank

Change a bank of Shooting Menu.

(refer to 2.5 kNkMAIDCapability_MenuBank in MAID3Type0001.PDF)

2) CompressionLevel

Set compression level of the image file created by camera.

(refer to 2.2 kNkMAIDCapability_CompressionLevel in MAID3Type0001.PDF)

3) ImageSize

Set the compression level of picture.

(refer to 2.1 kNkMAIDCapability_ImageSize in MAID3Type0001.PDF)

4) WBMode

Set white balance mode(auto/Incandescent/...).

(refer to 2.3 kNkMAIDCapability_WBMode in MAIDType0001.PDF)

5) Sensitivity

Set sensitivity of camera.

(refer to 2.4 kNkMAIDCapability_Sensitivity in MAIDType0001.PDF)

6) WB TuneAuto

Adjust white balance in Auto mode.

(refer to 2.9 kNkMAIDCapability_WBTuneAuto in MAIDType0001.PDF)

7) WB TuneIncandescent

Adjust white balance in Incandescent mode.

(refer to 2.10 kNkMAIDCapability_WBTuneIncandescent in MAIDType0001.PDF)

8) WBFluorescentType

Set the fluorescent type when the WBMode is “Fluorescent”.

(refer to 2.11 kNkMAIDCapability_WBFluorescentType in MAIDType0001.PDF)

9) WB TuneFluorescent

Adjust white balance in Fluorescent mode.

(refer to 2.12 kNkMAIDCapability_WBTuneFluorescent in MAIDType0001.PDF)

10) WB TuneSunny

Adjust white balance in Sunny mode.

(refer to 2.13 kNkMAIDCapability_WBTuneSunny in MAIDType0001.PDF)

11) WB TuneFlash

Adjust white balance in Flash mode.

(refer to 2.14 kNkMAIDCapability_WBTuneFlash in MAIDType0001.PDF)

12) WB TuneShade

Adjust white balance in Shade mode.

(refer to 2.15 kNkMAIDCapability_WBTuneShade in MAIDType0001.PDF)

13) WB TuneCloudy

Adjust white balance in Cloudy mode.

(refer to 2.16 kNkMAIDCapability_WBTuneCloudy in MAIDType0001.PDF)

14) WB TuneColorTemp

set the color temperature in Color Temperature mode.

(refer to 2.17 kNkMAIDCapability_WBTuneColorTemp in MAIDType0001.PDF)

15) WB TuneColorAdjust

Adjust white balance in Color Temperature mode.

(refer to 2.18 kNkMAIDCapability_WBTuneColorAdjust in MAIDType0001.PDF)

16) WB TunePreset

Adjust white balance in Preset mode.

(refer to 2.19-23 kNkMAIDCapability_WBTunePreset1-5in MAIDType0001.PDF)

17) WB PresetData

Set white balance preset data to camera.

When you set preset data to camera, you have to name the file “PresetData.jpg” and put the file in

this application folder in windows, or put the file in home directory in macintosh.

(refer to 2.26 kNkMAIDCapability_WBPresetData in MAIDType0001.PDF)

18) PictureControl

Set and get current Picture Control.

(refer to 2.38 kNkMAIDCapability_PictureControl in MAIDType0001.PDF)

19) PictureControlData

Set and get Picture Control data.

When you set Picture Control data to camera, you have to name the file "PicCtrlData.dat" and put the file in this application folder in windows, or put the file in home directory in macintosh.

(refer to 2.40 kNkMAIDCapability_PictureControlData in MAIDType0001.PDF)

20) GetPicCtrlInfo

Get Picture Control information. The Picture Control information is saved as like "PicCtrlInfo.dat" in application folder in windows, or saved in home directory in macintosh.

(refer to 2.41 kNkMAIDCapability_GetPicCtrlInfo in MAIDType0001.PDF)

21) DeleteCustomPictureControl

Delete Custom Picture Control.

(refer to 2.42 kNkMAIDCapability_DeleteCustomPictureControl in MAIDType0001.PDF)

22) LiveViewProhibit

Get the Live view prohibition condition.

(refer to 2.152 kNkMAIDCapability_LiveViewProhibit in MAIDType0001.PDF)

23) LiveViewMode

Set the mode of Live view.

(refer to 2.46 kNkMAIDCapability_LiveViewMode in MAIDType0001.PDF)

24) LiveViewStatus

Start or stop Live view, and get current status of Live view.

(refer to 2.151 kNkMAIDCapability_LiveViewStatus in MAIDType0001.PDF)

25) LiveViewImageZoomRate

Set the zoom rate of Live view image.

(refer to 2.153 kNkMAIDCapability_LiveViewImageZoomRate in MAIDType0001.PDF)

26) GetLiveViewImage

Live view data will be get. Display information will be saved as like "LiveView001_H.dat" and Live view image will be saved as like "LiveView001.jpg" in application folder in windows, or in home directory in macintosh.

(refer to 2.187 kNkMAIDCapability_GetLiveViewImage in MAIDType0001.PDF)

Sub Menu 6

You can read and write a custom setting of source object.

1) ResetCustomSetting

Reset the custom settings which is selected by kNkMAIDCapability_CustomSettings.

(refer to 2.50 kNkMAIDCapability_ResetCustomSetting in MAIDType0001.PDF)

2) ResetFileNumber

Resets the number of the file which will be stored in CF card.

(refer to 2.83 NkMAIDCapability_ResetFileNumber in MAIDType0001.PDF)

3) ShootNoCard

Set enable to shoot when a CF card is not install.

(refer to 2.128 kMAIDCapability_ShootNoCard in MAIDType0001.PDF)

4) NumberingMode

Select a file numbering method.

(refer to 2.82 NkMAIDCapability_NumberingMode in MAIDType0001.PDF)

5) LimitImageDisplay

Select limit time of picture display.

(refer to 2.75 NkMAIDCapability_LimitImageDisplay in MAIDType0001.PDF)

6) AutoOffDelay

Select a time delay for auto meter switch-off.

(refer to 2.73 kNkMAIDCapability_AutoOffDelay in MAIDType0001.PDF)

7) SelfTimerDuration

Set a self timer duration.

(refer to 2.74 NkMAIDCapability_SelfTimerDuration in MAIDType0001.PDF)

8) EVInterval

Select an interval of exposure value.

(refer to 2.65 kMAIDCapability_EVInterval in MAIDType0001.PDF)

9) BracketingVary

Select a Bracketing variation.

(refer to 2.109 kMAIDCapability_BracketingVary in MAIDType0001.PDF)

10) BracketingOrder

Select an bracketing order.

(refer to 2.111 kMAIDCapability_BracketingOrder in MAIDType0001.PDF)

11) ExchangeDials

Exchange the functions for front and rear command dials.

(refer to 2.124 kNkMAIDCapability_ExchangeDials in MAIDType0001.PDF)

12) AEAFLockButton

Activate AF lock and AE lock when AE/AF lock button is pressed.

(refer to 2.121 kNkMAIDCapability_AEAFLockButton in MAIDType0001.PDF)

13) AELockonRelease

Activate AE lock or not when shutter button lightly pressed.

(refer to 2.72 kNkMAIDCapability_AELockonRelease in MAIDType0001.PDF)

14) LCDBackLight

Turn on LCD backlight when the release button is slightly pressed.

(refer to 2.87 kNkMAIDCapability_LCDBackLight in MAIDType0001.PDF)

15) AFAreaSelector

Set AF area selector motion is circular or not.

(refer to 2.59 kNkMAIDCapability_AFAreaSelector in MAIDType0001.PDF)

16) AFsPriority

Select a prior focusing area in single AF mode.

(refer to 2.52 kNkMAIDCapability_AFsPriority in MAIDType0001.PDF)

17) AFcPriority

Select a prior focusing area in continuous AF mode.

(refer to 2.51 kNkMAIDCapability_AFcPriority in MAIDType0001.PDF)

Sub Menu 7

You can read and write a setting of image object.

1) IsAlive

Show the status of this image object.(refer to 9.6 kNkMAIDCapability_IsAlive in MAID3.PDF)

2) Name

Show the name of this image object. (refer to 9.9 kNkMAIDCapability_Name in MAID3.PDF)

3) StoredBytes

Show the file size of this image file in bytes.

(refer to 9.14 kNkMAIDCapability_StoredBytes in MAID3.PDF)

4) Pixels

Show the image size of this image in pixels.

(refer to 9.40 kNkMAIDCapability_Pixels in MAID3.PDF)

5) RawJpegImageStatus

Show whether this image has raw and jpeg or not.

(refer to 2.183 kNkMAIDCapability_RawJpegImageStatus in MAIDType0001.PDF)

6) Acquire

Get an image file. The image is saved as like "Image001.jpg" in application folder in windows, or saved in home directory in macintosh. (refer to 9.19 kNkMAIDCapability_Acquire in MAID3.PDF)

Sub Menu 8

You can read and write a setting of thumbnail object.

1) IsAlive

Show the status of this thumbnail object.(refer to 9.6 kNkMAIDCapability_IsAlive in MAID3.PDF)

2) Name

Show the name of this thumbnail object. (refer to 9.9 kNkMAIDCapability_Name in MAID3.PDF)

3) StoredBytes

Show the size of this thumbnail data in bytes.

(refer to 9.14 kNkMAIDCapability_StoredBytes in MAID3.PDF)

4) Pixels

Show the image size of this thumbnail image in pixels.

(refer to 9.40 kNkMAIDCapability_Pixels in MAID3.PDF)

5) Acquire

Get an thumbnail image data. The thumbnail is saved as like "Thumb001.raw" in application folder in windows, or saved in home directory in macintosh.

(refer to 9.19 kNkMAIDCapability_Acquire in MAID3.PDF)

Appendix

Restriction

- This sample program doesn't provide all of the capability Type0001 module support. About usage of the other capability, please refer the document "MAID3Type0001(E).rtf".
- This sample program doesn't care of changes in camera condition. If you want to check the camera status, you should send kNkMAIDCommand_Async to module object periodically. If this command is carried out, change of the state of a camera will be notified by MAIDEventProc.
- This sample program supports the case 2, "After issuing kNkMAIDCapability_Acquire for ImageObject, and before issuing kNkMAIDCommand_Close" as the way to delete DRAM image. This sample program does not use the case 1, "Before receiving kNkMAIDEvent_AddChild"
- When you use Type0001 Module (Type0001.md3), please set USB transmission mode of the camera body as PTP.

History

Rev.1.0 October 25, 2007 First version