




Phins Compact C7

Operation Guide

Revision History

Edition	Date	Comments
A	07/2019	Creation
B	03/2020	Alignment phases updated
C	10/2022	Select the Web-Based Graphical User Interface display, Start-up phases and Viewing the status messages chapters updated. Selecting the Attitude conventions chapter removed.

Copyright

All rights reserved. No part of this manual may be reproduced or transmitted, in any form or by any means, whether electronic, printed manual or otherwise, including but not limited to photocopying, recording or information storage and retrieval systems, for any purpose without prior written permission of iXblue.

Disclaimer

iXblue specifically disclaims all warranties, either expressed or implied, including but not limited to implied warranties about merchantability and fitness for a particular purpose with respect to this product and documentation. iXblue reserves the right to revise or to make changes or improvements to this product or documentation at any time without notifying any person of such revision or improvements.

In no event shall iXblue be liable for any consequential or incidental damages, including but not limited to loss of business profits or any commercial damages, arising out of the use of this product.

Trademarks

Microsoft, MS-DOS and Windows are registered trademarks of Microsoft Corporation.

Intel and Pentium are registered trademarks and Celeron is a trademark of Intel Corporation.

Export Control

This product is subject to export control regulations. Please refer to the commercial offer or contact iXblue for details about the applicable export control regulations and restrictions.

Phins Compact C7 Documentation

The following documents give all the information you need in order to understand and to use your product.

- **Phins Compact C7 Technical Description** (*ref.: MU-PHINC7TD-AN-001*)
 - > Phins Compact C7 and iXblue technology presentation
 - > Technical specifications
 - > Certification and qualification, life cycle
 - > Mechanical, electrical and communication interface description
- **Phins Compact C7 Installation & Setup Guide** (*ref.: MU-PHINC7ISG-AN-001*)
 - > Conventions
 - > Physical and electrical installation
 - > Connecting to the Web-Based Graphical User Interface
 - > Setup the Phins Compact C7
 - > Contacting iXblue support
- **Phins Compact C7 Operation Guide** (*ref.: MU-PHINC7OG-AN-001*)
 - > Introduction to the Inertial Navigation System
 - > Start-up Phases
 - > Web-Based Graphical User Interface description
 - > Configuring the navigation parameters & managing the external information
 - > Viewing the system information
 - > Recording data
- **Phins Compact C7 Interface Library** (*ref.: MU-PHINC7IL-AN-001*)
 - > NMEA frames
 - > Digital input and output protocols
 - > Pulses interfaces specification
 - > Control commands
- **Subsea Inertial Products - Maintenance Manual** (*ref.: MU-SUBSEAMM-AN-001*)
 - > Troubleshooting
 - > Corrective maintenance
- **Subsea Inertial Products - Illustrated Part Catalog** (*ref.: MU-SUBSEADP-AN-001*)
 - > Detailed part list
 - > Alphanumerical Index
- **Application Note - INS+DVL Calibration** (*ref.: MU-DVLINS-AN-001*)
 - > Configuring the calibration
 - > Calibrating the DVL+INS
- **Application Note - Installation and Configuration of AHRS and INS for Seabed Mapping Measurements** (*ref.: MU-HEAVAPN-AN-001*)
 - > Using heave compensation on seabed mapping
 - > Effect of vehicle transient movements

Phins Compact C7 Operation Guide Overview

This document must be read and understood prior to using the product.

The manufacturer shall in no case be held liable for any application or use that does not comply with the stipulations in this manual.

The Phins Compact C7 Operation Guide is divided into several parts:

- **Part 1: Introduction to the Inertial Navigation System**
This part gives information about the presentation of the inertial navigation system.
- **Part 2: Start-up Phases**
This part gives details on the start-up phases, alignment phases and recommended trajectories.
- **Part 3: Web-Based Graphical User Interface Description**
This part gives detail on the Web-Based Graphical User Interface.
- **Part 4: Configuring the Web-Based Graphical User Interface**
This part gives detail on how to configure the Web-Based Graphical User Interface.
- **Part 5: Configuring the Navigation Parameters**
This part gives details on how to configure starting mode, altitude mode and current model.
- **Part 6: Managing the External Information**
This part gives the configuration parameters to help you fixing the Phins Compact C7.
- **Part 7: Viewing the System Information**
This part gives detail on where to find the detailed status, the navigation data and the events.
- **Part 8: Recording Data**
- **Appendix A: External data rejection criteria**

Abbreviations and Acronyms

ACC	Accelerometer
CTD	Conductivity, Temperature, Depth sensor
DVL	Doppler Velocity Log
EGNOS	European Geo-stationary Navigation Overlay Service
GALILEO	European Satellite Navigation System
GGA	Essential fix data which provide 3D location and accuracy data
GLONASS	Global Navigation Satellite System (operated by the Russian Space Forces)
GNSS	Global Navigation Satellite System
GPS	Global Positioning System (operated by the United States Department of Defense)
GUI	Graphical User Interface
HRP	Heading, Roll, Pitch
INS	Inertial Navigation System
IP	Internet Protocol
PPS	Pulse Per Second
SD	Standard Deviation
UTC	International acronym for Coordinated Universal Time (CUT)
UTM	Universal Transverse Mercator
ZUPT	Zero velocity UPdaTe

Table of Contents

1	INTRODUCTION TO THE INERTIAL NAVIGATION SYSTEM	11
1.1	INERTIAL NAVIGATION SYSTEM PRINCIPLES	11
1.2	KALMAN FILTER	14
1.3	PROPAGATION OF ERRORS IN PURE INERTIAL MODE	15
1.3.1	Horizontal Plane	15
1.3.2	Vertical Axis	17
1.4	REJECTION FILTER	19
1.5	CURRENT MODEL	20
1.6	EXTERNAL SENSOR DATA AGE MANAGEMENT	21
2	START-UP PHASES	22
2.1	ALIGNMENT PROCESS	22
2.2	START-UP MODES	23
2.2.1	Start-up	23
2.2.2	Wait for Position (recommended)	24
2.2.3	Immediate run	24
2.2.4	Emulation Mode	24
2.3	COARSE ALIGNMENT	25
2.4	INITIALIZATION OF THE HEAVE FILTER	26
2.5	FINE ALIGNMENT	27
2.6	OPTIMAL ALIGNMENT	27
2.7	SYSTEM FULL PERFORMANCE	28
3	WEB-BASED GRAPHICAL USER INTERFACE DESCRIPTION	29
3.1	CONTROL PAGE	29
3.2	MENUS	31
3.3	DATA RESOLUTION	32
4	CONFIGURING THE WEB-BASED GRAPHICAL USER INTERFACE	33
4.1	SELECTING THE WEB-BASED GRAPHICAL USER INTERFACE LANGUAGE	33
4.2	SELECTING THE WEB-BASED GRAPHICAL USER INTERFACE DISPLAY	34
4.3	SELECTING THE SYSTEM COORDINATES	35
4.4	SELECTING THE SPEED AND ANGLE UNITS	36
4.5	SELECTING THE POSITION ERROR CONVENTION	37
5	CONFIGURING THE NAVIGATION PARAMETERS	38
5.1	CONFIGURING THE STARTING MODE	38
5.2	CONFIGURING THE ALTITUDE MODE	39
5.3	CONFIGURING THE CURRENT MODEL	40
5.4	ENABLING THE EXTENSION OF THE UTM ZONE	41
6	MANAGING THE EXTERNAL INFORMATION	42
6.1	ENABLING THE EXTERNAL SENSORS	42
6.2	INPUTTING MANUALLY INFORMATION TO PHINS COMPACT C7	44
6.2.1	Configuring manually the position	45
6.2.2	Configuring the ZUPT Mode	47
6.3	CONFIGURING THE ANNOTATION MARKERS	49
7	VIEWING THE SYSTEM INFORMATION	50
7.1	VIEWING THE STATUS MESSAGES	50
7.2	VIEWING THE NAVIGATION DATA	52
7.3	VIEWING THE EVENTS MESSAGES	55

8	RECORDING DATA	56
8.1	INTERNAL DATA LOGGING	56
8.2	EXTERNAL DATA LOGGING	57
A	APPENDIX: EXTERNAL DATA REJECTION CRITERIA	59

PAGE INTENTIONALLY LEFT BLANK

1 Introduction to the Inertial Navigation System

Phins Compact C7 is an Inertial Navigation System (INS) that provides heading, roll, pitch, speed, position and heave surge sway information to the user, with or without external sensor data.

1.1 Inertial Navigation System Principles

INS Data flow

Figure 1 details the data flow inside the Phins Compact C7, from sensor acquisition to user data outputs in Web-Based Graphical User Interface and protocols:

- The FOG, accelerometers and temperature sensors are sampled at 400 Hz.
- An inertial sensor assembly (ISA) block is generated to synchronize this data set.
- The thermal compensation is applied to this data flow to get sensor blocks that are no longer sensitive to thermal changes.
- This data set is compensated at 400 Hz from coning/sculling dynamic effects due to discrete integration of the sensors, and from accelerometer lever arms that generate centrifuge accelerations inside the IMU block. It is then downsampled to 200 Hz to get IMU delta rotation and delta speeds.
- The IMU data is then provided to the algorithm to compute user data at 200 Hz and this data set is used for Web-Based Graphical User Interface display at 1 Hz and for user output protocols, which rate is configurable from 0.1 Hz to 200 Hz.




Figure 1 - Inertial Navigation System Data Flow

INS Algorithm

Figure 2 details the algorithm architecture used in Phins Compact C7 to compute user data from IMU delta rotation and delta speed information:

- The delta rotation and delta speed coming from the IMU are used to integrate Phins Compact C7 motion, based on current attitude, speed and position, to compute next attitude, speed and position. This is performed with or without external sensor input.
- When external sensors are available, they are first pre-filtered in the rejection filter to make sure they are consistent with the Phins Compact C7 current position, speed and attitude.
- If they are consistent, they are used by a Kalman filter to estimate current position, speed and attitude error and correct the user data and the estimated INS internal sensor errors.




Figure 2 - Inertial Navigation System Algorithm



The Phins Compact C7 algorithm integrates its internal sensors at 200 Hz rate but the Kalman filter only runs at 1 Hz and thus only uses one observation per second for each external sensor. It is thus useless to input external sensors at higher rates: this will add CPU load on the system but will not improve the navigation results. In some cases, higher rate outputs of external sensors may be repeated data with different timestamps, which is not accurate at all and shall be avoided. Limiting input sensors to 1 Hz is thus highly recommended.

Moreover, external sensor data sent to the Phins Compact C7 shall be as raw as possible. If the external sensor offers filtering or extrapolation options (on GNSS receiver for exemple), they must be disabled, to avoid misleading the Phins Compact C7 Kalman filter that assumes raw data input.

Integration of Movement

The algorithm converts angular increments and speed increments computed by the IMU into user navigation data by integrating these values as described in Figure 3:

- The IMU delta-rotations are compensated from craft rate and earth rotation and used to update the current attitude.
- The IMU delta-speed are projected from Phins Compact C7 body frame to geographical frame using the current attitude, compensated from local computed gravity and Coriolis force to update current geographical speed.
- Position is updated using geographical speed.




Figure 3 - Integration of movement

1.2 Kalman Filter

The Kalman Filter is a Bayesian probabilistic filter that models integration of movement errors and predict future state error statistics from current state to compare it to external observation and determine integration error and update model parameters. The Kalman Filter typically estimates:

- Attitude errors
- Position error
- Speed error
- Internal sensor errors (FOG and accelerometer biases, scale factors, etc.)




Figure 4 - Kalman Filter Steps: predict, measure, correct

This works when external observations are available.



External observations must be accurate. If they are not, the Kalman Filter may be corrupted. This means that both the configuration of the external sensor (lever arms, timestamping) and its error estimation (standard deviation provided by the sensor or set by the user) must be correct.

1.3 Propagation of Errors in Pure Inertial Mode

1.3.1 HORIZONTAL PLANE

The accuracy of data computed by the pure inertial system is dependent:

- On the accuracy of accelerometers and gyroscopes sensors.
- On the capacity of the Kalman Filter to increase the sensor accuracies.
- On the initial attitude, velocity and position errors obtained after the coarse alignment.


All sensors have errors (no matter how small they are). Since the gyroscopes and accelerometers data are integrated over time and since the velocity, position and attitude computations form a closed loop, all these errors propagate with time and influence each other.

Error propagation can be divided into 3 different categories:


- Schuler oscillation (84,4 min period)
- 24h oscillation (24 h period)
- Drift (only on longitude data)

In pure inertial, without external sensor observations, the navigation equation integration will accumulate accelerometer and gyrometer errors in time and generate speed, attitude and position errors. In these conditions, latitude error oscillates with Shuler Period (84 minutes) and Earth period (24 h). The error amplitude depends on the Phins Compact C7 sensor class but is bounded. The longitude error also oscillates with the same periods, plus an additional linear drift due to composite polar gyrometer bias and scale factor error. The oscillation amplitude and the linear drift speed depend on Phins Compact C7 sensor class and this error is not bounded due to the linear part of the drift. The linear drift is due to longitude error generated by gyrometer bias along the polar axis.


The resulting 2D position error combines latitude and longitude errors. It is not bounded as the longitude error:



Heading and roll/pitch errors oscillate with both earth period and Shuler period. The roll and pitch error is mainly driven by acceleration errors and thus Shuler effect. The heading error is more affected by gyro errors that vary with Earth period.



North and East speed error also oscillate with Earth and Shuler periods, due to both acceleration errors and attitude errors, but they are bounded.



1.3.2 VERTICAL AXIS

The estimation of altitude cannot be done by free inertial means: the error would increase exponentially. The altitude of Phins Compact C7 is stabilized (either by external sensor data or artificially) to prevent this exponential growth of the altitude error. The estimation of the product altitude is configured with the altitude computation mode.

The following altitude modes are available:

- **Stabilization:** The stabilization mode is selected when the update of the mean altitude is not needed and the altitude drift to be avoided during long GNSS drop-outs. In this mode, the altitude drift will be maintained small around a mean value by filtering out the low-frequency components of the altitude variation computed by Phins Compact C7.

- **GPS:** in this GPS altitude mode, Phins Compact C7 will use GNSS altitude and vertical speed sensors.

In navigation mode, GNSS data is filtered by the algorithm. Phins Compact C7 will use the quality indicator in the GGA telegram to evaluate the reliability of the GNSS position. Refer to the GPS input protocol description in the Phins Compact C7 Interface Library document.

If the GST telegram is received, Phins Compact C7 will use this data instead of the quality indicator. This quality indicator information will be used to reject GNSS spikes, resulting in smooth position data. The smaller the standard deviation (SD) on altitude is, the better the spike rejection will be and the Phins Compact C7 computed altitude will follow more closely the GNSS altitude.

If the GNSS signal is lost and no 3D-speed sensor is received, the altitude drift will be maintained small around a mean value by switching to Stabilization mode (as described above). The mean value is the value of Phins Compact C7 when the last valid aiding measurement was received. Phins Compact C7 will exit stabilization mode as soon as altitude SD and vertical speed SD are within a given criterion and when GNSS is back ON and valid.

- **Hydrography:** This hydrography mode is used solely with RTK GNSS. In this case, the goal is to reject GNSS jumps that are associated with poor altitude fixes and will degrade product altitude computation (i.e.: multibeam imagery in Hydro applications). The altitude is the combination of GNSS altitude mode with an added feature of quality mode rejection. In this mode Phins Compact C7 will use GNSS altitude and vertical speed to compute altitude. It operates in the following manner:

If the GST telegram is received, altitude standard deviation is retrieved in the data string. If not, the quality factor in the GGA telegram is converted in altitude standard deviation (SD).

When Q=4 (RTK mode) then the GNSS altitude in GGA string is used by Phins Compact C7 to compute height. For the other cases, when this condition is not met (i.e., Q = 0, 1, 2, 3, 5, 6) the product will stabilize the altitude to the last valid value. Phins Compact C7 will exit stabilization mode as soon as altitude SD and vertical speed SD are within given criteria. This will happen in practice when GNSS is back to mode 4 (RTK). If GNSS is lost (i.e., under a bridge), the same altitude stabilization applies.

- **Depth** (recommended for subsea application with depth sensor): In this mode, depth output is computed using subsea positioning system (i.e., USBL, depth sensor) or/and vertical speed sensor if available.

As long as depth underwater sensor is available, Phins Compact C7 filters this information based on sensor standard deviation. In case of sensor drop-out, if no 3D speed sensor is received, the depth output value is stabilized around the last value received as in stabilization mode, until sensor data becomes available.

In all these modes, the default altitude convention used by Phins Compact C7 is the mean sea level altitude (MSL). Ellipsoid WGS84 height can also be selectable in the Output port configuration from the Web-Based Graphical User Interface (refer to the Phins Compact C7 Installation & Setup Guide).

1.4 Rejection Filter

To prevent from corrupting the Kalman filter with inconsistent data that do not follow the Kalman filter sensor models, a rejection filter is added in front of the Kalman filter.

This filter will check the consistency between Kalman filter prediction and external sensor information.

When the sensor data is consistent with the Kalman filter prediction (the distance between sensor observation and Kalman prediction is in the same order of magnitude as the respective standard deviations), the observation is validated and feeds the Kalman filter.

When the distance is larger, it is either attenuated before feeding the Kalman, or when it is too large, it is rejected and will not be passed to the Kalman filter. This allows maintaining a stable Kalman filter even when external sensors exhibit transient errors (multi-path GNSS, spurious speed error on speed sensor, etc.).

For each external sensor, the rejection filter can be set in three modes:

- Automatic: it behaves as described above, rejecting outliers and accepting consistent observations
- Always true: the rejection filter is by-passed and all external sensor observations will feed the Kalman filter
- Always false: the external sensor data will not be used at all

For more details on rejection criteria, please refer to Appendix A.

1.5 Current Model

The algorithm uses a dedicated model to manage the water current estimation in time and distance. This current estimation is used to link the measured water speed information from EMLog to INS speed.

The more confidence the algorithm will have on current stability, the tighter the coupling will be between INS estimated speed and water speed measurement.

Confidence in previously estimated current will change in time and in traveled distance: when no observation allowed to re-estimate the current for a long time or a long traveled distance, the algorithm will degrade its confidence in current estimation.

As soon as new observations allow to re-estimate it, it will be able to converge again on current confidence, for example when both GNSS and EMLog are received together.

Maintaining a good current estimation allows to significantly reduce the INS navigation error oscillating at Shuler period and Earth rotation period, and this can be done by optimized setup on current model maximum standard deviation and time/distance correlation time.

In a very stable zone where current is known as quite constant, the setup can be typically 0.3 m/s in 3 h and 10 km. This means that after 3 h or 10 km of navigation, current would only change by 0.3 m/s RMS.

In an unstable area, where current could change quickly of more than 1 knot, the setup can be typically 1 m/s in 1 h and 3 km.

This setup will be more robust and avoid misleading the algorithm on current stability but will be less efficient to filter out navigation oscillating errors.




Figure 5 - Current model

1.6 External Sensor Data Age Management

Phins Compact C7 is using external sensor data in the Kalman filter to compare it to the same data type calculated by the Phins Compact C7. To do this, we need to compare data that were concomitant, for example to compare GNSS or EM Log speed to Phins Compact C7 speed at the same time.

To achieve this, Phins Compact C7 maintains a 3 s history of speed data to be able to match external sensor data with Phins Compact C7 estimated data even if external sensor data is aged. Thus, maximum age of external speed sensor data is 3 s.


When external sensor data is timestamped, the Phins Compact C7 computes external sensor data age by comparing current time inside Phins Compact C7 with external data sensor timestamp. It then uses this age to retrieve the position or speed in the Phins Compact C7 logs and computes the position or speed error by comparing this internal estimation to external sensor data at that time.

When external sensor data is not timestamped, the Phins Compact C7 assumes a null age and thus uses current position or speed to compare external data to internal estimation and compute the error that will feed the Kalman filter.

2 Start-Up Phases

2.1 Alignment Process

The alignment process starts as it is described on the following figure with the different alignment types displayed on the Web-Based Graphical User Interface and the type of moves and output data during this time.



The different phases of the Phins Compact C7 alignment are:

- **Coarse alignment:** Coarse alignment starts when position is received. The data are computed by the Phins Compact C7 but not yet valid. This alignment will finish when heading standard deviation gets lower than 1° seclat .
- **Fine alignment:** Fine alignment is completed when heading standard deviation $< 0.03^\circ \text{ seclat}$.
- **Optimal alignment:** Phins Compact C7 is ready for navigation. The performance of the system has not been reached, but all the data are valid. Optimal alignment is completed when heading standard deviation $< 0.02^\circ \text{ seclat}$.
- **System ready:** when fine alignment is completed, the system is ready and gives all the data with full performance.

2.2 Start-Up Modes




Figure 6 - Start-up modes for Phins Compact C7

2.2.1 START-UP

Phins Compact C7 starts 20 s after power is applied (there is no ON/OFF switch), it then performs a self-test phase.

During this phase:

- The system is muted and cannot receive commands.
- The blue disc flashes, no data is displayed on the Web-Based Graphical User Interface in the CONTROL page.

At the end of this phase, the system starts transmitting data and can receive commands

2.2.2 WAIT FOR POSITION (RECOMMENDED)

In the case of “Wait for position” starting mode, the Phins Compact C7 waits for at least one valid position input data from any of these active position sensors to start the alignment sequence.

No data is displayed on the Web-Based Graphical User Interface.

‘Wait for position’ status is displayed.

The position standard deviation used after ‘Wait position’ mode is the standard deviation specified by the external position sensor or by the manual position fix used to exit this mode.

When the system is set to “wait for position” start-up mode, but no external positioning sensor (GNSS for instance) is configured, then the product will behave like if it were set to “immediate run” start-up mode, that is to say, start immediately, using the last position used in SETUP - POSITION FIX menu.

2.2.3 IMMEDIATE RUN

In the case of “Immediate run” starting mode, Phins Compact C7 uses the manual position and altitude stored in the system to start the initial alignment process immediately, without waiting for any sensor. In this mode, the initial position standard deviation is set to 50 m by default.

2.2.4 EMULATION MODE

Emulation mode is an algorithm starting mode where DSP input sensor data is simulated instead of being captured from the sensor board.

This mode is normally reserved to simulator systems with no real sensors inside to still be able to monitor alignment process and external sensor data fusion by emulating fixed sensors.

Simulated sensor values will correspond to a static system at current user latitude, with a fixed heading of 45° and a roll and pitch of 0°. Once you select this mode you need to restart the product. The position used to start the algorithm in this mode shall be the same as the initial position stored for ‘Immediate Run’ mode, with 50 m standard deviation. No data are displayed on the Web-Based Graphical User Interface.

‘Emulation mode’ is displayed orange in the system detailed status.



Difference between Simulation and Emulation mode

Unlike in simulation mode (activated in the SETUP menu of the Web-Based Graphical User Interface), the system goes through a complete starting sequence in emulation mode.

For more information on the simulation mode, refer to the Phins Compact C7 Installation & Setup Guide.

2.3 Coarse Alignment

Principle	During this phase, Phins Compact C7 is estimating for initial attitude(leveling) and heading (north seeking) using a dedicated algorithm.
Output Data	The data are computed by Phins Compact C7 but are not valid yet.
Start/Duration	"Alignment" status is displayed on the Web-Based Graphical User Interface. The Coarse alignment will finish when heading standard deviation gets lower than 1° seclat.
End of phase	At the end of the coarse alignment, Phins Compact C7 will automatically switch to the fine alignment.




Figure 7 - Coarse alignment status

2.4 Initialization of the Heave Filter

Principle

Heave measurement is used to compensate for vertical movement due to sea waves in application such as multi-beam or sonar imagery.

Heave is obtained from a double mathematical integration of the vertical geographical accelerometer data. To avoid this data to drift, it is filtered (i.e. high pass filter). The heave filter is designed to measure periodic vertical movement of a surface vessel related to the average sea level.

Heave measured at a specific monitoring point is the addition of the heave measured at the unit location and the heave induced by the rotations (roll & pitch) applied to the lever arms from the unit to the specific monitoring point. The same filtering method applies to the surge and sway, respectively, the two horizontal filtered displacements.

For more details refer to Application Note - Installation and Configuration of AHRS and INS for Seabed Mapping Measurements (Ref.: MU-HEAVAPN-AN-001).

Output Data

There is no output data during the coarse alignment. During the heave filter initialization phase, the heave, surge and sway outputs have not reached full accuracy.

Condition

Heave performance depends on the amplitude and frequency of the waves.

Important

To ensure heave performance at any location of the subsea vehicle, its center of gravity must be enabled and configured in the Web-Based Graphical User Interface, refer to Phins Compact C7 Installation & Setup Guide.

Start-Duration

Heave initialization occurs when the unit is started (or restarted). The heave initialization phase is performed in parallel of the coarse alignment phase.

End of Phase

The heave initialization ends after 6 minutes. Once the heave filter completes its initialization, it will accurately measure any variations of Phins Compact C7 positions in the three directions (heave, surge and sway).



The Heave Init. status is displayed **orange** in the Web-Based Graphical User Interface when it is in progress.

When it is displayed grey, this heave initialization is completed.

Delayed heave

Phins Compact C7 can output two distinct heave measurements :

- Real Time Heave which provides heave in real time mode
- Smart Heave™ provides a measurement of heave with a 100 s fix delay. This data will give the best accuracy in all sea conditions.

The type of the heave measurement and protocol are defined for each output port through the Web-Based Graphical User Interface. Refer to the Phins Compact C7 Installation & Setup Guide.

2.5 Fine Alignment

Principle	After coarse alignment phase, Phins Compact C7 is ready for navigation and switches to the “fine alignment” phase. This mode is an auto-calibration mode. In this mode, the Kalman Filter is activated and it will use both inertial sensors and external sensors to compute optimal estimates of errors (i.e.: ACC & FOG bias), attitude, heading, speed and position. INS Kalman filter will continuously estimate internal sensor biases in navigation mode as long as external sensor data is available.
Output Data	During the fine alignment, heading is reliable, position and attitude are computed.
Start-Duration	“Fine alignment” status means that the system is fully functional, but the performance is not completely reached. The “Navigation mode” flag is also displayed and it means that the system is operational, the data provided by the Phins Compact C7 can be used.
End of phase	Fine alignment will finish when heading standard deviation is lower than 0.03° seclat.

2.6 Optimal alignment

Principle	Optimal alignment indicates that the system is at its best attitude performances.
Output Data	Heading is reliable, position and attitude are computed. Full accuracy output are available for heave, surge and sway.
Start-Duration	Optimal alignment starts after the fine alignment.
	To view the several views following the type of status on the Web-Based Graphical User Interface, refer to the section "Alignment Process".
End of Phase	The optimal alignment is completed when standard heading is below to 0.02° seclat and with Navigation mode set.
	The Optimal alignment status is displayed orange in the Web-Based Graphical User Interface when it is in progress. When it is displayed grey, this alignment is completed.

2.7 System Full Performance

Principle	During navigation, Phins Compact C7 uses its own inertial sensors together with external sensors, when they are available, to provide optimal estimates of position, speed, attitude and heading. When no external sensor is available, Phins Compact C7 switches automatically to “pure inertial mode” and keeps providing position, speed, attitude and heading estimates
Output Data	Phins Compact C7 is ready for navigation with optimal performances.
Start Duration	The “System Full Performance” status is raised after optimal alignment completes.
End of Phase	The System Full Performance status disappears: • when Phins Compact C7 restarts • when the connection is lost



To view the several views following the type of status on the Web-Based Graphical User Interface, refer to the section "Alignment Process".

3 Web-Based Graphical User Interface Description

The Web-Based Graphical User Interface is a user-friendly interface and is composed of one main window which displays the menus to be selected and all the information of your product.

3.1 Control Page

The Control page is the first page displayed after launching the Web-Based Graphical User Interface. It is composed of several areas:

- The **menus area** which displays all the menus of the Web-Based Graphical User Interface. Refer to section 3.2 to get details on the menus.
- The **navigation data area** which displays the Phins Compact C7 navigation data, the geographic coordinates and the system status. System status is described in the section 1.
- The **logo**. It is always visible whichever the selected menu is. It gives visual information about the system status thanks to the associated color code and provides a quick access to the detailed status.
- The **compass area** which displays the heading in degrees from 0 to 360° by main steps of 20° and sub-steps of 10°. Fine outer graduations are displayed by steps of 2°. An internal fine heading rose displays heading steps between 0 and 10.



The Control page is available any time by clicking on the logo of the Web-Based Graphical User Interface.




Figure 8 - Main page of the Web-Based Graphical User Interface

When clicking on the logo, the real-time information is displayed in the Detailed status in real time:

- **Input/Output:** Input, Output, Pulses
- **System:** Navigation, System, Sensors
- **Ext. Sensors:** displays the status of the Phins Compact C7 external sensors

Refer to the Phins Compact C7 Interface Library for the explanation of the status.




Figure 9 - Control page of the Web-Based Graphical User Interface

3.2 Menus

Many menus are available in order to configure and monitor the product as shown on the figure below.




Figure 10 - Menus of the Web-Based Graphical User Interface

- **MAIN MENU BAR**
 - > **CONTROL** displays information on the product and navigation & status information. This page is the default page displayed when the Web-Based Graphical User Interface is launched.
 - > **INSTALLATION** displays a drop-down sub-menu to configure the installation parameters:
 - MECHANICAL PARAMETERS
 - INPUTS
 - OUTPUTS
 - NETWORK
 - > **SETUP** displays a drop-down sub-menu to set specific parameters during a mission:
 - POSITION FIX
 - NAVIGATION PARAMETERS
 - WARNING CONFIGURATION
 - DVL CALIBRATION
 - SETTING MANAGEMENT
 - SIMULATION MODE
 - PASSWORDS
 - ADVANCED POSITION FILTERING
 - LOGBOOK
 - > **DATA LOGGING** menu to launch the internal data logging.
- **DATA MENU BAR**
 - > **navigation data** to access to all the data values. Information is displayed in a pop-up window
 - > **events viewer** to get a list of all events (errors, status or events messages) that have occurred. Information is displayed in a pop-up window
 - > **maintenance** to access to maintenance information and/or restart the unit
 - > **options** to set specific options of this interface

3.3 Data resolution

The data on the Web-Based Graphical User Interface are displayed with the following resolution:

Data type	Resolution after the decimal point	Example
Latitude, Longitude °	8 digits	48.12839644°
Latitude, Longitude ° '	6 digits	48° 07.703786'
Latitude, Longitude ° ' "	4 digits	48° 07' 42.2272"
All other real data	3 digits	N/A

4 Configuring the Web-Based Graphical User Interface

At first delivery, the Web-Based Graphical User Interface parameters are set to their default values. The parameters can be modified to fit your needs.

- These options only affect the way data is displayed but do not affect the operation of the Phins Compact C7 itself. As an example, changing units for angles will not affect the units used in the output protocols of the Phins Compact C7.
- These settings are saved locally in cookies on the client PC. If the client PC is changed or client cookies are cleared, these settings will be reverted to their default values.

4.1 Selecting the Web-Based Graphical User Interface language

These settings only affect the text of the Web-Based Graphical User Interface. It will not translate the options, the selections or the protocols names.

1. Click on the **options** menu. The following options are displayed.

The screenshot shows the 'MMI Display Options' menu with the following sections and settings:

- General**
 - Language: English (dropdown)
 - Mode: Day (dropdown)
- Coordinates**
 - System: Latitude/Longitude (dropdown)
 - Notation: Degrees, Decimal Minutes (dropdown)
- Units**
 - Speed: Meter per second (m/s) (dropdown)
 - Angle: Degree (°) (dropdown)
- Norms**
 - Position Std. Dev.: RMS (dropdown)

2. In the **General** area, select the right language in the Language drop-down list: French or English.
3. Click on the **OK** button. The text of the web-based user interface is then displayed with the selected language.

4.2 Selecting the Web-Based Graphical User Interface Display

1. Click on the **options** menu. The following options are displayed.

The screenshot shows a web-based graphical user interface for the Phins Compact C7. The title of the menu is "MMI Display Options". It is organized into five sections, each with a downward-pointing triangle icon and a section title:

- General**: Contains two dropdown menus: "Language" set to "English" and "Mode" set to "Day".
- Coordinates**: Contains two dropdown menus: "System" set to "Latitude/Longitude" and "Notation" set to "Degrees, Decimal Minutes".
- Units**: Contains two dropdown menus: "Speed" set to "Meter per second (m/s)" and "Angle" set to "Degree (°)".
- Norms**: Contains one dropdown menu: "Position Std. Dev." set to "RMS".

2. In the **General** area, select **Day** (white background), **Dusk** (grey background) or **Night** (black background) in the **Mode** drop-down list.
3. Click on the **OK** button.

4.3 Selecting the System Coordinates

1. Click on the **options** menu. The following options are displayed.

The screenshot shows the 'MMI Display Options' menu with the following settings:

- General**
 - Language: English
 - Mode: Day
- Coordinates**
 - System: Latitude/Longitude
 - Notation: Degrees, Decimal Minutes
- Units**
 - Speed: Meter per second (m/s)
 - Angle: Degree (°)
- Norms**
 - Position Std. Dev.: RMS

2. In the **Coordinates** area, the following options are available:
 - **System:** The coordinate system used in the user interface for position
 - > Latitude / Longitude: The commonly used latitude and longitude notation.
 - > UTM: Commonly used for land applications.
 - > Polar Lat / Lon: Polar latitude and longitude notations, most used in applications near the geographic poles where other projections are not suitable.
 - **Notation** (only applicable for settings Latitude / Longitude and Polar Lat / Lon)
 - > Decimal degrees: The display format used will be 00.00000000°
 - > Degrees, decimal minutes: The display format used will be 00°00.000000'
 - > Degrees, minutes, seconds: The display format used will be 00°00'00.0000"
3. Click on the **OK** button.

4.4 Selecting the Speed and Angle Units

1. Click on the **options** menu. The following options are displayed.

The screenshot shows the 'MMI Display Options' menu with the following sections and settings:

- General**
 - Language: English
 - Mode: Day
- Coordinates**
 - System: Latitude/Longitude
 - Notation: Degrees, Decimal Minutes
- Units**
 - Speed: Meter per second (m/s)
 - Angle: Degree (°)
- Norms**
 - Position Std. Dev.: RMS

2. In the **Units** area, select the units in the **Speed** drop-down list:

- **Knot (kn):** Knot
- **Meter per second (m/s)**

3. Select the angle in the **Angle** drop-down list:

- **Degree (°):** for degree
- **Mil (mil):** angle unit used in land defense applications

4. Click on the **OK** button.

4.5 Selecting the Position Error Convention

1. Click on the **options** menu. The following options are displayed.

MMI Display Options

▼ **General**

Language

Mode

▼ **Coordinates**

System

Notation

▼ **Units**

Speed

Angle

▼ **Norms**

Position Std. Dev.

2. In the **Norms** area, select the position error convention for all standard deviations computed by the Phins Compact C7 in the **Position Standard Deviation** drop-down list:
 - RMS
 - CEP 50 (0.67 x RMS)
 - CEP 95 (2 x RMS)

3. Click on the **OK** button.

5 Configuring the Navigation Parameters

5.1 Configuring the Starting Mode

To get details on the starting modes, refer to the section 2.

-
1. Click on the **SETUP** menu then select the **NAVIGATION PARAMETERS** option. The Navigation Parameters page is displayed.
-

2. In the **Starting Mode** area, select the starting mode from the list:



▼ Starting Mode

Starting Mode Wait for position ▼

- **Wait for position** (default and recommended)
- **Immediate Run**
- **Emulation mode**

-
3. Click on the **OK** button to save the settings.
-

5.2 Configuring the Altitude Mode

To get details on the altitude modes, refer to the section 1.3.2.

-
1. Click on the **SETUP** menu then select the **NAVIGATION PARAMETERS** option. The Navigation Parameters page is displayed.
-

2. In the **Altitude Mode** area, select the altitude mode from the list:



- **Stabilization**
- **GNSS altitude**
- **Hydro altitude**
- **Depth sensor** (recommended for subsea with depth sensor)

-
3. Click on the **OK** button to save the settings.
-

5.3 Configuring the Current Model

To get details on the current model, refer to section 1.5.



This option is displayed only if DVL sensor is configured.

1. Click on the **SETUP** menu then select the **NAVIGATION PARAMETERS** option. The Navigation Parameters page is displayed.

2. In the **Parameters of the current** area, enter the parameters:

▼ Parameters of the Current

Time

s

Amplitude

m/s

- Time: time constant of the current model
- Amplitude: maximum standard deviation of the current used in the filter

These settings are used when EM Log speed is input into the system.

3. Click on the **OK** button to save the settings.

5.4 Enabling the Extension of the UTM Zone

A check box allows the user to extend the current UTM zone to keep linear UTM coordinates and to avoid automatic zone computation as done by Phins Compact C7 in standard mode.

-
1. Click on the **SETUP** menu then select the **NAVIGATION PARAMETERS** option. The Navigation Parameters page is displayed.
-

2. In the **UTM Zone Mode** area, tick the **Extend current UTM Zone** box:



▼ UTM Zone Mode

Extend current UTM Zone ☐

Phins Compact C7 continues to give the UTM position referring to the original zone, even if the vehicle has over-passed the bounds of the original area.

-
3. Click on the **OK** button to save the settings.
-

6 Managing the external information

Phins Compact C7 requires some external information at start-up and when possible during navigation. When external information (position, speed, time) is not available, Phins Compact C7 uses only its internal sensors (accelerometers, FOG, clock) to estimate navigation data. In this configuration speed is less accurate and position can drift (see Phins Compact C7 Technical Description for performances).

To avoid this, position, speed and time fixes can be sent to the Phins Compact C7, this can be done in various mode:

- External sensor connection
- Manual information

6.1 Enabling the External Sensors

Phins Compact C7 receives data from external sensors, this data is displayed in the Navigation data window (refer to section 7.2).

In order to prevent incorrect or corrupted external aiding data degrading the performance of the product, external sensor data first passes through a rejection filter, before being incorporated into Phins Compact C7 main computation and Kalman filter.

External data acceptance can be:

- Automatic: left to the Phins Compact C7 rejection filter to decide whether to accept it or not: recommended mode, the external sensor is displayed ON.

External Sensors

GNSS 1

ON

- Forced in: forced mode bypasses the system rejection filter meaning all data, including potentially incorrect data is used by the system. Forced mode is not recommended as bad external sensor data will no longer be rejected and could corrupt the Kalman filter.



If an external sensor is set in Forced mode (in the input configuration page), the related ON/OFF button is inactive and no action is possible on this button.

External Sensors

GNSS 1 forced

ON

- Disabled: using the toggle box to switch the external sensor OFF (per default, after configuration of a new sensor): the box is displayed OFF. When toggled off the external sensor data will not be used in the Phins Compact C7 Kalman filter computations.


External Sensors

GNSS 1

OFF

To use an external sensor data, the external sensor should be:

- Activated: switched and displayed “ON” on the CONTROL page
- Or forced in by the rejection filter:
- Valid: valid status in the External Sensors Detailed Status



Procedure

1. Click on the  logo.
2. To **enable the external sensor**, click on the parameter of the external sensors(s) **until displaying ON**.

External Sensors



The sensor data will be used by the Kalman filter.

3. To **disable the external sensor**, click on the parameter of the external sensors(s) **until displaying OFF**.

The sensor data is no more used by the Kalman filter.

External Sensors



6.2 Inputting manually information to Phins Compact C7

Whenever Phins Compact C7 is started, the initial position is required.

Failure to input a correct initial position will generate inconsistent heading value, and the algorithm will be corrupted if the position given is too far from the real one.

Position initialization is done either using a sensor fix (GNSS) or input initial position.

Important

If a GNSS is connected, activated and GNSS fixes are valid, the position is used continuously.

There are several ways to input manual data:

- Position:
 - > manual position fix: this position is not saved in the Phins Compact C7
 - > position ZUPT



ZUPT mode shall only be used when the Phins Compact C7 is static. Activating ZUPT mode when Phins Compact C7 is moving could corrupt the Kalman filter and degrade navigation performance.

6.2.1 CONFIGURING MANUALLY THE POSITION

The position fix sent to the system is used only as an individual fix that is managed by the Kalman as GNSS position. The position fix is not saved in the non-volatile memory.

This is used to send a position fix during operation. It allows you to start the Phins Compact C7 when the starting mode is "Wait for position".

1. Click on the **SETUP** menu then select the **POSITION FIX** option. The following page is displayed according to the position representation:

The screenshot shows the 'Position Fix' configuration page. Under the 'Manual Position' section, the following fields are visible: Latitude (48° 48.036' N), Longitude (2° 0.0239' E), Depth (-87.48 m), Precision (10 m), Label (empty), Shortcuts (dropdown), and a Delete checkbox. An 'Advanced Mode' section at the bottom has a 'Manual position forced' checkbox. A circular button labeled 'Replace By Current Position' is on the right.

The screenshot shows the 'Position Fix' configuration page for UTM coordinates. Under the 'Manual Position' section, the following fields are visible: UTM Northing (5416662.46 m), UTM Easting (431327.53 m), Depth (-87.48 m), UTM Zone (U31), Precision (10 m), Label (empty), Shortcuts (dropdown), and a Delete checkbox. An 'Advanced Mode' section at the bottom has a 'Manual position forced' checkbox. A circular button labeled 'Replace By Current Position' is on the right.

2. In the **Manual position** area, select or enter the following parameters:
 - For Latitude/longitude system coordinates
 - > **Latitude**: Latitude in either degrees, or (degrees, decimal minutes) or (degrees, minutes, seconds) + hemisphere: N (North) or S (South)
 - > **Longitude**: Longitude in degrees, or (degrees, decimal minutes) or (degrees, minutes, seconds) + E (East) or W (West)
 - > **Depth**: in meters.
 - > **Precision**: standard deviation for the Kalman on input latitude, longitude and altitude, to be chosen in a drop-down list from 0.1 to 1000 m.
 - > **Label**: defining a text label for this position allows it to be kept locally on the computer (i.e., the position is kept in a cookie)
 - > **Shortcuts**: to use a position already defined and labeled
 - > **Delete box**: check this box to delete the position saved with the entered label
 - For UTM system coordinates
 - > **UTM Northing**
 - > **UTM Easting**
 - > **Depth**: in meters.
 - > **UTM Zone**: letter + number of the UTM zone
 - > **Precision**: standard deviation for the Kalman on input latitude, longitude and altitude, to be chosen in a drop-down list from 0.1 to 1000 m.
 - > **Label**: defining a text label for this position (waypoint system) allows it to be kept locally on the PC (i.e., the position is kept in a cookie)
 - > **Shortcuts**: to use a position already defined and labeled

-
3. If you want to take the current position into account by avoiding to type the current coordinates, just click on the **Replace by current position** button.

 4. Click on the **OK** button to take this updated position into account. This information will be used by the Kalman filter to improve its position estimation.

 5. In the Advanced area, tick the **Manual position forced** box to force the manual position fix that is normally going through the rejection filter. When the position is forced, the rejection is bypassed.

 6. Click on **OK** button to save the settings then click on **OK** to validate.
-

6.2.2 CONFIGURING THE ZUPT MODE

Zero velocity update modes may be used when Phins Compact C7 is kept static without any external sensor connected.

In this mode, fake speed (or position) information is input to Phins Compact C7 in order to improve the estimation of attitude and heading, to prevent the estimated position and speed from drifting and to perform fine alignment.



It is highly recommended to check that the product is not in “ZUPT” mode in normal operation, when other sensors are available. The ZUPT switch must be OFF.

1. Click on the **SETUP** menu then select the **NAVIGATION PARAMETERS** option. The Navigation Parameters page is displayed.
2. In the **ZUPT Mode** area, select the ZUPT mode from the list:

▼ ZUPT Mode

ZUPT Mode None

- **None:** no zero velocity update.
- **Static 10 m/s:** the fake sensor is sending to Phins Compact C7 a speed value of 0 m/s with a standard deviation of 10 m/s. The acquisition mode is « Always True » which means that Phins Compact C7 will always consider this information valid. The ZUPT flag will always be valid. This mode can be set when Phins Compact C7 is used as a gyrocompass and no external aiding sensor are connected (i.e., GNSS).
- **Static 0.1 m/s:** the fake sensor is sending to Phins Compact C7 a speed value of 0 m/s with a standard deviation of 0.1 m/s. The acquisition mode is « Always True » which means that Phins Compact C7 will always consider this information valid. The ZUPT flag will always be valid.
- **Autostatic:** the fake sensor is sending to Phins Compact C7 a speed value of 0 m/s with a standard deviation of 0.01 m/s. Phins Compact C7 will exit this mode if the measured rotation rate of any gyro is greater than 10°/h. In this case the ZUPT flag will change from valid to invalid.
- **Autostatic Bench:** the fake sensor is sending to Phins Compact C7 a speed value of 0 m/s with a standard deviation of 0.01 m/s. The fake sensor is sending to Phins Compact C7 a rotation value of 0°/h with a standard deviation equivalent to twice gyrometer noise. An additional constraint here is that heading, roll and pitch are assumed to be constant. Phins Compact C7 will exit this mode if the measured rotation rate (compensated from earth rotation) of any gyro is greater than 10°/h. This mode is restricted to very stable environment (i.e., internal calibration on turn table, alignment on bench for check-up tests).

- **Position:** the fake sensor is sending to the product no displacement in the three axis with a standard deviation of 0.1 m in the navigation frame. The acquisition mode is « Always True » which means that the product will always consider this information valid. The ZUPT flag will always be valid. This mode cannot be used at quay.




It is highly recommended to use Autostatic bench mode, only in the laboratory/workshop environment.

After a Zero Velocity Update sequence, it is highly recommended to deactivate the Zero Velocity Update mode.

-
3. Click on the **OK** button to save the settings.
-
4. **To enable the ZUPT mode**, click on the iXblue logo. The control page is displayed with the status.
-
5. Click on the ZUPT parameter until displaying ON.



-
6. To disable the ZUPT mode click on the ZUPT parameter until displaying OFF.




6.3 Configuring the Annotation Markers

An annotation marker is a marker associated with a user message (free text) defined by the user. This user message is part of the POSTPROCESSING protocol. This protocol should be selected in the output port configuration, refer to Phins Compact C7 Installation & Setup Guide.

Annotation markers can be decoded and exported using DelphiIns software.

-
1. Click on the **Setup** menu then select the **Log Book** option. The Logbook page is then displayed:



The screenshot shows a window titled "Logbook". Inside, there are three labeled fields: "Manual Time" with a small square tick box to its right, "Identifier" with a text input box containing the number "0", and "Message" with an empty text input box.

-
2. Click on **Manual Time** tick box to associate the message to a date and a time (UTC). If no date and time are specified, the current system time is used to timestamp the annotation.
 3. Enter an **identifier** to the message.
 4. Enter the **message** (32 characters maximum) which will be associated with the marker identifier.
 5. Click on the **OK** button to save the marker.
-

7 Viewing the System Information

7.1 Viewing the Status Messages

Two types of status messages are available on the Web-Based Graphical User Interface

- STATUS: displays status information on the top right of the window.
- DETAILED STATUS displays in the center of the window:
 - > Input/Output
 - > System
 - > External sensors status

The color of the logo gives you information on the Phins Compact C7 status.




Figure 11 - Web-based Graphical User Interface

Logo color

When a problem occurs, the color of the disc changes and the detailed status window is automatically displayed with the equipment in fault.



No activity



Activity

- Normal operation



Warning

- Does not affect performance
- Ideally: troubleshoot and correct



Alarm, error

- Affecting performance
- Need to troubleshoot and correct

Status Messages

Message displayed in blue means that is an information message

Message displayed in orange means that is a warning message

Message displayed in red means that is an error message

Message	Meaning
Alignment	Phins Compact C7 is in its coarse alignment phase
Fine alignment	Is set after the coarse alignment.
Optimal alignment	Is set after the fine alignment.
System ready	Phins Compact C7 is ready for navigation with optimal performances
System warning	There is a system warning
System error	An error has occurred
Connection Lost	The Ethernet connection with Phins Compact C7 is lost

Detailed Status

Detailed status displayed in blue means that is an information message

Detailed status displayed in orange means that a warning status is displayed for 3 seconds. This remains true whatever the protocol frequency.

Detailed status displayed in red means that an error status is displayed for 10 seconds. This remains true whatever the protocol frequency.

The Web-Based Graphical User Interface displays the status in real-time. To get the detailed status description, refer to the Phins Compact C7 Interface Library document.

7.2 Viewing the Navigation Data

Navigation data computed and received by Phins Compact C7 and data received from the external sensors are displayed in the Navigation Data pop-up window (see figure below).

Click on the **navigation data** menu on the top menus of the Web-Based Graphical User Interface.




Figure 12 - Navigation data pop-up window

Data displayed in the Navigation Data pop-up window:

- Heading and attitude
 - > Heading + standard deviation
 - > Roll + standard deviation
 - > Pitch + standard deviation
- Position
 - > Latitude + standard deviation
 - > Longitude + standard deviation
 - > Altitude + standard deviation
 or
 - > UTM North + standard deviation
 - > UTM East + standard deviation
 - > UTM Zone
 - > Altitude + standard deviation
- Heave
 - > Heave
 - > Surge
 - > Sway

- Time
 - > System time since last reboot
 - > UTC synchronized time
 - > Last UTC synchro reception time
- Speed
 - > Speed norm
 - > North speed + standard deviation
 - > East speed + standard deviation
 - > Vertical speed + standard deviation
- GNSS1 and GNSS2
 - > Latitude
 - > Longitude
 - > Altitude
 - > Standard deviation: it corresponds to the standard deviation of the latitude data.
 - > Time: it is the validity time of the last GNSS data. In the case of GNSS drop-out, or GNSS shielding, GNSS data is not updated and the last valid data from the GNSS are displayed.
 - > Mode: it corresponds to the quality factor. Refer to the Phins Compact C7 Interface Library document to get the definition of the quality factor.
 - > Delay: it indicates the drift between last GNSS frame reception time and validity time contained in that frame. It should be less than 200 ms in typical cases. Values larger than 1 s or negative values usually come from a bad time synchronization configuration (PPS + Time instead of Time + PPS, or large network propagation time for example).
- EM Log
 - > Speed: longitudinal speed in knots
 - > Time: it is the arrival time of the last log EM data
- DVL 1 and DVL 2
 - > Longitudinal bottom speed
 - > Transverse bottom speed
 - > Vertical bottom speed
 - > Longitudinal water speed
 - > Transverse water speed
 - > Vertical water speed
 - > Range to Bottom
 - > Speed of sound
 - > Time
 - > Delay
- Current
 - > North current + standard deviation (m/s)
 - > East current + standard deviation (m/s)
- USBL 1, 2, 3
 - > Beacon N° (beacon ID)
 - > TP Code (Transponder code)
 - > Latitude
 - > Longitude
 - > Depth

- > Delay
- > Time: it is the validity time of the last USBL data.
- LBL
 - > Beacon N° (beacon ID)
 - > Latitude
 - > Longitude
 - > Depth
 - > Range
 - > Time: it is the validity time of the last LBL data.
- CTD
 - > Sound of speed data (from SVP or CTD)
- Depth
 - > Depth in meters
 - > Time: it is the validity time of the last depth sensor data

7.3 Viewing the Events Messages

Event viewer records all important events and system messages that occurred since the last system reboot. Events are time stamped using system date that can be synchronized in UTC. If no UTC synchronization is available, the system uses a default date for all the events (01-01-2006). Event names and colors use the same convention as the statuses displayed in the control page.

The system status and the error messages generated by Phins Compact C7 can be followed in the events viewer window by clicking on the **events viewer** menu. See hereafter an example of event viewer messages.




Figure 13 - Events viewer window

8 Recording Data

8.1 Internal Data Logging

Internal Data logging allows logging to Phins Compact C7 without requiring a PC to be connected during the survey.



The useful memory available for storing user data is 3,400 MB.

The storage requirement is proportional to the output frequency.

1. Click on the **DATA LOGGING** menu. The following information is displayed.
2. If needed, in the **Logging Information** field, modify the **Root File Name** that is automatically generated by typing the new name directly in the dedicated box. It must be composed of alphanumeric characters without any space between characters.
Selected directory: indicates the directory in the internal data logger
Free Space: indicates the space (in percentage value) available in the internal data logger
Remaining Time: indicates an estimation of the remaining time to be recorded according to the selected configuration chosen
3. For the **Logging parameters**, you can choose the Segmentation type:
 - **Segmentation:** select the type of segmentation (Time or Size) and the segmentation value.
 - Tick **Auto Data Logging at Startup** if you want automatic data logging at start up.
Wait for GNSS to get the time used to create the Root File Name.
Important: For auto data logging at start-up, PPS should be synchronized or NTP server should be enabled and valid.
4. In the **Input Selection** field, select the **input** from which to record the data. A file suffix, associated to each type of selected input, is automatically added to the Root File Name of the Logging Information field.
5. In the **Output Selection** field, select the **output** from which to record data. A file suffix, associated to each type of selected output, is automatically added to the Root File Name of the Logging Information field.
6. Click on the **File Explorer** field to browse and select the folder to record the selected data. The File Explorer also allows deleting/creating folders and retrieving/deleting files.
7. Click on the chosen directory then click on **Select** text to validate the directory choice. In the Logging Information field, the selected directory is displayed in front of Selected Directory.
8. Click on the **Start Logging** button to start recording all selected outputs.
The logging starts: an "Internal Data logging in Progress" message is displayed in the INTERNAL DATA LOGGING field.
At any moment, you can stop the record by clicking on the **Stop Logging** button.



When the PC is disconnected from Phins Compact C7, the internal data logging continues.

To retrieve the logged files:

- Connect the PC.
- Click on the Stop Logging button.
- Browse the internal data log files system.
- Click on the files to be downloaded.

8.2 External Data Logging



iXblue provides also an external dedicated tool to log system outputs: iXblue Multilogger.

This tool and its user guide are available on the Phins Compact C7 flash drive.

Whenever possible it is recommended to record the « postprocessing » protocol. If an issue occurs during use, it will allow iXblue to perform a detailed analysis.

iXblue CONTACT - SUPPORT

For non-URGENT support:

- by email: support@ixblue.com
- using the form on the iXblue web site www.ixblue.com

For 24/7 URGENT SUPPORT:

- North America / NORAM
+1 617 861 4589
- Europe Middle-East Africa Latin-America / EMEA-LATAM
+33 1 30 08 98 98
- Asia Pacific / APAC
+65 6747 7027

A Appendix: External data rejection criteria

When an observation of external data is performed data will be accepted, rejected or attenuated by the Kalman filter.

For example, when a GNSS position is received, the distance δ between Phins Compact C7 position and GNSS position is calculated.

- If the distance is smaller than 3 times the quadratic sum of GNSS position standard deviation and Phins Compact C7 standard deviation the position is accepted.
- If the distance is greater than 5 times the quadratic sum of GNSS position standard deviation and Phins Compact C7 standard deviation the position is rejected.
- If the distance is within 3 to 5 times the quadratic sum of GNSS position standard deviation and Phins Compact C7 standard deviation, the position is attenuated by a factor μ .

These criteria can be written as follows:

$$\mu = \begin{cases} 1 & \text{if } \delta < 3\sqrt{\sigma_{INS}^2 + \sigma_{GPS}^2} \\ 1 - \frac{\left[\frac{\delta}{\sqrt{\sigma_{INS}^2 + \sigma_{GPS}^2}} \right] - 3}{2} & \text{if } 3\sqrt{\sigma_{INS}^2 + \sigma_{GPS}^2} < \delta < 5\sqrt{\sigma_{INS}^2 + \sigma_{GPS}^2} \\ 0 & \text{if } \delta > 5\sqrt{\sigma_{INS}^2 + \sigma_{GPS}^2} \end{cases}$$

After GNSS position is taken into account, the new standard deviation of Phins Compact C7 position is calculated as follows:

$$\sigma_{INS}^2 = \frac{\sigma_{INS}^2 \cdot \frac{\sigma_{GPS}^2}{\mu}}{\sigma_{INS}^2 + \frac{\sigma_{GPS}^2}{\mu}}$$

When GNSS sensor data is accepted, $\mu = 1$, and GNSS standard deviation is taken as: σ_{GPS} . We hence find the standard formula for the new Phins Compact C7 standard deviation at the output of the Kalman filter:

$$\sigma_{INS} = \sqrt{\frac{\sigma_{INS}^2 \cdot \sigma_{GPS}^2}{\sigma_{INS}^2 + \sigma_{GPS}^2}}$$

When GNSS sensor data is rejected, $\mu = 0$.

GNSS standard deviation is taken into account with the following value:

$$\frac{\sigma_{GPS}}{\mu}$$

which tends to an infinite value when $\mu = 0$.

So rejecting an external sensor is equivalent to associating an infinite standard deviation to the GNSS position.

When GNSS data is attenuated, $0 < \mu < 1$.

GNSS standard deviation is taken into account with the following value:

$$\frac{\sigma_{GPS}}{\mu} > \sigma_{GPS}$$

So attenuating an external sensor is equivalent to increasing the standard deviation associated with this sensor.

The same criteria described above is applicable to all types of external aiding data.




Figure 14 - Rejection criteria schematic

PAGE INTENTIONALLY LEFT BLANK