

NORBIT

Subsea ROV/AUV & USV Integration Manual



Notice

We make every effort to provide the latest technical documentation. There may be updates. For this, please contact [NORBIT Support](#) for the latest information.

Copyright Statement

Copyright 2023 by NORBIT. All rights reserved. This publication may not be copied, translated, reproduced or transmitted in any electronic form, without prior written consent from NORBIT.

Disclaimer

While every effort is made to ensure the information given is accurate, NORBIT does not accept liability for any errors or omissions. All non-metric weights and measurements are approximate. Specifications, equipment, and other information in this document are subject to change without notice.

All performance metrics mentioned in this document, such as attainable depths, was derived from tests in Portland, Oregon and Seattle/Tacoma, Washington, USA in May 2017. Acoustic conditions are described when describing performance capabilities.

Release Notice

This is the December 7, 2023 release of the NORBIT ROV/AUV/USV Integration Manual.

Reference Documentation

This manual should be used in conjunction with the following documents. Please contact NORBIT Support if you do not have these documents.

TN-180196 - WBMS Data Format Definition
TN-210082 - WINGHEAD Interface Description
TN-140075 - Multibeam User Manual

Contact Information

NORBIT Subsea AS
Stiklestadveien 1
7041 Trondheim
Norway

Phone: +47 739 82 569
Support: <https://norbit.com/subsea/support/>
Email: subsea_support@norbit.com
Web: <https://norbit.com/subsea/>

Contents

1	General Guidelines	1
1.1	Subsea Hardware Configuration	1
1.2	Motion Stabilisation	1
2	ROV Configurations	1
2.1	WBMS Single Head	1
2.2	WBMS Dual Head	2
2.2.1	WBMS Trigger & Timing Connection	2
2.3	WINGHEAD Single Head	3
2.4	WINGHEAD Dual Head	3
2.4.1	WINGHEAD Trigger & Timing Connection	4
3	AUV Configurations	5
3.1	WINGHEAD Single Head	5
4	WINGHEAD Series	5
4.1	WINGHEAD Bulkhead Options	5
4.2	Vent Screw	6
4.3	Power	9
4.3.1	Input Voltage	9
4.3.2	Power Consumption	9
4.3.3	Power Inrush	9
4.3.4	Sonar Grounding	9
4.3.5	Common Mode Choke	10
4.4	Ethernet	11
4.4.1	General	11
4.4.2	Change Sonar IP Address	11
4.4.3	Change Ethernet Speed	11
4.5	Trigger	11
4.5.1	General	11
4.5.2	IO Configuration	12
4.5.3	Trigger Delays	12
4.6	Timing	12
4.6.1	General	12
4.6.2	IO Configuration	12
4.6.3	IRIG-B	13
4.6.4	NTP+PPS	13
4.6.5	NTP	13
4.7	Cable Options	13
4.7.1	USV	13
4.7.2	ROV/AUV	13
5	WBMS Series	14
5.1	WBMS Bulkhead Pinout	14
5.2	Power	14
5.2.1	Input Voltage	14
5.2.2	Power Consumption	14
5.2.3	Power Inrush	15
5.2.4	Sonar Grounding	15
5.2.5	Common Mode Choke	15
5.3	Ethernet	16
5.3.1	General	16
5.3.2	Change Sonar IP Address	16
5.4	Trigger	16
5.4.1	General	16
5.4.2	Trigger Delays	16
5.5	Timing	17
5.5.1	General	17

5.5.2	IRIG-B	17
5.5.3	NTP+PPS	17
5.5.4	NTP	17
5.5.5	1PPS+ZDA Direct	17
5.6	Cable Options	18
5.6.1	USV	18
5.6.2	ROV/AUV	18
6	Mounting	19
6.1	Weights & Dimensions	19
6.2	Acoustic Clearance Zones	19
6.3	Isolation	19
6.4	ROV Mounting	20
6.4.1	WINGHEAD Mounting Including Bracket	20
6.4.2	WBMS Mounting Including Bracket	21
6.4.3	WBMS Mounting Excluding Bracket	21
6.5	Mounting Examples	22
7	Operation Without GUI	25
7.1	Passive Mode	25
7.2	Headless Mode	25
7.3	Stop Sonar Pinging	26
7.4	Start/Stop Recording	27
8	Time Synchronisation	28
8.1	Subsea Timing Options	28
8.2	WINGHEAD Timing	28
8.2.1	Prerequisites	28
8.2.2	Configuration	28
8.2.3	PPS Loss	29
8.2.4	PPS Noise	30
8.3	WBMS Timing	30
8.3.1	Configuration	30
8.3.2	Invalid Time Reporting	31
8.3.3	Troubleshooting	32
8.4	General Timing Issues	33
8.4.1	PPS Issues	33
8.4.2	NTP Issues	33
Appendix A: Sonar Head Signal Input		34
A1.	WINGHEAD Signal Input	34
A2.	WBMS Signal Input	36
Appendix B: RS232 Considerations		38
Appendix C: Integration Guides		39
C1.	RTS Gen5 Quick Start	39
C2.	ROV Integration Example with WBMS & ROVINS	44
C3.	Innova Matrix 2+ Quick Start	46
Appendix D: Timing Methods		51
D1.	WBMS 1PPS+ZDA Direct Timing Scheme	51
D2.	NTP Configuration on a Time-Synchronised PC	52
Appendix E: Suggested Pigtail Test Cables		56
E1.	WINGHEAD 24-Pin Test Cable	56
E2.	WBMS 10-Pin Test Cable	57

1 General Guidelines

This document describes the special considerations when mounting NORBIT sonars on ROVs, AUVs, ASVs and USVs. The focus is on the electronic and technical side of the installation and should be used in conjunction with the NORBIT Multibeam User Manual (TN-140075).


1.1 Subsea Hardware Configuration

The topside SIU is **NOT** required for subsea (ROV and AUV) installations, and NORBIT does not recommend using it. Refer to sections 2 and 3 for the recommended ROV and AUV hardware configurations, respectively.

1.2 Motion Stabilisation

For standalone NORBIT sonars, without integrated INS functionality, a TSS1 message can be interfaced from an external motion sensor for roll stabilisation (and pitch stabilisation on certain models), to allow wider swaths and more even sounding coverage in dynamic sea states. TSS1 is a common data format which most ROV and AUV motion sensors can output.

The message should be interfaced to the PC on which the NORBIT GUI is installed, via a serial COM port. Under **INS Tools > TSS1**, enable the **Use TSS1** checkbox, and select the **COM port** and **Baud Rate**. Click **OK**. Stabilisation should then be enabled under the **Advanced** menu.



High update rates of at least 50Hz are recommended. The minimum baud rate for a 50Hz update rate is 19200. The selected baud rate must match the output from the motion sensor.

2 ROV Configurations

The following configurations are valid with WINGHEAD, WBMS Bathy, FLS, STX, Deep Sea and FullOcean NORBIT sonars.

2.1 WBMS Single Head

The recommended setup for single head is shown below:




Figure 1. Typical WBMS Single Head ROV Setup

2.2 WBMS Dual Head

The recommended setup for dual head is shown below:




Figure 2. Typical WBMS Dual Head ROV Setup

2.2.1 WBMS Trigger & Timing Connection

To connect the trigger signal between the dual head sonars, the RS232 trigger signal must be crossed over (TX to RX):

Signal	Pin	Comment
RS232 TX/Trig Out	5	Trigger between sonars
RS232 TX/Trig In	6	Trigger between sonars
PPS/IRIG-B in	7	To MUX/timing output
Signal GND	8	Shared signal GND (do not connect to PWR GND)
PWR GND	9	To PSU (do not common with Signal GND)
PWR 24V	10	To PSU

Table 1. Trigger & Timing Connections




Figure 3. Dual Head ROV synchronisation and 1PPS wiring

2.3 WINGHEAD Single Head

The WINGHEAD ROV setup is very similar to the WBMS, however options can be available.




Figure 4. Typical WINGHEAD Single Head ROV Setup

Notes:

- 18-pin variant uses RS422 serial interfacing and 100Mbit Ethernet.
- 24-pin variant uses RS422 or TTL serial interfacing and 100Mbit or 1000Mbit ethernet.
- Non-WINGHEAD “S” series models will run on 24v/48v DC.

2.4 WINGHEAD Dual Head




Figure 5. Typical WINGHEAD Dual Head ROV Setup

2.4.1 WINGHEAD Trigger & Timing Connection

To connect the trigger signal between the dual head sonars, the RS422 trigger should be pin-to-pin as it uses half duplex signalling:

Signal/Sonar	18-pin (RS422)	24-pin (RS422 PPS)	24-pin (TTL PPS)	Comment
Trigger+	15	24	24	RS422 Trigger between sonars
Trigger-	16	23	23	
TIME+	9	1	1	1PPS signal Do not connect Time GND to PWR GND
TIME-	14	2	N/A	
TIME GND	N/A	N/A	3	

Table 2. Trigger and Timing Connections




Figure 6. WINGHEAD 18-pin Trigger and Timing RS422 Connections




Figure 7. WINGHEAD 24-pin Trigger and Timing RS422 and TTL Connections

3 AUV Configurations

3.1 WINGHEAD Single Head

The recommended setup for single head AUV installations is shown below:




Figure 8. Typical WINGHEAD Single Head AUV Setup

4 WINGHEAD Series

4.1 WINGHEAD Bulkhead Options

Depending on the sonar model, the WINGHEAD contains either an 18-pin or 24-pin bulkhead connector. The pinout descriptions and electrical specifications are detailed in the following sections.


The 24-pin connector supports an extra INS channel for synchronisation purposes, and can therefore support longer cables, extra wires for Gigabit Ethernet communications, and ground connections allowing single-ended time and trigger interfacing.

By default, the TRIG+/- and TIME+/- inputs are configured for RS422 to allow better noise immunity. The input characteristics can be modified in the sonar Web UI, which can be accessed in a web browser at <http://<sonar-ip>:8080> (for example: <http://192.168.53.XX:8080>, where XX is the last 2 digits of the sonar serial number). Refer to section 4.5.2 for more details.

4.2 Vent Screw

WINGHEAD B44 Deep Sea models are equipped with a pressure vent screw located on the bottom lid. This primarily serves the purpose of facilitating production procedures carried out by qualified NORBIT personnel.

Additionally, it functions as a safety measure following deep dives, should there be any concerns about potential leaks, by enabling the controlled release of pressure in a safe and controlled manner. Do **NOT** tamper with the vent screw unless absolutely necessary, as doing so may result in irreparable damage to the sonar. If in doubt, contact NORBIT Support for guidance.



4.2.1 Option 1: 24-Pin Connector

WINGHEAD 24-Pin Bulkhead Connector, PN 33227

Connector type : NORBIT 33227
 Material : Titanium Grade 5
 Insert : Lemo 24 pin
 Endurance : > 5000 cycles IEC 60512-5 test 9a
 BH O-ring life : Situation dependent – check regularly.
 BH O-ring : Parker 6-725 NBR 70 Ø16.56x1.78



Figure 9 – 24-Pin Bulkhead and with mating connector

Pin	Function	Electrical Spec	Comment
1	TIME+	RS422	Selectable Single-ended/Balanced TTL/ RS422*
2	TIME-	RS422	
3	TIME_GND	RS422 GND	
4	PWR-	Power GND	Main Power GND
5	ETH_B-	1000BASE-T	Selectable 1000BASE-T and 100BASE-T
6	ETH_B+	1000BASE-T	Selectable 1000BASE-T and 100BASE-T
7	PWR-	Power GND	Main Power GND
8	ETH_A+	1000BASE-T	Selectable 1000BASE-T and 100BASE-T
9	IMU_A+	RS422	RS422
10	IMU_B-	RS422	RS422
11	IMU_C+	RS422	RS422
12	ETH_C-	1000BASE-T	Selectable 1000BASE-T and 100BASE-T
13	ETH_A-	1000BASE-T	Selectable 1000BASE-T and 100BASE-T
14	IMU_A-	RS422	RS422
15	IMU_B+	RS422	RS422
16	IMU_C-	RS422	RS422
17	ETH_C+	1000BASE-T	Selectable 1000BASE-T and 100BASE-T
18	PWR+	24v or 24v-48v	DC Main power input (-S models or other models)
19	ETH_D+	1000BASE-T	Selectable 1000BASE-T and 100BASE-T
20	ETH_D-	1000BASE-T	Selectable 1000BASE-T and 100BASE-T
21	PWR+	24v or 24v-48v	DC supply input (24v-S models or 24-48v other models)
22	TRIG_GND	RS422 GND	Selectable Single-ended/Balanced TTL/ RS422*
23	TRIG-	RS422	
24	TRIG+	RS422	

Table 3. WINGHEAD 24-Pin Bulkhead Pinout

The 24-pin connection allows selection of electrical input types for Trigger pulse and Time input between balanced (RS422) and single-ended (TTL). The default is RS422 for better noise immunity. RS422 connections should be made between the TRIG+/- or TIME+/- connections, and TTL connections should be between TRIG_GND and TRIG+, or TIME_GND and TIME+ connections.

*RS232 (12v-24v) can be input using the Single-ended input type with the introduction of a 220Ω in-line resistor.

4.2.2 Option 2: 18-Pin Connector

WINGHEAD 18-Pin Bulkhead Connector, PN 33237

Connector type : NORBIT 33237
 Material : Titanium Grade 5
 Insert : Lemo 18 pin
 Endurance : > 5000 cycles IEC 60512-5 test 9a
 BH O-ring life : Situation dependent – check regularly.
 BH O-ring : Parker 2-014 NBR70 Ø12.42x1.78




Figure 10. 18-Pin Bulkhead (Left) and Mating Connector (Right)

Pin	Function	Electrical Spec	Comment
1	PWR-	Power GND	Main Power GND
2	PWR-	Power GND	Main Power GND
3	PWR+	24v or 24v-48v	DC supply input (24v-S models or 24-48v other models)
4	PWR+		
5	IMU COM1	RS422	RS422
6	IMU COM2	RS422	RS422
7	LAN TX+	100BASE-T	100BASE-T
8	LAN RX+	100BASE-T	100BASE-T
9	IRIG B+	RS422	RS422 Only
10	IMU COM3	RS422	RS422
11	IMU COM4	RS422	RS422
12	LAN TX-	100BASE-T	100BASE-T
13	LAN RX-	100BASE-T	100BASE-T
14	IRIG B-	RS422	RS422 Only
15	TRIGGER+	RS422	RS422 Only
16	TRIGGER-	RS422	RS422 Only
17	NC		
18	NC		

Table 4. WINGHEAD 18-Pin Bulkhead Pinout

4.3 Power

4.3.1 Input Voltage

When not using the SIU, i.e., when powering the WINGHEAD sonar directly, as per the recommended setup for ROV and AUV installations, the following specifications should be followed:

Input	Voltage	Comments
Minimum	24V (cut-off: 20v)	If the PSU and power lines create voltage drops, or spikes that fall under 20V, unexpected behaviour may be encountered, with sudden system reboots.
Maximum for "S" series models	28V (break-down: 30v)	Approaching the break down voltage will burn the input on the sonar, requiring service.
Maximum for all other models	48V (shut-off: 52v)	

4.3.2 Power Consumption

Consumption may vary according to the model and TX settings applied during operation. The guiding numbers provided in [Table 5](#) were measured with an 8m cable and 48V PSU. Note that these do not cover all models and hardware revisions. If the power budget is tight, contact NORBIT Support for advice. NORBIT recommends using a 150W PSU (minimum) for all WINGHEAD models.

WINGHEAD Model	Description	Idle	5Hz 1600µs Peak	5Hz 1600µs Mean
B41, B41 Titanium, B44 Deep Sea, B44 Full Ocean	WINGHEAD Non-Integrated	47W	106W	76W
i77h, i79h	WINGHEAD Integrated	50W	109W	79W
B51S, B57S	WINGHEAD Stabilised	50W	103W	59W
i80S	WINGHEAD Stabilised (Integrated)	53W	106W	62W

Table 5. Power Consumption

Note: Figures quoted are for relatively low ping rates with longer pulse lengths for long range operations. For short range operations the sonars will ping faster, however shorter pulse lengths are used, therefore the current drawn is normally less.

4.3.3 Power Inrush

Power inrush is determined by several factors. Cable length (impedance between the PSU and sonar), input capacitor bank and PSU output capacitor bank are the most important factors. Below is a list of the NORBIT WINGHEAD sonars and the inrush specifications.

4.3.3.1 WINGHEAD B41, B41 Titanium, B44 Deep Sea, B44 Full Ocean, i77h & i79h

PSU Capacitor bank : ~70uF
TX PSU : ~90uF

4.3.3.2 WINGHEAD B51S, B57S, i80S & i87S

PSU Capacitor bank : ~170uF
TX PSU : ~70uF

4.3.4 Sonar Grounding

The sonar has multiple ground nodes, as detailed below.

4.3.4.1 Chassis Ground

Coupled to Internal Isolated Ground.

4.3.4.2 Power Ground

External power ground.

- **24-Pin Connector (PN 33227):** Connected to Pins 4 & 7 (ref [Table 3](#))
- **18-Pin Connector (PN 33237):** Connected to Pins 1 & 2 (ref [Table 4](#))

4.3.4.3 Time Ground

24-Pin Connector (PN 33227)

- For single-ended inputs (TTL) the WINGHEAD timing input has a separate signal ground. It is galvanically isolated from all other ground nodes. For 1PPS/Time input, connect to pins 1&3 (ref [Table 3](#))
- For balanced inputs (RS422) connect to pins 1&2 for the 1PPS/Time input, with optional RS422 ground on pin 3 (ref [Table 3](#))

18-Pin Connector (PN 33237)

- For single-ended inputs (TTL) a signal ground is not available. Therefore, a TTL/RS422 converter is needed, and the input is connected in the balanced mode described below.
- For balanced inputs (RS422) connect to pins 9 & 14 for the 1PPS/Time input (ref [Table 4](#))

4.3.4.4 Trigger Ground

Note that the trigger input and output are across the same pairs, independent of pulse type.

24-Pin Connector (PN 33227)

- For single-ended inputs (TTL) the WINGHEAD timing input has a separate signal ground. It is galvanically isolated from all other ground nodes. For Trigger input, connect to pins 22-24 (ref [Table 3](#))
- For balanced inputs (RS422) connect to pins 23-24 for the trigger input, with optional RS422 ground on pin 22 (ref [Table 3](#))

18-Pin Connector (PN 33237)

- For single-ended inputs (TTL) a signal ground is not available. Therefore, a TTL/RS422 converter is needed, and the input is connected in the balanced mode described below.
- For balanced inputs (RS422) connect to pins 15-16 for the trigger input (ref [Table 4](#))

4.3.5 Common Mode Choke

If the sonar is mounted without the SIU, as per the recommended setup for ROV and AUV installations, NORBIT advises the use of a common mode choke on the power lines to limit noise to the sonar through the power lines. A suitable choke is suggested below:

Manufacturer :	Bourns Inc.
Part :	7124-RC
Description :	Common Mode, CMC 2.55MH 10A 2LN Through Hole

4.4 Ethernet

4.4.1 General

NORBIT WINGHEAD sonars use the following:

- 4 wire 100BASE-T with HP Auto-MDIX Support for the 18-pin variant.
- 4/8 wire 100BASE-T/1000BASE-T with HP Auto-MDIX Support for the 24-pin variant. This is selected through the sonar web user interface.

4.4.2 Change Sonar IP Address

To change the IP address of WINGHEAD S series sonars (e.g. i80S, B51S), please contact NORBIT Support for assistance and **DO NOT** attempt to change it through the web interface. To change the IP address of regular WINGHEAD sonars, use a web browser entering: <http://<sonar-ip>:8080> (for example: <http://192.168.53.XX:8080>, where XX is the last 2 digits of the sonar serial number). Use the mode selection to change between static and DHCP. Use the IP address, Netmask and Gateway to change the static settings.

Figure 11. Web UI Network Settings

4.4.3 Change Ethernet Speed

The default Ethernet link speed is 100Mbit, however the 24-pin variant will run at 1000Mbit. The Auto-MDIX should auto-detect the link speed, however this might not be the case with some multiplexers. If necessary, the maximum auto-negotiated speed can be changed in the sonar Web UI, selecting 1000Mbit or 100Mbit, as shown in Figure 11.

4.5 Trigger


4.5.1 General

Many installations require synchronisation of sensors to prevent acoustic interference. NORBIT WINGHEAD sonars contain trigger lines for input and output of synchronisation pulses. To run NORBIT sonars in dual head mode, the trigger lines are required.

Description	:	Transceiver RS422, Isolated, Configurable
Ground	:	Trig_GND
Maximum ratings	:	See Table 3

The trigger input is RS422 (default), optional TTL 5V and 3V3.

4.5.2 IO Configuration



The screenshot shows the 'IO line configuration' tab in the NORBIT Web UI. It contains two dropdown menus. The first is labeled 'Time' and has a value of 'balanced'. The second is labeled 'Trigger' and also has a value of 'balanced'. Both dropdowns have a small downward arrow on the right side.

Figure 12. IO Line Configuration

How inputs are electrically interfaced is dependent on how they are wired. In the Web UI **IO Line Configuration** tab, selecting the “Balanced” input switches in a termination load resistor across the + & - inputs for RS422 operations. This load resistor is switched in (Balanced) or out (Single-ended).

If a Dual Head set up is used and the inputs are in parallel, then only one sonar should be in the “Balanced” mode otherwise the signal may be double terminated.

To connect the signals to the input:

- **TTL:** For TTL, connect TTL+ to Trig+ and TTL GND to Trig_GND.
- **RS422:** For RS422, connect as standard RS422. NORBIT does not, in general, recommend using the GND.
- **RS232:** RS232 can be used providing the inputs do not exceed +/-15v. For this reason, for voltages in the regions of +12v to +24v and/or -24v to -12v a 220Ω series resistor should be used to protect the input. If voltages are greater than +/-24v then more significant protection should be considered.

4.5.3 Trigger Delays

Trigger In: The Trigger In signal will initiate the TX. An adjustable trigger delay is possible with millisecond resolution.

Trigger Out: The Trigger Out signal is adjustable. Contact NORBIT Support for further details.

4.6 Timing

4.6.1 General

Description	:	Transceiver RS422, Isolated, Configurable
Ground	:	Time_GND
Maximum ratings	:	See Table 3

The timing input is RS422 (default), TTL (5V & 3V3).

4.6.2 IO Configuration

See section [4.5.2](#).

4.6.3 IRIG-B

Most common method when using the NORBIT SIU topside unit. The SIU timing processor uses ZDA + 1PPS to generate the IRIG-B signal. The timing signal is then connected from the SIU via the deck cable to the sonar.

Accuracy	:	Good, <0.1ms
USV	:	Recommended
ROV/AUV	:	Not recommended

4.6.4 NTP+PPS

Most common method when not using the NORBIT SIU topside. The sonar accepts the 1PPS pulse on the TIME/IRIG connection and qualifies the time using an NTP server through Ethernet. NTP can be run on a topside time-synchronised PC. This could be the PC running the data acquisition software, which obtains time from a GNSS source. Several NTP services are available including Qinsy SNTP and Meinberg NTP, both of which are free.

Accuracy	:	Good, <0.1ms
USV	:	Not recommended
ROV/AUV	:	Recommended

4.6.5 NTP

The sonar connects to an NTP server through Ethernet. For platforms with lots of motion and dynamics, this method is not recommended. For steady slow-moving platforms, this is an adequate solution if 1PPS is not available. NTP servers can be run on a topside time-synchronised PC on the same subnet as the sonar. This could be the PC running the data acquisition software, which obtains time from a GNSS source. Several NTP services are available including Qinsy SNTP and Meinberg NTP, both of which are free. Windows built-in NTP service is not recommended.

Accuracy	:	Medium, <2ms
USV	:	Not recommended
ROV/AUV	:	Optional

4.7 Cable Options

NORBIT can supply customised cables if required. Please contact NORBIT Support for more information.

4.7.1 USV


NORBIT offers a USV mounting cable kit. With this kit, the same bulkhead connector used on the sonar can be supplied to fit to the USV's watertight compartment, along with a deck cable with two underwater connectors to connect to the sonar. Internal to the compartment, various options can be made available. Contact NORBIT Support for more information.

4.7.2 ROV/AUV

For ROV mounting, NORBIT offers the WINGHEAD Titanium Interface Pigtail 24pin (PN 33256).

5 WBMS Series

5.1 WBMS Bulkhead Pinout



WBMS Bulkhead Connector

Connector type : NORBIT 33049
 Material : Titanium Grade 5
 Insert : Lemo 10 pin
 Endurance : > 5000 cycles IEC 60512-5 test 9a BH
 O-ring life : Situation dependent – check regularly.
 BH O-ring : Type 2-014 NBR-70 12.42x1.78mm
 Pressure rating : 600 Bar (mated)

Pin	Function	Electrical spec	Maximum Rating	Comment
1	LAN, TX+	100Base-T	1500 Vrms	Twisted Pair
2	LAN, TX-	100Base-T	1500 Vrms	
3	LAN, RX+	100Base-T	1500 Vrms	Twisted Pair
4	LAN, RX-	100Base-T	1500 Vrms	
5	Trig OUT	RS232	-15V to +15V	Debug/trigger. V _{low} =-6.1V V _{high} =6.6V
6	Trig IN	RS232 (TTL comp.)	-25V to +25V	Debug/trigger. Trigger threshold 1.7±0.5V
7	PPS/IRIG-B	TTL 5V	-9V to +14V	Timing input. 3.3V and 5V TTL
8	Signal GND	GND	-	Shared ground for Pin 5, 6 and 7.
9	GND	GND	-	Power ground
10	24VDC	24VDC	28V	Power input

Table 6. WBMS Bulkhead Pinout

5.2 Power

5.2.1 Input Voltage

All NORBIT WBMS sonars have the same input voltage specification when not using the SIU.

Input	Voltage	Comments
Minimum	24V (cut-off: 30v)	If the PSU and power lines create voltage drops, or spikes that fall under 20V, unexpected behaviour may be encountered, with sudden system reboots.
Maximum	28V (break-down: 30v)	Approaching the break down voltage will burn the input on the sonar, requiring service.

5.2.2 Power Consumption

Consumption may vary according to the model and TX settings applied during operation. The guiding numbers provided in [Table 7](#) were measured with an 8m cable and 24V PSU with no drop. Note that these do not cover all models and hardware revisions. If the power budget is tight, contact NORBIT Support for advice.

Model	Description	Idle	20Hz 500µs Peak	20Hz 500µs Mean
24002, 24009,	WBMS FLS Wide, all materials	0.6 A	2.4 A	1.4 A
24003, 24007, 24010	WBMS Bathy (2x1°), all materials	0.6 A	2.7 A	1.5 A
24016, 24017	WBMS STX (1x1°), all materials	0.8 A	2.5 A	2.0 A

Table 7. Power Consumption

5.2.3 Power Inrush

Power inrush is determined by several factors. Cable length (impedance between PSU and sonar), input capacitor bank and PSU output capacitor bank are the most important factors. Below is a list of the most common NORBIT sonars and some data on inrush.

5.2.3.1 WBMS FLS (24002/24009)

PSU Capacitor bank	:	70uF
TX PSU	:	No TX inrush

5.2.3.2 WBMS Bathy (24003/24007/24010)

PSU Capacitor bank	:	70uF
TX PSU	:	~10mF

The NORBIT bathy sonars have a power input capacitance of around 10000uF. Most PSUs will handle this, but if there is other equipment operating in parallel with the sonar, and power issues are experienced when the sonar is powered on, NORBIT recommends adding at least 10000uF (35V rated) output capacitance to the PSU.

5.2.3.3 WBMS STX (24016/24017)

PSU Capacitor bank	:	170uF
TX PSU	:	No TX inrush

5.2.4 Sonar Grounding

The sonar has three different ground nodes, as detailed below.

5.2.4.1 Chassis Ground

Capacitively coupled to Power Ground with high voltage capacitors.
All models : 110-130nF 500V

5.2.4.2 Power Ground

Internal power ground, connected to Pin 9 (see section [5.1](#))

5.2.4.3 Signal Ground

Signal ground is galvanically isolated from all other ground nodes. See sections [5.4](#) and [5.5](#).

5.2.5 Common Mode Choke

If the NORBIT sonar is mounted without the SIU, as per the recommended setup for ROV and AUV installations, NORBIT advises using a common mode choke on the power lines to limit noise to the sonar through the power lines. A suitable choke is suggested below:

Manufacturer	:	WURTH ELEKTRONIK
Part	:	744834433
Description	:	Common Mode, Power Line, Horizontal, 3.3 mH, 5 A, WE-CMBH Series

5.3 Ethernet

5.3.1 General

NORBIT WBMS sonars uses a 4 wire 10BASE-T/100BASE-TX with HP Auto-MDIX Support, and it cannot be reconfigured.

Estimated data rates for a single head WBMS system at maximum ping rate are provided below.

Ping Rate	Bathy	INS	WC	SS	SN	SNS	Data Rate
50 Hz	✓	✓	X	X	X	X	5 Mbps
50 Hz	✓	✓	✓	✓	X	X	13 Mbps
50 Hz	✓	✓	✓	✓	✓	X	13 Mbps
50 Hz	✓	✓	X	X	X	✓	11 Mbps

Table 8. WBMS Data Rates

5.3.2 Change Sonar IP Address

Refer to the NORBIT Multibeam User Manual (TN-140075) for instructions.

5.4 Trigger

5.4.1 General

Many installations require synchronisation of sensors to prevent interference. NORBIT sonars have separate trigger lines for input and output of synchronisation pulses. Note that some of the oldest system revisions may not have this capability. To run NORBIT sonars in dual head mode, the trigger lines are required.

Hardware Description : Transceiver RS232, Isolated
 Ground : SigGND
 Maximum ratings : See [Table 6](#)

The trigger input is TTL 5V and 3V3 compatible and the SigGND is isolated from power ground.

5.4.2 Trigger Delays

Trigger In: The default delay from the Trigger In signal to the centre of the transmit pulse is 3300µs (half the transmit pulse buffer plus additional). An adjustable trigger delay is possible in millisecond resolution.

Trigger Out: The Trigger Out signal is sent out at 3300µs (half the transmit pulse buffer plus additional) before the centre of the following transmit pulse. An adjustable trigger delay is possible in millisecond resolution.

The command `set_trigger_mode` and `set_trigger_delay` will control the trigger and adjust the trigger delay in both Trigger In and Out. Refer to the Data Format Definition document (TN-180196, TN-210082) for details.

5.5 Timing

5.5.1 General

Hardware description :	Transceiver RS485, Isolated
Ground :	SigGND
Maximum ratings :	See Table 6

The timing input is TTL 5V and 3V3 compatible and the SigGND is isolated from power ground. There are several ways of time synchronizing a NORBIT sonar. The timing pins are Pins 7 and 8 (see section [5.1](#)). The time synchronisation methods are detailed below.

5.5.2 IRIG-B

Most common method when using the NORBIT SIU topside. The SIU timing processor uses ZDA + 1PPS to generate the IRIG-B signal. The timing signal is then connected from the SIU via the deck cable to the sonar.

Accuracy :	Good, <0.1ms
USV :	Recommended
ROV/AUV :	Not recommended

5.5.3 NTP+PPS

Most common method when not using the NORBIT SIU topside. The sonar takes 1PPS + SigGND on pins 7 and 8 and connects to an NTP server through Ethernet. NTP can be run on the topside PC where the data acquisition software is installed, and there are many free NTP services available, such as Qinsy NTP and Meinberg NTP, both of which are free.

Accuracy :	Good, <0.1ms
USV :	Not recommended
ROV/AUV :	Recommended

5.5.4 NTP

When there is no 1PPS available, the last method is NTP only, but NORBIT strongly advises against this unless there is no alternative. The sonar connects to an NTP server through Ethernet. For platforms with lots of motion and dynamics, this method is not recommended. For steady slow-moving platforms, this is an adequate solution if 1PPS is not available. NTP can be run on the topside PC where the data acquisition software is installed, and there are many free NTP services available, such as Qinsy NTP and Meinberg NTP, both of which are free.

Accuracy :	Medium, <2ms
USV :	Not recommended
ROV/AUV :	Optional

5.5.5 1PPS+ZDA Direct

The WBMS accepts 1PPS on pins 7 and 8 and \$GPZDA on pins 5 and 6. This option uses the trigger lines and requires a firmware upgrade. As such, when this option is used, it is not possible to use the trigger function in dual head operations. Refer to [0](#) for more details.

Accuracy :	Good, <0.1ms
USV :	See section 4.6.3
ROV/AUV :	Not typically used, see section 4.6.4

5.6 Cable Options

NORBIT can supply customised cables if required. Please contact NORBIT Support for more information.

5.6.1 USV

NORBIT can offer a USV mounting cable kit. Contact NORBIT Support for more information.

5.6.2 ROV/AUV

For ROV mounting, NORBIT offers the following cables:

- PN 33095, WBMS Interface Pigtail
- PN 33205, WBMS Interface Pigtail Angled (longer lead times should be expected)

6 Mounting

6.1 Weights & Dimensions

Approximate sonar weights are given below. For dimensions, please refer to the datasheets on the NORBIT website. DeepSea refers to WBMS sonars with 4500m depth rating, while FullOcean refers to 6000m. Standard systems are depth rated to 100m.

Sonar	Displacement m ³	Weight in air		Weight in water	
		Sonar (kg)	Sonar & Bracket (kg)	Sonar (kg)	Sonar & Bracket (kg)
WBMS Standard TX, DeepSea	2.40	6.4	7.9	4.00	4.50
WBMS Standard TX, FullOcean	2.50	7.0	8.5	4.50	5.00
WBMS Narrow TX, Standard	2.85	5.1	6.6	2.25	2.75
WBMS Narrow TX, DeepSea	3.00	7.6	9.1	4.60	5.10
WBMS Narrow TX, FullOcean	3.10	8.2	9.7	5.10	5.60
WBMS STX, Standard	2.30	5.2	6.7	2.90	3.40
WINGHEAD B41 (100m rated)	3.10	6.6	8.1	3.5	4.7
WINGHEAD B41Ti (1500m rated)	3.10	9.0	10.5	5.9	7.1

Table 9. Approximate Weights

6.2 Acoustic Clearance Zones

Both the WBMS and WINGHEAD sonars need 180° coverage side to side for normal seabed operations and more if the user wants to look “up” for special operations. The along track clearance should be >15° and >30° for S series or STX models.




Figure 13. Acoustic Clearance Zones

6.3 Isolation

It is important to keep the NORBIT sonar electrically isolated from the mounting structure that it is attached to, such as brackets, poles and the vessel's hull. This can lead to severe corrosion otherwise. It is good practice to test the electrical isolation using a low voltage DMM (not a Megger).

Use the NORBIT protection plate if mounted directly on metal (PN 45459) and the correct plastic spacers for the screws which fasten the sonar.

6.4 ROV Mounting

6.4.1 WINGHEAD Mounting Including Bracket

Bracket part number : 451214, 451215
Bracket material : PETP Plastic
Bracket flange : Figure 14




Figure 14. WINGHEAD with Standard Bracket

The WINGHEAD bracket can be reconfigured as required (Figure 15). The “hull mount” configuration is typically used for ROV and AUV installations.




Figure 15. Reconfiguring the Bracket

6.4.2 WBMS Mounting Including Bracket

Bracket part number	:	35047
Bracket spacers	:	45466
Bracket material	:	POM Plastic
Bracket flange	:	Figure 16




Figure 16. WBMS standard bracket 35047 flange (left) and WBMS mounted on standard bracket (right)

For detailed drawings of the WBMS and WBMS Narrow Transmit sonars, please refer to the NORBIT Multibeam User Manual. (TN-140075).

6.4.3 WBMS Mounting Excluding Bracket

Protection plate	:	1 x 45459
WBMS spacer	:	2 x 45466 (included with the compact bracket, PN 35165) 2 x 45193 (supplied when compact bracket is not included)
Screws	:	M6 x 70-100mm
Hole spacing	:	160mm



Figure 17. WBMS mounted without bracket

6.5 Mounting Examples




Figure 18. WBMS Basic on Sperre SUB-fighter 30k with IXBLUE PHINS



Figure 19. Dual WBMS Basic on a STD Quasar ROV with IXBLUE ROVINS



Figure 20. Up looking WBMS Bathy on Seatronics




Figure 21. Sub-Atlantic Comanche ROV



Figure 22. Mounted on Comanche




Figure 23. WINGHEAD mounted on Resolve Marine's Helix XLX66 ROV

7 Operation Without GUI

Some setups, such as those on AUVs, may require operation without the NORBIT GUI. Users can interface with the sonar on a script level, providing direct commands to the sonar (ref. TN-180196, TN-210082). In addition, the GUI can be operated in Passive and Headless modes. These modes are not intended to be used where several observers are required, as it substantially increases sonar bandwidth and may cause data loss.

7.1 Passive Mode

Passive mode is a special operating mode of the GUI where the user has no interaction with the sonar. The data flows through the GUI and is visualised as normal, but the sonar settings cannot be changed. The data is also output as an s7k stream, so the GUI acts as a proxy server. In this mode, the user can still change some GUI related options in a limited manner. It is mostly used for data visualisation in real time and prevents unintended setting adjustments.

- Step 1.** Connect the GUI to the sonar as normal (i.e. active mode).
- Step 2.** Setup the sonar as needed with the desired operator settings.
- Step 3.** Close the GUI.
- Step 4.** Modify the sonar ini file, located at: `%appdata%\Norbit\settings_sonarid_<sonarName>.ini`
- Step 5.** Under [Gui], change `use_passive_connection` from `false` to `true`. Save and close.
- Step 6.** Start the GUI to connect it in passive mode.
- Step 7.** To revert the sonar to active mode, modify the sonar ini file, or select "Set Sonar Factory Defaults" on the Connection dialog within the GUI.


7.2 Headless Mode

Headless mode is a further simplification of passive mode, where the data flow is the same, however no GUI is displayed for visualisation. Instead, only a simple console is displayed. In this case the software acts as a proxy server with no interaction. The NORBIT GUI must have been connected to the sonar once in normal (active) mode prior to using headless mode. To activate headless mode:

- Step 1.** Connect the GUI to the sonar as normal (i.e. active mode).
- Step 2.** Setup the sonar as needed with the desired operator settings.
- Step 3.** Make a note of the sonar name, which is found on the info box next to the wedge. For example:

Sonar Name: 24016-2-PBDDFA_#1708

- Step 4.** Close the GUI.
- Step 5.** Navigate to `C:\users\<user>\AppData\Roaming\Norbit\` and copy the name of the .ini file relevant to the sonar that you wish to operate in headless mode. For example:



- Step 6.** Open Windows Command Prompt and change the active directory to:
`C:\Program Files (x86)\Norbit AS\WBMS\`

Step 7. Enter the command:

```
wbmsgui.exe -headless settings sonarid <sonar name>.ini
```

For example:

```
wbmsgui.exe -headless settings_sonarid_24016-2-PBDDFA_#1708.ini
```

Step 8. The GUI will now connect in passive mode and act as a proxy only. Commands must be sent separately to the sonar each time a setting change is required.

Step 9. Press the Esc key to close down the console application.



NOTE: It is important to ensure that the sonar has the correct firmware version and an up-to-date license (if applicable) otherwise it will fail to start.




Figure 24. GUI in Headless Mode

7.3 Stop Sonar Pinging

For AUV installations, it is often not desirable to have the sonar pinging when the GUI connects. To prevent the sonar from pinging, add the `start_playing_on_connection` command to the GUI ini file, under the `[General]` section. The file is located at: `%appdata%\Norbit\wbmsgui.ini`

```
[General]
start playing on connection=false
```

7.4 Start/Stop Recording

The GUI implements two WebSocket servers which clients can connect to. The communication format on the binary sockets is UTF-8 encoded JSON. The control port (40804) is used to send messages to the GUI, and the status port (40803) is used to receive messages from the GUI.

After the GUI is started, the following commands are used on the control port using a WebSocket client app or Google Chrome extension on the following URL: *ws://<host-ip>:40804/WBMSControl* (where <host-ip> is the IP address of the PC which runs the headless GUI).

start_recording

Starts recording bathymetric data to a .wbm file and simultaneously starts grid generation to the database. A recording_status message is output on the status port when the recording status is successfully changed. Usage example:

```
{ "method": "start_recording", "bin_size": 0.0, "database_name":  
"unknown", "record_type": "unknown", "datum": "unknown" }
```

Note: bin_size value shall be 0.0 in case no grid generation is requested. The database_name, record_type and datum parameters are not relevant unless using DCT, therefore “unknown” values can be set.

stop_recording

Stops the recording of bathymetric data and grid generation. A system_status message is output on the status port when the recording status is changed. Usage example:

```
{ "method": "stop_recording" }
```

Starting and then stopping recording will result in a new recording being generated in the %user%\Norbit\WBMS folder.

8 Time Synchronisation

8.1 Subsea Timing Options

For ROV and similar operations, there are three timing options available for timestamping the data produced by the sonar:

1. The same **IRIG-B** timing scheme that is used by surface applications. This requires the timing data to be sent from the SIU, which in turn is being fed by 1PPS & ZDA. This is not normally used for remote operations.
2. **NTP timing** relies on the network to set the NTP clock in the sonar from an accurate source at the dry-end. Various factors rely on this, but it is usually better than 10ms. This is suitable for platforms where there are little dynamics, e.g. an ROV that is moving linearly and not experiencing sudden movements.
3. **PPS & NTP timing** uses the PPS clock, which needs a 1PPS signal to reset the sonar PPS clock once every second. The PPS event is qualified using the NTP clock to set the whole second time. This means that the NTP clock must be accurate to just under 500ms for this to work correctly. This method is better than 1ms accuracy and is therefore suitable for all subsea scenarios.

In the remote situation, unexpected errors may happen:

- Noise causing false 1PPS events. This can be caused by such things as unshielded cables and common signal grounds. Connecting power supply grounds to signal grounds can also generate noise on the signal line.
- Sharing the 1PPS line amongst sensors can load the signal causing the amplitude to decrease. This can lead to missed events or misfiring due to noise.
- NTP updates can be missed due to network traffic and issues with the NTP server, Windows operating systems issues, etc.
- A complete break in network communications with the sonar GUI running topside.

Refer to [Appendix D](#) for more information on available timing methods, including instructions on how to configure NTP time servers.

8.2 WINGHEAD Timing

8.2.1 Prerequisites

- A Single-ended or Balanced signal should be correctly interfaced to the sonar head(s). If long transmission lines are used, the IO configuration may be changed to **Balanced** to switch in the RS422 termination resistor. However, this may load the signal, so it should be tested in Single-ended mode first. If a dual head system is sharing a Balanced signal, only one sonar should have balanced selected (only one termination resistor switched in).
- An NTP server should be set up on a time-synchronised PC on the same subnet as the sonar(s) as described above.
- The NTP time should be closer than 100ms to the 1PPS event, otherwise the time will be invalid.

8.2.2 Configuration

To receive the NTP message on the sonar, access the sonar web UI (<http://192.168.53.XX>, where XX is the last 2 digits of the sonar serial number) and go to the **Time Settings** tab. In the **NTP Servers** field, enter the network IP address of the PC which runs the NTP time server. In a normal, single NTP time source situation, leave the **Preferred** checkbox deselected.




Figure 25. WINGHEAD Timing Inputs

In the **Time Source** drop down menu, select the **NTP only** option, or the correct **NTP+PPS** option according to the polarity of the 1PPS pulse being sent. For the method to take effect, it is necessary to reboot the sonar, which can be performed via the **Maintenance** tab.

If everything is set correctly, the time reported in the GUI will change to the current UTC time. If an error is present, the GUI date/time will be flagged red on the main GUI display with a date of 1970.




Figure 26. GUI showing valid (left) and invalid (right) timing.

If a valid date and time is reported in the GUI, the **Timing Status** in the sonar web UI **Diagnostics** tab will show green with the “**No Error**” message:




Figure 27. Web UI diagnostics reporting No Error.

If an error is detected, it will be described in the **Time Status** field.

8.2.3 PPS Loss

If the 1PPS signal is missing for more than 5 seconds, an error will be flagged, and the GUI time will revert to 1970. The time from this event will be displayed in seconds in the **Time Status** field:




Figure 28. Error associated with PPS loss.

The 1PPS time synchronisation takes a couple of seconds to re-acquire after the signal is restored.

8.2.4 PPS Noise

Noise on the line will result in loss of PPS, which will make the signal look more than 100ms off the NTP time resulting in a signal offset error. It may also cause the loss of the PPS signal, resulting in both an “offset error” and “missing PPS signal”:




Figure 29. Errors associated with PPS noise.

Either way, the signal should be robust and noise free and will be re-acquired after a couple of seconds of “clear” 1PPS pulses.


8.3 WBMS Timing

8.3.1 Configuration

For WBMS sonars, the time source is set in the **Advanced > Options > Timing & Triggering** menu of the GUI. Enter the network IP address of the PC which runs the NTP time server.

After a few seconds, the date and time reported in the NORBIT GUI should change from the invalid time in 1970 (highlighted red in the GUI) to the current UTC date and time (now white). The time should be the same as the broadcasting PC, and the IP address of the sonar should appear in the SNTP server status dialog if Qinsy SNTP is used.

If there is a break in network communications with the topside, the default action is for the GUI to send the configuration parameters, including the Time Source, which would result in a restart of the NTP service causing a jump in the reported time to 1970 for a short period.



If the current Time Source is the same as the one sent by the GUI, it does **NOT** restart the service and there is no interruption to time.

To achieve this, commands must be applied in the sonar startup script facility which is accessed via web UI (<http://192.168.53.XX> where XX is the last two digits of the sonar serial number). If we assume that the IP address of the NTP server is found at the address 192.168.53.150, then:

For “NTP Server” Time source, the script is:

```
set_ntp_server 192.168.53.150
set_time_source 1
```

For “NTP + PPS pos” Time source, the script is:

```
set_ntp_server 192.168.53.150
set_time_source 3
```

For “NTP + PPS neg” Time source, the script is:

```
set_ntp_server 192.168.53.150
set_time_source 4
```

For example, using NTP time as the time source, check **Enable Script**, enter the required script lines from the previous section, click **Submit** and then **Reboot** at the bottom of the page:



Figure 30. Startup Script

Notes:

- This step is only required once and the sonar will then execute it during every boot up.
- If the method of time synchronisation is changed, the `set_time_source` number should be updated accordingly.
- The startup script should always be visible in the sonar web page.
- Following the use of the sonar in an ROV environment, even if the script is not disabled and time is changed from the SIU to, for example, “1PPS & ZDA” (i.e. IRIG-B) the system will still start up OK with the setting from the GUI. There would only be a timing issue if a communications break occurred.
- The behaviour described above is valid from WBMS firmware version 5.5.82 and later.

8.3.2 Invalid Time Reporting

When an error in timing occurs, the sonar date/time will be flagged red on the main GUI display with a date of 1970. The data output will also reflect this invalid time stamp. The accuracy of the internal clock is, however, such that it will drift by up-to approximately 3ms in one minute. The sonar can therefore afford to miss the timing events for short periods and remain within specification.

Once time has been established correctly (i.e. the time noted on the sonar wedge appears white and shows the correct UTC time), the WBMS sonar will behave as follows when a timing event is missed:

- **Bad or missing NTP updates** – the clock will note that an update has not occurred but will wait for 5 minutes before flagging the time as bad (red) in the GUI.
- **Missing 1PPS** – the sonar will note that an update has not occurred but wait for 30 seconds of missing 1PPS events before flagging the time as bad (red) in the GUI.

This allows a robust handling of timing in a less than ideal situation. Note that the behaviour described above is valid as of WBMS firmware version 5.5.82 and later.

8.3.3 Troubleshooting

If the instructions above are executed correctly but the sonar time remains invalid, it may be because:

- The 1PPS pulse does not reach the sonar. This is most likely due to hardware issues.
- The NTP message does not reach the sonar. This could be due to network issues.

In the NORBIT GUI, the **Info** tab within the **Sonar Connection** dialog shows a log of system events. If there is a problem with the time setting service, the log will display a message which includes the text “Time status change” and a corresponding error code. A summary of these codes is provided below. The code is an 8-bit byte constructed as follows:

Bit	7	6	5	4	3	2	1	0
Content	T ₀	PPS Synch	PPS Old			NTP Status		

Table 10. WBMS Error Code

Bit	Description	Comment
7	T ₀ – set when time fails the required criteria	Time will jump to 1970 in the GUI when set.
6	PPS out of sync	PPS not arriving at 1 second interval.
5	PPS old	PPS has not arrived for more than 2 seconds.
4-3	Not used	
2-0	NTP status	See below.

Table 11. WBMS Error Code Summary

2	1	0	
0	0	0	OK
0	0	1	No data from server
0	1	0	Parse Error
0	1	1	NTP Timeout from server
1	0	0	NTP Synch offset too large
1	0	1	NTP update too old

Table 12. WBMS NTP Error Code Status Summary

Code	Description
0	OK
1	NTP log is empty, no peer message has been received since last NTP startup.
2	Could not parse NTP log. Garbled NTP log.
3	Timeout when trying to communicate with NTP server.
4	NTP out of sync. Offset to server is more than 10ms.
5	More than 5 minutes since last NTP update.
32	NTP is in sync, PPS missing.
64	PPS Out of sync.
160	Time is bad, PPS is missing.

Table 13. Example NTP Error Codes reported in the GUI **Info** tab

8.4 General Timing Issues

8.4.1 PPS Issues

- If the 1PPS is wired but is not detected by the time synchronisation, check that the wiring is correct for the signal type, i.e. single ended or balanced (applicable for WINGHEAD only).
- If the signal is shared amongst other sensors, the level might be loaded below a detection threshold. In the case of the WINGHEAD, check the signal type is switched to Single-ended in the web UI IO line configuration tab. For test purposes, unplug some of the sharing sensors to decrease the loading.
- Check the 1PPS signal using an oscilloscope. An RS422 signal should use dual channel differential input and a TTL/RS232 signal should use a single channel input with ground.
- If the 1PPS+NTP time synchronisation is not working, first check that NTP only works before proceeding with additional troubleshooting.

8.4.2 NTP Issues

- Remember that the NTP server must be on the same subnet as the sonar and the Windows time service must be disabled.
- Meinberg takes several minutes to become active from PC reboot or service restart.
- The PC should be time synchronised to the master time source. Roughly setting the clock is not sufficient. The use of the 1PPS signal should be used to aid PC synchronisation (i.e. PPS box for Qinsy and HYPACK, and handshake line toggling for PDS.)
- NTP time occurs on port 123, so this port should not be blocked.
- Ship networks and switches should be avoided as they can lead to complications.
- The IP address of the PC which runs the NTP server should be entered in the sonar configuration and not the IP address of the sonar itself.
- For test purposes, try NTP only using a different PC in case there is some machine-specific issue.

Appendix A: Sonar Head Signal Input

A1. WINGHEAD Signal Input

The WINGHEAD sonar has two serial inputs:

1. **Synchronisation and Miscellaneous Communications** – this is normally used for dual head synchronisation between two WINGHEAD sonars, however it can also be used as a “back door” input for troubleshooting.
2. **Time Synchronisation** – normally used to receive an IRIG-B time message from a SIU, however in the case of an ROV installation this is changed to accept a 1PPS input with the pulse being qualified by a NTP time synch.

The input circuitry is as follows:




Figure 31. Input Circuitry

These inputs have two options and have limits of -15v/+15v.

- **“Balanced”** RS422 using 2 wire half duplex communications. This is noise tolerant differential signalling.
- **“Single-Ended”** nominally TTL using signal and ground connections. This is more traditional to be compatible with existing ROV-type infrastructure. It should be noted that this is available on 24-pin variants only and typically accept a 5v/3v3 TTL input.



NOTE: There is a selectable 120Ω termination resistor across the input of the transceiver which can be used for RS422 communications. This is selectable in the **IO configuration** menu of the sonar web UI, using **“Balanced”** mode. Selecting **“Single-ended”** deselects this termination resistor.

Signal Driver Type – the 1PPS input should be a Source type driver that can maintain the voltage swing. It has been found that Sink drivers will not work well in this application.

Dual Head – it is common practice to share a 1PPS source from a MUX, so in a dual head installation the load to the source could be as shown in the following diagram.




Figure 32. Dual Head

It is therefore important to check the **loaded** signal with an oscilloscope for

- **Noise** – Is there noise on the signal that may cause false triggering?
- **Level** – Is the signal level sufficient to trigger the input?

The **Single-Ended** input can be driven from a TTL or RS232 output, however the same considerations to the input for RS232 should be noted as shown in the WBMS section, i.e. note instances where the pulse polarity is swapped through RS232 coding and set the detection in the sonar software accordingly. The input can accept a minimum voltage transition window between 0v and 3v3.

The **Balanced** input can be driven by RS422/485 and has been tested with RS232. With RS232 GND connected to RS422-, the same considerations to the input for RS232 inversion through coding should be noted as shown in the WBMS section. Alternatively, if the signal is inverted through coding, the signals can be swapped, i.e. RS232 GND is connected to RS422+ and RS232 signal is connected to RS422-, and the input to the WINGHEAD will be the same polarity as the pulse from the source.

The differential input requires that the difference between A&B is >200mv, however there is inline protection for each line which will slightly reduce the voltage available. The difference window should be around 0.6v without the termination resistor enabled, and 1v with the resistor enabled. Additionally, any noise will lead to phantom switching, therefore a window of 2v is recommended. A&B voltages should not exceed +/-15v, and if they do, a series 220Ω resistor should be used.

If RS232 is to be used, then the voltage limits should be respected (-15v/+15v). If they exceed these limits, again a series 220Ω resistor must be used, or in-line breakers may activate temporarily stopping inputs. With this scheme, NORBIT does not recommend that the voltage exceed +/-24v.

A2. WBMS Signal Input

The WBMS sonar has two serial inputs:

1. **Synchronisation and Miscellaneous Communications** – RS232 with TX/RX w.r.t a common signal ground. This is normally used for dual head synchronisation between two WBMS sonars. However, it can also be used as a “back door” input for troubleshooting. In later firmware versions it will also accept a ZDA time message.
2. **Time Synchronisation** – TTL with RX only w.r.t a common signal ground. This is normally used to receive an IRIG-B time message from an SIU. However, in the case of an ROV installation, this is changed to accept a 1PPS input with the pulse being qualified by a NTP time synchronisation.

The RS232 channel is normally used for inter-sonar handshakes (other than in the situation described above), however the TTL Time input is interfaced extensively for ROV and similar applications where the TTL input accepts a 1PPS pulse, usually via a MUX.

The circuit for the Time input uses a RS485 transceiver and is set up as follows:




Figure 33. Time Input Circuit

The system is designed to accept 5v/3v3 TTL (after loading) and the inputs to the device have limits of -8v/+15v. This means RS232 levels can also be used. However, the voltage limits should be respected. If they exceed these limits, a series 220Ω resistor must be used.

Signal Driver Type – the 1PPS input should be a **Source** type driver that can maintain the voltage swing. It has been found that Sink drivers will not work well in this application.

Dual Head – it is common practice to share a 1PPS source from a MUX. Therefore, in dual head installations, the load to the 1PPS source could be as shown in the following diagram.




Figure 34. Dual Head

It is therefore important to check the **loaded** signal with an oscilloscope for:

- **Noise** – Is there noise on the signal that may cause false triggering?
- **Level** – Is the signal level sufficient to trigger the input?

Appendix B: RS232 Considerations

RS232 works by switching between +ve and -ve voltages with respect to a common ground. It is coded as follows: **Logic 0 is +ve voltage, Logic 1 is -ve voltage**

Usually, a PPS pulse is available as a TTL or similar pulse. Some Multiplexors can accept TTL topside and output RS232 at the wet end (or other signal combinations). Additionally, users can convert the signal to RS232 from TTL before inputting to the topside. The following possibilities then exist:

1. TTL input topside with serial channel configured RS232 IO topside & RS232 IO wet-end.
2. The TTL pulse is converted to RS232 topside and input to the MUX with the serial channel configured RS232 IO topside & RS232 IO wet-end.
3. The TTL input topside with the MUX serial channel configured TTL topside and RS232 wet-end.

If options 2 or 3 are used, the signal is effectively inverted. Therefore, for a +ve 1PPS pulse input the scenario is as follows:




Figure 35. PPS pulse input topside from a timing source and resulting RS232 waveform from the MUX.

The Trigger direction of the event should be set accordingly in the **Timing and Triggering** setup for WBMS sonars, and for WINGHEAD sonars should be set in the **Time** settings tab in the sonar web UI. For scenarios 2 & 3 above where the polarity is reversed:

- For a +ve 1PPS pulse input and a RS232 pulse presented to the sonar, the Sonar Timing Configuration should be set to NTP&PPS neg
- For a -ve 1PPS pulse input and a RS232 pulse presented to the sonar, the Sonar Timing Configuration should be set to NTP&PPS pos




Figure 36. WBMS timing/trigger for +ve (left) and -ve (centre) topside input pulses; WINGHEAD inputs (right)

If the pulse is inverted and the trigger is set incorrectly, the time of the sonar will be incorrect by the width of the pulse. This is insignificant if the pulse width is <1ms, however if it is greater than that, there may be an impact on the multibeam data, especially in dynamic conditions.

For this reason, using wide 1PPS pulses (is discouraged in **ANY** scenario and a maximum of 1ms should be selected if possible. The pulse should also not be set too narrow as this has implications with rise time in some situations (0.5ms is a good compromise).

Appendix C: Integration Guides

C1. RTS Gen5 Quick Start



Rental Technology & Services AS
Devoted to Solutions

RTS GEN 5 MUX MkII

Quick Reference Guide 3000TI-Norbit

- Depth rating: 3000 meter
- Optical fiber range 10km, optional 70km for single mode fiber
- 16 channel C-WDM, 1271nm-1611nm
- 8 channels RS-232 fully isolated
- One channel RS-422 fully isolated
- One channel RS-485 fully isolated
- Four channel 10/100Mbit Ethernet

- PPS Timing pulse available subsea for CH6 and INS Ethernet
- PPS Timing pulse available subsea for CH12a and CH12b
- HD/SD video (optional)
- 14 configurable Relay outputs (24Vdc/48vdc)
- Two channel AC relay output 110VAC
- Small size, and a highly flexible modular system

RTS MUX GEN 5 Topside Unit




Power Requirement Topside unit: 100W max
Voltage requirement: 90-264VAC or 120-370VDC
Operating ambient Temperature: -15°C to +45°C
Weight: 8.5kg ± 1.0kg
Size: 134mm x 374mm x 483mm [HxDxW]
19" panel and 3U height

RTS MUX GEN 5 Subsea Unit



Power requirement Subsea unit: 800W max.
(AC output relays OFF)
Voltage requirement: 90-264VAC or 120-370VDC
Operating ambient temperature: -2°C to +35°C
Weight in air: 32 kg ± 2.0 kg
Weight in water: 15 kg ± 2.0 kg
Size: 435mm x Ø 230mm




Block schematic RTS MUX GEN 5 system.

Rental Technology & Services AS
tel: +47 52 81 47 60
e-mail: sales@rts.as

Aakrehamn Teknologisenter
Sjøenveien 52
NO-4270 Åkrehamn NORWAY





Connections on subsea bottle cap



Back panel RTS MUX GEN 5 Topside unit.





NOTES:

1. CH10b in the GEN 5 MUX equipped with INS Ethernet is fitted only with Power function.
2. Video 1-4 currently not in use. (Optional SDI or Composite Video)
3. OPT1/OPT2 currently not in use.
4. USB is currently not in use.
5. Remote option is currently not in use.








Specifications subject to change without further notice.

RTS GEN 5 MUX: TOPSIDE CONNECTORS

MUX GEN5 INS_ETH REV 1.79 Norbit
Date 08.02.2019

LABEL	FUNCTION	BULKHEAD	PINOUT																												
CH1 CH2 CH3 CH4 CH5 CH6 CH7 CH8	GENERAL PORT RS232	DB-9 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>NC</td><td>7</td><td>NC</td></tr><tr><td>2</td><td>RX Data Down</td><td>8</td><td>NC</td></tr><tr><td>3</td><td>TX Data Up</td><td>9</td><td>NC</td></tr><tr><td>4</td><td>NC</td><td></td><td></td></tr><tr><td>5</td><td>SerGND</td><td></td><td></td></tr><tr><td>6</td><td>NC</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	NC	7	NC	2	RX Data Down	8	NC	3	TX Data Up	9	NC	4	NC			5	SerGND			6	NC		
PIN	Function	PIN	Function																												
1	NC	7	NC																												
2	RX Data Down	8	NC																												
3	TX Data Up	9	NC																												
4	NC																														
5	SerGND																														
6	NC																														
CH9a	GENERAL PORT RS422	DB-9 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>NC</td><td>7</td><td>RX+ Data Down</td></tr><tr><td>2</td><td>NC</td><td>8</td><td>TX+ Data Up</td></tr><tr><td>3</td><td>NC</td><td>9</td><td>TX- Data Up</td></tr><tr><td>4</td><td>NC</td><td></td><td></td></tr><tr><td>5</td><td>Signal GND</td><td></td><td></td></tr><tr><td>6</td><td>RX- Data Down</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	NC	7	RX+ Data Down	2	NC	8	TX+ Data Up	3	NC	9	TX- Data Up	4	NC			5	Signal GND			6	RX- Data Down		
PIN	Function	PIN	Function																												
1	NC	7	RX+ Data Down																												
2	NC	8	TX+ Data Up																												
3	NC	9	TX- Data Up																												
4	NC																														
5	Signal GND																														
6	RX- Data Down																														
CH9b	GENERAL PORT RS485	DB-9 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>NC</td><td>7</td><td>Data +</td></tr><tr><td>2</td><td>NC</td><td>8</td><td>NC</td></tr><tr><td>3</td><td>NC</td><td>9</td><td>NC</td></tr><tr><td>4</td><td>NC</td><td></td><td></td></tr><tr><td>5</td><td>Signal GND</td><td></td><td></td></tr><tr><td>6</td><td>Data -</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	NC	7	Data +	2	NC	8	NC	3	NC	9	NC	4	NC			5	Signal GND			6	Data -		
PIN	Function	PIN	Function																												
1	NC	7	Data +																												
2	NC	8	NC																												
3	NC	9	NC																												
4	NC																														
5	Signal GND																														
6	Data -																														
CH10a CH11	GENERAL PORT ETHERNET	RJ45 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>TXD+ WHITE/ORANGE</td><td>7</td><td>NC</td></tr><tr><td>2</td><td>TXD- ORANGE</td><td>8</td><td>NC</td></tr><tr><td>3</td><td>RXD+ WHITE/GREEN</td><td></td><td></td></tr><tr><td>4</td><td>NC</td><td></td><td></td></tr><tr><td>5</td><td>NC</td><td></td><td></td></tr><tr><td>6</td><td>RXD- GREEN</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	TXD+ WHITE/ORANGE	7	NC	2	TXD- ORANGE	8	NC	3	RXD+ WHITE/GREEN			4	NC			5	NC			6	RXD- GREEN		
PIN	Function	PIN	Function																												
1	TXD+ WHITE/ORANGE	7	NC																												
2	TXD- ORANGE	8	NC																												
3	RXD+ WHITE/GREEN																														
4	NC																														
5	NC																														
6	RXD- GREEN																														
CH11 (Repeater)	GENERAL PORT RS232	DB-9 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>NC</td><td>7</td><td>NC</td></tr><tr><td>2</td><td>RX Data Down</td><td>8</td><td>NC</td></tr><tr><td>3</td><td>TX Data Up</td><td>9</td><td>NC</td></tr><tr><td>4</td><td>NC</td><td></td><td></td></tr><tr><td>5</td><td>SerGND</td><td></td><td></td></tr><tr><td>6</td><td>NC</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	NC	7	NC	2	RX Data Down	8	NC	3	TX Data Up	9	NC	4	NC			5	SerGND			6	NC		
PIN	Function	PIN	Function																												
1	NC	7	NC																												
2	RX Data Down	8	NC																												
3	TX Data Up	9	NC																												
4	NC																														
5	SerGND																														
6	NC																														
CH12a CH12b	NORBIT	RJ45 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>BiDiA+ WHITE/GREEN</td><td>7</td><td>BiDiD+ WHITE/BROWN</td></tr><tr><td>2</td><td>BiDiA- GREEN</td><td>8</td><td>BiDiD- BROWN</td></tr><tr><td>3</td><td>BiDiB+ WHITE/ORANGE</td><td></td><td></td></tr><tr><td>4</td><td>BiDiC+ BLUE</td><td></td><td></td></tr><tr><td>5</td><td>BiDiC- WHITE/BLUE</td><td></td><td></td></tr><tr><td>6</td><td>BiDiB- ORANGE</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	BiDiA+ WHITE/GREEN	7	BiDiD+ WHITE/BROWN	2	BiDiA- GREEN	8	BiDiD- BROWN	3	BiDiB+ WHITE/ORANGE			4	BiDiC+ BLUE			5	BiDiC- WHITE/BLUE			6	BiDiB- ORANGE		
PIN	Function	PIN	Function																												
1	BiDiA+ WHITE/GREEN	7	BiDiD+ WHITE/BROWN																												
2	BiDiA- GREEN	8	BiDiD- BROWN																												
3	BiDiB+ WHITE/ORANGE																														
4	BiDiC+ BLUE																														
5	BiDiC- WHITE/BLUE																														
6	BiDiB- ORANGE																														
PULSE INPUT PPS INPUT	PULSE	BNC 	<table><tr><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>GND</td></tr><tr><td>2</td><td>+5V</td></tr></table>	PIN	Function	1	GND	2	+5V																						
PIN	Function																														
1	GND																														
2	+5V																														
POWER	POWER 110VAC	C14 	<table><tr><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>VAC 110V L</td></tr><tr><td>2</td><td>VAC 110V H</td></tr><tr><td>3</td><td>GND</td></tr></table>	PIN	Function	1	VAC 110V L	2	VAC 110V H	3	GND																				
PIN	Function																														
1	VAC 110V L																														
2	VAC 110V H																														
3	GND																														


RTS GEN 5 MUX: SUBSEA CONNECTORS

LABEL	FUNCTION	BULKHEAD	PINOUT																																
CH1 CH2 CH3 CH4	GENERAL PORT RS232	MCBH-6-F 	<table><tr><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>+24V</td></tr><tr><td>2</td><td>GND</td></tr><tr><td>3</td><td>TX Data Down</td></tr><tr><td>4</td><td>RX Data Up</td></tr><tr><td>5</td><td>SerGND</td></tr><tr><td>6</td><td>NC</td></tr></table>	PIN	Function	1	+24V	2	GND	3	TX Data Down	4	RX Data Up	5	SerGND	6	NC																		
PIN	Function																																		
1	+24V																																		
2	GND																																		
3	TX Data Down																																		
4	RX Data Up																																		
5	SerGND																																		
6	NC																																		
CH5 CH6	GENERAL PORT RS232	MCBH-6-F 	<table><tr><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>+24V</td></tr><tr><td>2</td><td>GND</td></tr><tr><td>3</td><td>TX Data Down</td></tr><tr><td>4</td><td>RX Data Up</td></tr><tr><td>5</td><td>SerGND</td></tr><tr><td>6</td><td>NC</td></tr></table>	PIN	Function	1	+24V	2	GND	3	TX Data Down	4	RX Data Up	5	SerGND	6	NC																		
PIN	Function																																		
1	+24V																																		
2	GND																																		
3	TX Data Down																																		
4	RX Data Up																																		
5	SerGND																																		
6	NC																																		
CH7 CH8	AC SUPPLY PORT RS232	MCBH-6-F SPECIAL 	<table><tr><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>Mech GND</td></tr><tr><td>2</td><td>AC 110/240V L</td></tr><tr><td>3</td><td>TX Data Down</td></tr><tr><td>4</td><td>RX Data Up</td></tr><tr><td>5</td><td>SerGND</td></tr><tr><td>6</td><td>AC 110/240V N</td></tr></table>	PIN	Function	1	Mech GND	2	AC 110/240V L	3	TX Data Down	4	RX Data Up	5	SerGND	6	AC 110/240V N																		
PIN	Function																																		
1	Mech GND																																		
2	AC 110/240V L																																		
3	TX Data Down																																		
4	RX Data Up																																		
5	SerGND																																		
6	AC 110/240V N																																		
Note: Special Modified Seacon MCBH-6-F Modified Penetrator AC power output voltage is depending on AC main supply (power input)																																			
CH9a CH9b	GENERAL PORT RS422 RS485	MCBH-6-F 	<table><tr><th>PIN</th><th>Function Channel 9a RS422</th><th>PIN</th><th>Function Channel 9b RS485</th></tr><tr><td>1</td><td>+24V</td><td>1</td><td>+24V</td></tr><tr><td>2</td><td>GND</td><td>2</td><td>GND</td></tr><tr><td>3</td><td>RX- Data Up</td><td>3</td><td>Data +</td></tr><tr><td>4</td><td>RX+ Data Up</td><td>4</td><td>Data -</td></tr><tr><td>5</td><td>TX+ Data Down</td><td>5</td><td>NC</td></tr><tr><td>6</td><td>TX- Data Down</td><td>6</td><td>NC</td></tr></table>	PIN	Function Channel 9a RS422	PIN	Function Channel 9b RS485	1	+24V	1	+24V	2	GND	2	GND	3	RX- Data Up	3	Data +	4	RX+ Data Up	4	Data -	5	TX+ Data Down	5	NC	6	TX- Data Down	6	NC				
PIN	Function Channel 9a RS422	PIN	Function Channel 9b RS485																																
1	+24V	1	+24V																																
2	GND	2	GND																																
3	RX- Data Up	3	Data +																																
4	RX+ Data Up	4	Data -																																
5	TX+ Data Down	5	NC																																
6	TX- Data Down	6	NC																																
CH10a	GENERAL PORT ETHERNET	MCBH-8-F 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>+24V</td><td>7</td><td>GND</td></tr><tr><td>2</td><td>GND</td><td>8</td><td>+48V</td></tr><tr><td>3</td><td>TXD+ WHITE/ORANGE</td><td></td><td></td></tr><tr><td>4</td><td>TXD- ORANGE</td><td></td><td></td></tr><tr><td>5</td><td>RXD+ WHITE/GREEN</td><td></td><td></td></tr><tr><td>6</td><td>RXD- GREEN</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	+24V	7	GND	2	GND	8	+48V	3	TXD+ WHITE/ORANGE			4	TXD- ORANGE			5	RXD+ WHITE/GREEN			6	RXD- GREEN						
PIN	Function	PIN	Function																																
1	+24V	7	GND																																
2	GND	8	+48V																																
3	TXD+ WHITE/ORANGE																																		
4	TXD- ORANGE																																		
5	RXD+ WHITE/GREEN																																		
6	RXD- GREEN																																		
CH11	PHINS Ethernet	5506-2013 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>GND PPS & SerGND</td><td>8</td><td>RS232 Repeater RX</td></tr><tr><td>2</td><td>PPS OUT, TTL 5V</td><td>9</td><td>Vout INS: +24VDC</td></tr><tr><td>3</td><td>Eth TXD+ WHITE/ORANGE</td><td>10</td><td>Vout INS: GND</td></tr><tr><td>4</td><td>Eth TXD- ORANGE</td><td>11</td><td>NC</td></tr><tr><td>5</td><td>Eth RXD+ WHITE/GREEN</td><td>12</td><td>Vout EXTSNS: GND</td></tr><tr><td>6</td><td>Eth RXD- GREEN</td><td>13</td><td>Vout EXTSNS: +24VDC</td></tr><tr><td>7</td><td>RS232 Repeater TX</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	GND PPS & SerGND	8	RS232 Repeater RX	2	PPS OUT, TTL 5V	9	Vout INS: +24VDC	3	Eth TXD+ WHITE/ORANGE	10	Vout INS: GND	4	Eth TXD- ORANGE	11	NC	5	Eth RXD+ WHITE/GREEN	12	Vout EXTSNS: GND	6	Eth RXD- GREEN	13	Vout EXTSNS: +24VDC	7	RS232 Repeater TX		
PIN	Function	PIN	Function																																
1	GND PPS & SerGND	8	RS232 Repeater RX																																
2	PPS OUT, TTL 5V	9	Vout INS: +24VDC																																
3	Eth TXD+ WHITE/ORANGE	10	Vout INS: GND																																
4	Eth TXD- ORANGE	11	NC																																
5	Eth RXD+ WHITE/GREEN	12	Vout EXTSNS: GND																																
6	Eth RXD- GREEN	13	Vout EXTSNS: +24VDC																																
7	RS232 Repeater TX																																		
CH12a CH12b	NORBIT	5506-2013 	<table><tr><th>PIN</th><th>Function</th><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>Trigger IN</td><td>8</td><td>Pulse(PPS) GND</td></tr><tr><td>2</td><td>Trigger OUT</td><td>9</td><td>Vout 1: +24VDC(Optional)</td></tr><tr><td>3</td><td>Ethernet Tx+ (White/Orange)</td><td>10</td><td>Vout 1: GND(Optional)</td></tr><tr><td>4</td><td>Ethernet Tx- (Orange)</td><td>11</td><td>Vout 2: +48VDC(Standard)</td></tr><tr><td>5</td><td>Ethernet Rx+ (White/Green)</td><td>12</td><td>Vout 2: GND(Standard)</td></tr><tr><td>6</td><td>Ethernet Rx- (Green)</td><td>13</td><td>NC</td></tr><tr><td>7</td><td>Pulse(PPS) Signal</td><td></td><td></td></tr></table>	PIN	Function	PIN	Function	1	Trigger IN	8	Pulse(PPS) GND	2	Trigger OUT	9	Vout 1: +24VDC(Optional)	3	Ethernet Tx+ (White/Orange)	10	Vout 1: GND(Optional)	4	Ethernet Tx- (Orange)	11	Vout 2: +48VDC(Standard)	5	Ethernet Rx+ (White/Green)	12	Vout 2: GND(Standard)	6	Ethernet Rx- (Green)	13	NC	7	Pulse(PPS) Signal		
PIN	Function	PIN	Function																																
1	Trigger IN	8	Pulse(PPS) GND																																
2	Trigger OUT	9	Vout 1: +24VDC(Optional)																																
3	Ethernet Tx+ (White/Orange)	10	Vout 1: GND(Optional)																																
4	Ethernet Tx- (Orange)	11	Vout 2: +48VDC(Standard)																																
5	Ethernet Rx+ (White/Green)	12	Vout 2: GND(Standard)																																
6	Ethernet Rx- (Green)	13	NC																																
7	Pulse(PPS) Signal																																		
POWER	POWER 110VAC	5506-2003 	<table><tr><th>PIN</th><th>Function</th></tr><tr><td>1</td><td>VAC 110V L</td></tr><tr><td>2</td><td>VAC 110V H</td></tr><tr><td>3</td><td>Mech GND</td></tr></table>	PIN	Function	1	VAC 110V L	2	VAC 110V H	3	Mech GND																								
PIN	Function																																		
1	VAC 110V L																																		
2	VAC 110V H																																		
3	Mech GND																																		

Note: Special Modified
Seacon MCBH-6-F
Modified Penetrator


AC power output
voltage is depending
on AC main supply
(power input)

RTS Gen5 NORBIT MOD




C2. ROV Integration Example with WBMS & ROVINS

Interfacing Scheme for Dual Head WBMS, iXblue ROVINS and RDI DVL



To configure the DVL for low latency triggering, set the `CX` command to enable the trigger input by sending `CX1`. Start the DVL pinging with the `CS` command. The DVL will then wait for a trigger before each ping. Setting the RS-485 lines to a break state for not less than 10 microseconds sends the trigger. The DVL will then ping within 250 microseconds of the leading edge of the break pulse (see also RDI document FSA-018: "Triggering a DVL with a TTL signal").

WBMS Bulkhead Pinout




Pin	WBMS Function	Cable
1	Tx +	Black (red pair)
2	Tx -	Red
3	Rx +	Black (blue pair)
4	Rx -	Blue
5	RS232 Tx/Trig Out	Black (green pair)
6	RS232 Rx/Trig In	Green
7	IRIG-B	Black (white pair)
8	Signal GND	White
9	PWR GND	Black 0,5mm ²
10	PWR +24V	White, 0.5mm ²

NORBIT WBMS Configuration


In dual head mode, the secondary WBMS head is configured automatically by the GUI to use external trigger from the primary head, which allows correct synchronisation. However, the user must ensure the proper electrical connections.

For subsea installations, the 1PPS+NTP scheme must be used to achieve the best timing accuracy. If the 1PPS is not available, the NTP alone can be used with limited timing accuracy. The timing is set in the NORBIT GUI and is sent to both sonar heads.



Interfacing to ixBlue ROVINS and RDI DVL

To slave the DVL to the multibeam, the best method is to supply a pulse on pins 24 (+) and 25 (-) of the central connector on the ROVINS.



Central Connector




Diagram of Port X
(X being C, D or E) Connector

Pin	Signal	Pin	Signal
1	System Power In (+24 V)	14	Port A: RS422 RX(+)(B)
2	System Power In GND (0/24v)	15	Repeater: RS422 RX(-)(A)/RS232 RX(+)
3	Ext Sensor 1 In (+V1)	16	Repeater: RS422 RX(+)(B)
4	Ext Sensor 1 In GND (0/+V1 V)	17	Port B: RS422 TX(+)(B)/RS232 TX(+)
5	Repeater: GND_R	18	Port B: RS422 TX(-)(A)
6	Ext Sensor 2 In (+V2)	19	Pulse A: OUT TTL
7	Ext Sensor 2 In GND (0/+V2)	20	Pulse A: IN TTL
8	Port A: GND_A	21	Pulse A: GND_A
9	Repeater: RS422 TX(+)(B)/RS232 TX(+)	22	Port B: RS422 RX(-)(A)/RS232 RX(+)
10	Repeater: RS422 TX(-)(A)	23	Port B: RS422 RX(+)(B)
11	Port A: RS422 TX(+)(B)/RS232 TX(+)	24	Ext Pulse IN +
12	Port A: RS422 TX(-)(A)	25	Ext Pulse IN -
13	Port A: RS422 RX(-)(A)/RS232 RX(+)	26	Port B: GND_B

Pin	Signal
1	Ext Sensor 1 Out (+V1)
2	Ext Sensor 1 Out GND (0/+V1 V)
3	Ext Sensor 2 Out (+V2)
4	Ext Sensor 2 Out GND (0/+V2 V)
5	Port X: RS422 TX(+)(B)/RS232 TX(+)
6	Port X: RS422 TX(-)(A)
7	Port X: RS422 RX(-)(A)/RS232 TX(+)
8	Port X: RS422 RX(+)(B)
9	Ext Pulse OUT +
10	Ext Pulse OUT -
11	Port X: GND_X
12	Reserved except if X=C : Pulse C: IN TTL

Then, on the connector which goes to the DVL (port C, D or E) on the ROVINS, the pulse will be available on Pin 9 (+) and 10 (-).

Sample TTL to RS422 Converter from B&B



C3. Innova Matrix 2+ Quick Start

Wet-end summary and channel list taken from manufacturers manual (MAN-000015294_R7):

- Dimensions: L=584mm, Ø=220 mm (Ø=210mm in centre)
- Depth rating: 5000 m
- Supply voltage: 85-260VAC, 50-60Hz
- 120-370VDC
- Maximum power consumption: 1200W
- Minimum power consumption: 150W
- Recommended fuse: 16A (@110VAC)
- Maximum inrush current: 40A (@265VRMS, Cold start)
- Housing material: Titanium grade 5
- Weight in air: 35 kg
- Weight in water: 13 kg




Multiple channels are available. C1, C2 and C3 are normally used for multibeam sensor interfacing.

Identifier	Connector Type	Signals	Power
C1	5506-2021-E	• Ethernet (1 Gbps) • PECL (optional)	• 24VDC (6A) • 48VDC (6A) Software switchable
C2	5506-2021-E	• Ethernet (1 Gbps) • PECL (optional)	• 24VDC (6A) • 48VDC (6A) Software switchable
C3	5506-2021-E	• Ethernet (2x 100Mbps) • PECL (optional) • RS232/RS485 • 5V TTL (PPS)	• 24VDC (6A) • 48VDC (3A) Hardware switchable. 24VDC is standard.
C4	MINL-5515-75Ω 5506-1508 (Optional)	• HD-SDI • Analog Video (optional) • RS232	• 24VDC (2A)
C5	MINL-5515-75Ω 5506-1508 (Optional)	• HD-SDI • Analog Video (optional) • RS232	• 24VDC (2A)
C6	MINL-5515-75Ω 5506-1508 (Optional)	• HD-SDI • Analog Video (optional) • RS232	• 24VDC (2A)
C7	MCBH8F	• RS232	• 24VDC (2A)
C8	MCBH8F	• RS232	• 24VDC (2A)
C9	MCBH8F	• Ethernet (100Mbps) • TTL (Same as C10)	• 24VDC (2A)
C10	MCBH8F	• RS232 • TTL (Same as C9)	• 24VDC (2A)
C11	MCBH8F	• RS232/RS485	• 24VDC (2A)
C12	MCBH6F	• RS232	• 110/230VAC (Depending on input power) (3.15A)
C13	MCBH8F	• RS232/RS485	• 24VDC (2A)

Connectors C1 & C2

- 24v or 48v DC max 6A selectable in software.
- 100Mbit or 1Gbit **independent** ethernet communications selectable from the topside.
- RS232 communications.
- Synchronisation loop back between the two connectors for a dual head synchronisation connection, so no flying lead required for this function. They connect C1-20 to C2-20 & C1-21 to C2-21.



5506-2021			
PIN	FUNCTION	PIN	FUNCTION
1	Eth, BiDir B-	12	N/C
2	Eth, BiDir B+	13	Eth, BiDir C+
3	N/C	14	Eth, BiDir C-
4	Eth, BiDir D-	15	RS232 0V
5	Eth, BiDir D+	16	RS232 Tx (Downlink)
6	48VDC	17	RS232 Rx (Uplink)
7	0V	18	N/C (PECL Screen)
8	24VDC	19	N/C (PECL Signal)
9	NC	20	Sync -
10	Eth, BiDir A-	21	Sync +
11	Eth, BiDir A+		

Figure 37. C1 & C2 Wet-End Connections (from MAN-000015294_R7)

RS232 Interface		Ethernet Interface			PECL (75 Ω) Interface	
RJ-45 (1)		RJ-45(C1)			BNC(C1)	
Pin	Function	Pin	Function	Color	Pin	Function
1	N/C	1	Eth, BiDir A+	White/Orange	Screen	PECL Screen
2	N/C	2	Eth, BiDir A-	Orange	Center	PECL Signal
3	N/C	3	Eth, BiDir B+	White/Green		
4	RS232 - 0V	4	Eth, BiDir C+	Blue		
5	RS232 – RX (Downlink)	5	Eth, BiDir C-	White/Blue		
6	RS232 – TX (Uplink)	6	Eth, BiDir B-	Green		
7	N/C	7	Eth, BiDir D+	White/Brown		
8	N/C	8	Eth, BiDir D-	Brown		

Figure 38. C1 & C2 Topside Connections (from MAN-000015294_R7)

The 18-pin variant of the WINGHEAD does not have Gigabit or single-ended 1PPS input capability, therefore it is better used on C3. If 1PPS input is not being employed, it could be used on this connector with 100Mbit communications.

If the communications are set to 100Mbit, the connector can be used with the WBMS. The wiring below is only a suggestion, and users should test the wiring before committing to moulding cables for installations.

C1/2 Pin	C1/2 Function	24-Pin WINGHEAD		10-Pin WBMS	
		Pin	Function	Pin	Function
1	Eth, BiDir B-	5	ETH_B-	4	LAN RX-
2	Eth, BiDir B+	6	ETH_B+	3	LAN RX+
3	NC				
4	Eth, BiDir D-	20	ETH_D-		
5	Eth, BiDir D+	19	ETH_D+		
6	48vDC				
7	0v	7 & 4	Power GND	9	Power GND
8	24vDC	18 & 21	24-48vDC	10	24vDC
9	NC				
10	Eth, BiDir A-	13	ETH_A-	2	LAN TX-
11	Eth, BiDir A+	8	ETH_A+	1	LAN TX+
12	NC				
13	Eth, BiDir C+	17	ETH_C+		
14	Eth, BiDir C-	12	ETH_C-		
15	RS232 0v	3	Time_GND	8	Signal GND
16	RS232 TX (Dn)	1	Time+	7	PPS
17	RS232 RX (Up)				
18	NC				
19	NC				
20	Sync -	23	Trig-	8	Signal GND
21	Sync +	24	Trig+	5 or 6*	Trig out OR Trig in

Table 14. C1 or C2 Connections to 24-pin WINGHEAD

*If using a dual head WBMS setup, it is necessary to make one cable with connection to sonar head RS232 Trigger out and one to RS232 Trigger in. For example, if we make C1 connected to the Primary sonar, then pin 5 from this sonar will go to pin 21 of the MUX connector, and for the secondary sonar, pin 6 will connect to pin 21 of the MUX connector.




Figure 39. Setup Using C1 & C2

Connector C3

- Hardware selectable 24v or 48v DC. Max 6A selectable in software.
- Dual 100Mbit ethernet communications connected to a gigabit switch and output from a single gigabit connection topside. See Figure 40 below.
- RS232/RS485 communications.
- Open collector Trigger downlink.




Figure 40. C3 Network Configuration at the wet-end




Figure 41. C3 Wet-End Connections (from MAN-000015294_R7)

Serial Interface		Ethernet Interface			TTL Interface	
RJ-45 (3 - Top)		RJ-45(C3)			RJ-45 (3 - Bottom)	
Pin	Function	Pin	Function	Color	Pin	Function
1	N/C	1	Eth, BiDir A+	White/Orange	1	TTL – 5V
2	RS485 +	2	Eth, BiDir A-	Orange	2	N/C
3	RS485 -	3	Eth, BiDir B+	White/Green	3	N/C
4	Serial - 0V	4	Eth, BiDir C+	Blue	4	N/C
5	RS232 – RX (Downlink)	5	Eth, BiDir C-	White/Blue	5	N/C
6	RS232 – TX (Uplink)	6	Eth, BiDir B-	Green	6	N/C
7	N/C	7	Eth, BiDir D+	White/Brown	7	N/C
8	N/C	8	Eth, BiDir D-	Brown	8	TTL – 0V

Figure 42. C3 Topside Connections (from MAN-000015294_R7)

Connections to one head use 4-wire ethernet, 24vDC (or 48v optional for WINGHEAD) and a 1PPS pulse downlink using one of 3 methods:

- **RS485 (Blue)** – The communications transceivers have been designed using a RS485 hardware and the system has been tested with this.
- **RS232 (Green)** – The communications transceivers can handle input voltages within the limits specified previously. The Innova system has been found to work using this.
- **Trigger (Gold)** – The output from the MUX uses an open collector output to sink from the instrument being triggered. It therefore has little drive capability and, although it gives TTL voltages unloaded, with 2 WBMS sonars connected the pulse height drops to below the required 3v3 threshold. This results in occasional loss of 1PPS pulse and in a noisy situation is unlikely to be reliable. It has, however, been used offshore.

It should be remembered that a link between dual head sonars for synchronisation should be achieved by wiring in the harness; it is not addressed in the C3 connector.




Figure 43. Setup Using C3

Wiring for one or two WINGHEAD sonars to C3 is shown below. This is only a suggestion and users should test the wiring for themselves before committing to moulding cables for installations.

C3 Pin	C3 Function	Pri. WINGHEAD Pin	Function	Sec. WINGHEAD Pin	Function
1	Ethernet Rd- 1	13	Eth_A-		
2	Ethernet Rd+ 1	8	Eth_A+		
3	Trigger	1	TIME+	1	TIME+
4	Ethernet Rd- 2			13	Eth_A-
5	Ethernet Rd+ 2			8	Eth_A+
6	48vDC				
7	0v	9	GND	9	GND
8	24vDC	10	24VDC	10	24VDC
9	RS485-	8	TIME-	8	TIME-
10	Ethernet Td- 1	5	Eth_B-		
11	Ethernet Td+ 1	6	Eth_B+		
12	RS485+	1	TIME+	1	TIME+
13	Ethernet Td- 2			5	Eth_B-
14	Ethernet Td+ 2			6	Eth_B+
15	RS232/RS485 0v	3	TIME_GND	3	TIME_GND
16	RS232 TX (Down)	1	TIME+	1	TIME+
17	RS232 RX (Up)				
18	NC				
19	NC				
20	Trigger 0v	3	TIME_GND	3	TIME_GND
21	NC				

Table 15. 24-pin WINGHEAD Connections to C3

If a WINGHEAD sonar with an 18-pin connector is used, the use of RS485 is recommended for 1PPS downlink.

Wiring for one or two WBMS sonars to C3 is shown below. This is only a suggestion and users should test the wiring for themselves before committing to moulding cables for installations.

C3 Pin	C3 Function	Pri. WBMS Pin	Function	Sec. WBMS Pin	Function
1	Ethernet Rd- 1	4	LAN RX-		
2	Ethernet Rd+ 1	3	LAN RX+		
3	Trigger	7	PPS/IRIG-B	7	PPS/IRIG-B
4	Ethernet Rd- 2			4	LAN RX-
5	Ethernet Rd+ 2			3	LAN RX+
6	48vDC				
7	0v	9	GND	9	GND
8	24vDC	10	24VDC	10	24VDC
9	RS485-	8	Signal GND	8	Signal GND
10	Ethernet Td- 1	2	LAN TX-		
11	Ethernet Td+ 1	1	LAN TX+		
12	RS485+	7	PPS/IRIG-B	7	PPS/IRIG-B
13	Ethernet Td- 2			2	LAN TX-
14	Ethernet Td+ 2			1	LAN TX+
15	RS232/RS485 0v	8	Signal GND	8	Signal GND
16	RS232 TX (Down)	7	PPS/IRIG-B	7	PPS/IRIG-B
17	RS232 RX (Up)				
18	NC				
19	NC				
20	Trigger 0v	8	Signal GND	8	Signal GND
21	NC				

Table 16. WBMS Connections to C3



Appendix D: Timing Methods

D1. WBMS 1PPS+ZDA Direct Timing Scheme

Description

When it is not possible to use NTP+PPS timing for subsea installations, another option is to use the 1PPS+ZDA direct timing scheme, as outlined below. Note that this scheme uses the trigger lines, therefore the trigger function is no longer available. It also requires sonar firmware 5.5.57 or later.

- The NORBIT WBMS timestamps data directly in the sonar head with high accuracy timing.
 - WBMS accepts the 1PPS signal from GNSS on pin 7 with GND pin 8.
 - WBMS accepts serial \$GPZDA on pin 6 with GND pin 8.
- To activate this timing mode, the following commands must be executed:
 - `set_time_source 5`
 - `set_ext_serial 1 38400`
- The baud rate of the serial port (38400 in the above example) can be changed to whatever is required. Use startup commands via the sonar web UI (shown below) to execute the change.
- The `set_time_source` command must be provided in the `bathy_sonar_factorysettings.ini` file, as shown below.



D2. NTP Configuration on a Time-Synchronised PC

This appendix explains how to configure two examples of NTP time servers. Other NTP servers are available as stand-alone services (like Meinberg) or as part of a package (like Qinsy). The server generally runs on the time-synchronised PC, which is normally the data acquisition PC, as it is synchronised to a source such as GNSS time.

Notes

- SNTP time to the sonar **WITHOUT** a 1PPS synchronisation pulse is accurate to better than 10 milliseconds and is suitable for platforms moving linearly, e.g. ROV with no tugging from the umbilical or sharp attitude/heading changes.
- The time received at the sonars is also only as good as the time on the time serving PC. This should have a time source such as 1PPS & ZDA, or similar.
- The time from the server takes a few seconds to become valid on the sonar.
- It is possible to have multiple instances of the Qinsy SNTP server active by mistake. Ensure that only one icon is displayed in the system tray.
- Only one NTP service should be active. The W32Time Service should be stopped, and the Startup should be disabled.




Figure 44. Disabling Windows Time Service

Qinsy SNTP Server

The SNTP time server is available with a Qinsy distribution. This is free to use, and no license is required. If it is not visible in the Qinsy Console, it should be added by selecting **View > Add/Remove QPS Programs**, and in the **Add/Remove Programs** dialog, select **SNTP Server**. The SNTP server is now available and can be started via the shortcut icon within the Qinsy Console.




Figure 45. Adding SNTP Server to Qinsy Console

Once the SNTP server is started, it is necessary to set the **NTP clock status reply** in the **Options** dialog to **Only valid status when PPS driver is running** if the Qinsy PPS driver is interfaced, otherwise, if time is set with a different method, then select **Always report valid status**.

Change the **Highlight client when offset** threshold to **>20ms**. Incoming requests for time updates will be shown in the main display along with the time of request.

Meinberg NTP Server

The Meinberg NTP server runs as a Windows service and can be downloaded from: https://www.meinbergglobal.com/english/sw/ntp.htm#ntp_stable

After completing the installation, it may be necessary to restart the PC.

Name	Description	Status	Startup Type	Log On As
Network Location Awareness	Collects an...	Running	Automatic	Network S...
Network Setup Service	The Networ...		Manual (Trig...	Local Syste...
Network Store Interface Ser...	This service ...	Running	Automatic	Local Service
Network Time Protocol Dae...	Synchroniz...	Running	Automatic	Local Syste...
NVIDIA Display Container LS	Container s...	Running	Automatic	Local Syste...

Figure 46. Windows Task Manager Services (after Meinberg installation)

On the **Services** tab within Windows Task Manager, the **Network Time Protocol Daemon Startup Type** should be configured for **Automatic** startup, and the **Status** should be **Running**. If this is not the case, the properties should be changed to allow this. The setup is configured by an editable .ini file found in the following directory: *C:\Program Files (x86)\NTP\etc\ntp.conf*

A simple example of the configuration is shown below, which assumes that the sonar and time-synchronised PC are on the default subnet of 192.168.53.XXX.

```
#Use drift file. This ensures a fast resynch following a reboot
driftfile "%ProgramFiles%\NTP\etc\ntp.drift"
# you are the time server
server 127.127.1.0
#broadcast time on your subnet ie x.x.x.255
broadcast 192.168.53.255 minpoll 0 maxpoll 0
```

The .ini file is most easily accessible from the Windows Start Menu, by typing “NTP” into the search, where the **Edit NTP Configuration App** can then be accessed. Note that it is necessary to restart the PC with each new configuration.




Figure 47. Edit NTP Configuration App (left) and Windows Start Menu (right)

The Meinberg group from the Windows Start Menu provides access to various functions, including starting and stopping the NTP services, and opening a status window for the server.

The NORBIT GUI must be configured to communicate with the time server, and therefore requires the network IP address of the PC. There may be a short delay for the time synchronisation to become active. When the time in the GUI becomes valid, the reported date/time will change from red to white.

Meinberg also offers a Status monitoring tool. The use of this tool is recommended to check that the service is running OK, and the timing is valid. It also offers easy viewing, editing and saving of the configuration file. Unfortunately, it does not show incoming time requests like the Qinsy SNTP utility.

The tool can be downloaded from: <https://www.meinbergglobal.com/english/sw/ntp-server-monitor.htm#download>




Figure 48. Meinberg Monitoring Tool



NOTE: The Meinberg NTP server will not immediately start to provide time updates to the sonar. It monitors the PC clock for a few minutes and when the “Reach” gets high enough (77 to a maximum of 377) it will start to reply to time requests. In the Monitoring tool, the LOCAL status will show this progression and turn green when it is ready to serve.

Appendix E: Suggested Pigtail Test Cables

While it is required to connect an ROV Pigtail to a MUX or vehicle junction box, it can be convenient to have a pigtail wired directly to a PSU and network cable to verify the setup and wiring prior to mobilisation.

E1. WINGHEAD 24-Pin Test Cable

This uses the WINGHEAD pigtail, PN 33256:

Connector Pin	Function	Pigtail Wire Colour	RJ45 Pin	Suggested Network Pair Colour	Other Connection	
1	Time+	White			TTL/RS232 OR RS422+	
2	Time-	Black/white			NC OR RS422-	
3	Time GND	Drain of Black/White			TTL/RS232 GND OR NC	
8	A+	Orange	1	White/Orange	100Mbit wiring	1Gbit Wiring
13	A-	Black/Orange	2	Orange		
6	B+	Blue	3	White/Green		
5	B-	Black/Blue	6	Green		
17	C+	Green	5	White/Blue	1Gbit Wiring	
12	C-	Black/Greem	4	Blue		
19	D+	Brown	7	White/Brown		
20	D-	Black/Brown	8	Brown		
21	24-48vDC	White (Power)			To PSU+	
4	Power GND	Black (Power)			To PSU 0v	
24	Synch+	Red			To DH S+	
23	Synch-	Black/Red			To DH S-	
22	Synch GND	Drain of Black/Red				




Figure . Pinout Diagrams



NOTE: Always check that the power output on the relevant pins is correct before connecting any sonar.

E2. WBMS 10-Pin Test Cable

This uses the 33095 WBMS pigtail, PN 33095:

Connector Pin	Function	Colour	RJ45 Pin	Suggested Network Pair Colour	Other Connection
1	LAN, TX+	White/Orange	1	White/Orange	
2	LAN, TX-	Orange	2	Orange	
3	LAN, RX+	White/Green	3	White/Green	
4	LAN, RX-	Green	6	Green	
5	Trig OUT	White/Brown			Synch out to Dual Head sonar OR
6	Trig IN	Brown			Synch in from Dual Head sonar
7	PPS/IRIG-B	White/Blu			1PPS in RS232/TTL
8	Signal GND	Blu			GND for 1PPS and Synch
9	GND	Black			0v of 24vDC
10	24VDC	White			24vDC




Figure 49. Pinout Diagrams



NOTE: Always check that the power output on the relevant pins is correct before connecting any sonar.