

Configuring the controller for the application

DISPLAY RUNNING IN SETUP IN ENTER + -			Factory configuration
Enter the access code	ACCESS CODE	Enter the access code and valid	0
Configure the 0-10V output	SET ANALOG-OUT	SPEED: 10V = 60000 rpm I motor: 1V per 250 mA θ.PUMP: 0.1V per 1°C θ.CONT: 0.1V per 1°C	Speed
Modify the STANDBY speed	STANDBY SPEED	38000 to 42000 rpm	38000
Give the authorization to restart the pump after a power cut	AUTO-STARTING	YES or NO	NO
Activate or deactivate the buzzer	BUZZER	ON or OFF	ON
Select the temperature measurement unit	TEMPERATURE UNIT	°C or °F	°C
Set the serial link parameters	SET SERIAL LINK	RS 232/RS 485/NETWORK (See sub-menus page 2)	RS232
Modify the time before starting the pump	SET START DELAY	From 0 to 240mn 59s	0mn 0s
Modify the time before opening the air inlet valve	TIME TO VENTING	From 0 to 59mn 59s	0mn 1s
Modify the air inlet valve opening time	VENTING TIME	From 0 to 59mn 59s	0mn 1s
Program the maximum operating time before changing the bearings	MAINTENANCE	From 1000 to 15000 hours	15000h
Bearings life time counter	TIME BEARING	From 0 to 50000 hours	0h
Modify the access code	NEW CODING	From 0 to 65535	0

Configuring the controller for the application

