

Use screw mount for ground
reference to Differential Inputs

OR

Use ground loop below.

