

Packing HydroRad-2 HR110455

- Place the instrument label-side up, as shown, with a dummy plug installed.
- Arrange the fiber optic cables such that they will not be pinched against the instrument, or under the lid.



- Place a layer of solid foam on top before closing the case

