

Optional Signals to/from Cabin

1. Alarm from Charge SBP (Mod 8)
2. and Return
3. Alarm from Motor SBP (Mod 6)
4. and Return
5. Alarm from Aux SBP (Mod 5)
6. and Return
7. Cerbo GX Temp 1
8. and Return
9. Cerbo GX Temp 2
10. and Return
11. Cerbo GX Temp 3
12. and Return
13. Cerbo GX Temp 4
14. and Return
15. Cerbo GX Relay 1 NC
16. Cerbo GX Relay 1 Com
17. Cerbo GX Relay 1 NO
18. Cerbo GX Relay 2 NC
19. Cerbo GX Relay 2 Com
20. Cerbo GX Relay 2 NO
21. Cerbo GX Dig in 1
22. Cerbo GX Dig in 2
23. Cerbo GX Dig in 3
24. Cerbo GX Dig in 4
25. Lynx Smart BMS Relay NO
26. Lynx Smart BMS Relay Com
27. Lynx Smart BMS Relay NC

