


Ground Fault Monitor Sense Blocks



Ground Fault Monitors use these sense blocks to interface voltages higher than 120VAC, or when the circuit to be monitored is far away from the Monitor. Show is a 3 phase 3000VAC sense block. Also available are Single Phase and DC Sense Blocks in Voltage Ranges to 5000VAC and 1000VDC.