

Before Deployment

1. Set-up your Alpha account with CLS - www.argos-system.org
2. Make sure the XMA's power switch (located in the head) is turned ON
3. Insert batteries with the correct polarity: positive (+) towards the head
4. If using CR123A batteries, insert the thin battery liner
5. The head should flash green whenever the unit tries to transmit

Transmission Test

1. Put the XMA outside with a clear view of the sky
2. Watch for messages on the Argos tracking site
3. It can take up to an hour to get a message depending on satellite position