

External Console

Pin	Signal Designator	Signal Description
1	CONSOLE_PWR	Console Device Power
2	CONSOLE_GND	Console Device Ground
3	CONSOLE_RX_IN	Console Device 232 Rx_In
4	CONSOLE_TX_OUT	Console Device 232 Tx_Out

Pager Reset

Pin	Signal Designator	Signal Description
1	PAGER_PWR	Pager Power Supply
2	PAGER_GND	Pager Ground Supply
3	PAGER_RELAY+	Relay+ from Pager
4	PAGER_RELAY-	Relay- from Pager
5	PAGER_RX_IN	Pager RS-232 Rx In
6	PAGER_TX_OUT	Pager RS-232 Tx Out

Long-Range Radio

Pin	Signal Designator	Signal Description
1	LRADIO_PWR	Long-range Radio Power
2	LRADIO_GND	Long-range Radio Ground
3	LRADIO_RX_IN	Long-range Radio Rx_In
4	LRADIO_TX_OUT	Long-range Radio Tx_Out
5	LRADIO_RTS	Long-range Radio RTS
6	LRADIO_CTS	Long-range Radio CTS
7	LRADIO_DTR	Long-range Radio DTR
8	LRADIO_DSR	Long-range Radio DSR
9	LRADIO_DCD	Long-range Radio DCD
10	LRADIO_RI	Long-range Radio RI

Short-Range Radio

Pin	Signal Designator	Signal Description
1	SRADIO_PWR	Short-range Radio Power
2	SRADIO_GND	Short-range Radio Ground
3	SRADIO_RX_IN	Short-range Radio Rx_In
4	SRADIO_TX_OUT	Short-range Radio Tx_Out
5	SRADIO_RTS	Short-range Radio RTS
6	SRADIO_CTS	Short-range Radio CTS
7	SRADIO_DTR	Short-range Radio DTR
8	SRADIO_DSR	Short-range Radio DSR
9	SRADIO_DCD	Short-range Radio DCD
10	SRADIO_RI	Short-range Radio RI