




1

Important! ! !
To make sure all function be workable, DO Install DisplayLink driver to your laptops with using CD-Manual.




2



3



4



5

Connect USB cable:
1. Only one USB connection is needed. an additional USB connection is provided for older laptops that have low power USB.
2. The monitor should be operated only by the USB cable in box.
3. DO Refer to "PC Requirement" of CD-manual or consult your dealer before trying other equipments to connect USB monitor.

