


AUV Docking Bouy Network Diagram



Internal Buoy Network (Ethernet and Wifi) – 134.89.93.x/24

- **DHCP scope:** 134.89.93.50 to 134.89.93.100
- **Static IP range:** 134.89.93.10 to 134.89.93.49, subnet mask 255.255.255.0
- **Default Gateway:** 134.89.93.1
- **Wireless SSID:** DockingCell, password is the same used for LRAUVs