

Command List

The following table lists the set of commands and arguments supported by the receiver. A full description of the commands can be found in the Reference Guide. Note that, depending on the options enabled on your receiver, some commands may not be supported.

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
sam gam	setAGCMode getAGCMode	Band Band	Mode	Gain						
		+ L1 + B3E6 + L2 + L5 + LBand all	auto frozen manual	0 ... <u>35</u> ... 70 dB						
lai	IstAntennaInfo	Antenna								
		Overview Main [antenna name]								
sal gal	setAntennaLocation getAntennaLocation	Antenna Antenna	Mode	DeltaX	DeltaY	DeltaZ				
		+ Base all	auto manual	-1000.0000 ... 0.0000 ... 1000.0000 m	-1000.0000 ... 0.0000 ... 1000.0000 m	-1000.0000 ... 0.0000 ... 1000.0000 m				
sao gao	setAntennaOffset getAntennaOffset	Antenna Antenna	DeltaE	DeltaN	DeltaU	Type (20)	SerialNr (20)	SetupID		
		+ Main all	-1000.0000 ... 0.0000 ... 1000.0000 m	-1000.0000 ... 0.0000 ... 1000.0000 m	-1000.0000 ... 0.0000 ... 1000.0000 m	Unknown	Unknown	0 ... 255		
lad	IstAsciiDisplay									
sto gto	setAttitudeOffset getAttitudeOffset	Heading	Pitch							
		-360.000 ... 0.000 ... 360.000 deg	-90.000 ... 0.000 ... 90.000 deg							
sbbs gbbs	setBBSamplingMode getBBSamplingMode	Mode								
		BeforeIM AfterIM								
scco gcco	setCalibCommonDelay getCalibCommonDelay	CommonDelay								
		-10000.000 ... 0.000 ... 10000.000 ns								
scsi gcsi	setCalibSignalDelay getCalibSignalDelay	Signal Signal	SignalDelay							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +GPSL1PY +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +QZSL1CB +NAVICL5 all	-1000.000 ... 0.000 ... 1000.000 ns							
sca gca	setChannelAllocation getChannelAllocation	Channel <i>Channel</i>	<i>Satellite</i>	<i>Search</i>	<i>Doppler</i>	<i>Window</i>				
		+Ch01 ... Ch60 all	<u>auto</u> G01 ... G36 F01 ... F14 E01 ... E36 S120 ... S158 C01 ... C63 J01 ... J10 I01 ... I14	<u>auto</u> manual	-50000 ... 0 ... 50000 Hz	1 ... 16000 ... 100000 Hz				
scia gcia	setCheckInternetAvailability getCheckInternetAvailability	<i>Mode</i>								
		<u>off</u> on								
scst gcst	setClockSyncThreshold getClockSyncThreshold	<i>Threshold</i>	<i>StartupSync</i>							
		ClockSteering usec500 msec1 msec2 msec3 msec4 msec5	<u>off</u> on							
sc2f gc2f	setCMRv2Formatting getCMRv2Formatting	<i>ReferenceID</i>								
		0 ... 31								
sc2i gc2i	setCMRv2Interval getCMRv2Interval	Message <i>Message</i>	<i>Interval</i>							
		+CMR0 +CMR1 +CMR2 +CMR3 all	0.1 ... 1.0 ... 600.0 s							
sc2m gc2m	setCMRv2Message2 getCMRv2Message2	<i>ShortID (8)</i>	<i>LongID (50)</i>	<i>COGO (16)</i>						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>Unknown</u>	<u>Unknown</u>	<u>Unknown</u>						
sc2o gc2o	setCMRv2Output getCMRv2Output	Cd <i>Cd</i>	<i>Messages</i>							
		+ COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + NTR4 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + <u>CMR0</u> + <u>CMR1</u> + <u>CMR2</u> + <u>CMR3</u> all							
sc2u gc2u	setCMRv2Usage getCMRv2Usage	<i>MsgUsage</i>								
		none + <u>CMR0</u> + <u>CMR1</u> + <u>CMR2</u> + <u>CMR3</u> + <u>CMR0p</u> + <u>CMR0w</u> all								
scm gcm	setCN0Mask getCN0Mask	Signal <i>Signal</i>	<i>Mask</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +Reserved1 +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB11 +BDSB21 +BDSB31 +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +QZSL1CB +NAVICL5 all	0 ... 10 ... 60 dB-Hz							
help	IstCommandHelp	Action (255)								
		Overview [command]								
scs gcs	setCOMSettings getCOMSettings	Cd <i>Cd</i>	<i>Rate</i>	<i>DataBits</i>	<i>Parity</i>	<i>StopBits</i>	<i>FlowControl</i>			
		+COM1 +COM2 +COM3 +COM4 all	baud1200 baud2400 baud4800 baud9600 baud19200 baud38400 baud57600 baud115200 baud230400 baud460800 baud500000 baud576000 baud921600 baud1000000 baud1152000 baud1500000 baud2000000 baud2500000 baud3000000 baud3500000 baud4000000	<u>bits8</u>	No	<u>bit1</u>	none RTS CTS			
lcf	IstConfigFile	File								
		Current Boot RxDefault User1 User2								
eccf gccf	exeCopyConfigFile getCopyConfigFile	Source	Target							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>Current</u> Boot User1 User2 RxDefault	<u>Current</u> Boot User1 User2							
scca gcda	setCrossDomainWebAccess getCrossDomainWebAccess	<i>Mode</i>								
		<u>off</u> on								
lcu	IstCurrentUser									
sdcm gdcn	setDaisyChainMode getDaisyChainMode	DC <i>DC</i>	<i>Mode</i>							
		+ DC1 + DC2 all	<u>Raw</u> ASCII RTCMv3							
sdio gdio	setDataInOut getDataInOut	Cd <i>Cd</i>	<i>Input</i>	<i>Output</i>	<i>Show</i>					
		+ DSK1 + COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + NTR4 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none CMD RTCMv2 RTCMv3 CMRv2 DC1 DC2 ASCIIIN <u>auto</u>	none + RTCMv2 + RTCMv3 + CMRv2 + <u>SBF</u> + <u>NMEA</u> + ASCIIIDisplay + DC1 + DC2 + Encapsulate + LBandBeam1 + LBandBeam2	(<u>off</u>) (on) (waiting)					
sdal gdal	setDefaultAccessLevel getDefaultAccessLevel	<i>Web</i>	<i>FileTransfer</i>	<i>Ip</i>	<i>Com</i>	<i>Usb</i>				
		<u>none</u>	<u>none</u> Viewer User	<u>none</u>	none Viewer <u>User</u>	none Viewer <u>User</u>				
sdca gdca	setDiffCorrMaxAge getDiffCorrMaxAge	<i>DGNSSCorr</i>	<i>RTKCorr</i>	<i>PPPCorr</i>	<i>Iono</i>					
		0.0 ... <u>400.0</u> ...3600.0 s	0.0 ... <u>20.0</u> ...3600.0 s	0.0 ... <u>1200.0</u> ...3600.0 s	0.0 ... <u>600.0</u> ...3600.0 s					
sdcu gdcu	setDiffCorrUsage getDiffCorrUsage	<i>Mode</i>	<i>MaxAge</i>	<i>BaseSelection</i>	<i>BaseID</i>	<i>MovingBase</i>	<i>MaxBase</i>	<i>MaxBaseline</i>		
		<u>LowLatency</u>	0.1 ... <u>3600.0</u> s	<u>auto</u> manual	0 ...4095	<u>off</u> on	<u>1</u> ...10	0 ... <u>2500000</u> m		
sdfa gdfa	setDiskFullAction getDiskFullAction	Disk <i>Disk</i>	<i>Action</i>							
		+ DSK1 all	DeleteOldest <u>StopLogging</u>							
ldi	IstDiskInfo	Disk	Directory (60)							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		DSK1 all								
sdds gdds	setDynamicDNS getDynamicDNS	<i>Provider</i>	<i>UserName (40)</i>	<i>Password (40/2)</i>	<i>Hostname (40)</i>	<i>Bind</i>				
		off dyndns.org no-ip.com				auto Ethernet				
eeem gecm	exeEchoMessage getEchoMessage	<i>Cd</i>	<i>Message (242)</i>	<i>EndOfLine</i>						
		DSK1 COM1 COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5 DC1 DC2	A:Unknown	none + CR + LF all						
sem gem	setElevationMask getElevationMask	<i>Engine</i> <i>Engine</i>	<i>Mask</i>							
		+Tracking +PVT all	-90 ...0 ...90 deg							
smth gmth	setENHTransfoHorizontal getENHTransfoHorizontal	<i>TransfoID</i> <i>TransfoID</i>	<i>DeltaE</i>	<i>DeltaN</i>	<i>E0</i>	<i>N0</i>	<i>AlphaEE</i>	<i>AlphaEN</i>	<i>AlphaNE</i>	<i>AlphaNN</i>
		+lt1 all	-250.0000 ...0.0000 ...250.0000 m	-250.0000 ...0.0000 ...250.0000 m	-8000000.0000 ...0.0000 ...8000000.0000 m	-8000000.0000 ...0.0000 ...8000000.0000 m	-1000.0000 ...0.0000 ...1000.0000 ppm	-1000.0000 ...0.0000 ...1000.0000 ppm	-1000.0000 ...0.0000 ...1000.0000 ppm	-1000.0000 ...0.0000 ...1000.0000 ppm
smtv gmtv	setENHTransfoVertical getENHTransfoVertical	<i>TransfoID</i> <i>TransfoID</i>	<i>DeltaH</i>	<i>E0</i>	<i>N0</i>	<i>AlphaHE</i>	<i>AlphaHN</i>			
		+lt1 all	-250.0000 ...0.0000 ...250.0000 m	-8000000.0000 ...0.0000 ...8000000.0000 m	-8000000.0000 ...0.0000 ...8000000.0000 m	-1000.0000 ...0.0000 ...1000.0000 ppm	-1000.0000 ...0.0000 ...1000.0000 ppm			
seth geth	setEthernetMode getEthernetMode	<i>Enable</i>								
		off on								
sep gep	setEventParameters getEventParameters	<i>Event</i> <i>Event</i>	<i>Polarity</i>	<i>Delay</i>						
		+EventA +EventB all	Low2High High2Low	-500.000000 ...0.000000 ...500.000000 ms						
facr	factoryReset									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
sfm gfm	setFileNaming getFileNaming	Cd <i>Cd</i>	<i>NamingType</i>	<i>FileName (20)</i>						
		+ DSK1 all	<u>FileName</u> Incremental IGS15M IGS1H IGS6H IGS24H	<u>log</u>						
sfpr gfpr	setFTPPushRINEX getFTPPushRINEX	<i>Server (32)</i>	<i>Path (64)</i>	<i>User (12)</i>	<i>Password (24/2)</i>					
				<u>anonymous</u>						
sfps gfps	setFTPPushSBF getFTPPushSBF	<i>Server (32)</i>	<i>Path (64)</i>	<i>User (12)</i>	<i>Password (24/2)</i>					
				<u>anonymous</u>						
efpt gfpt	exeFTPPushTest getFTPPushTest	Server (45)	Path (64)	User (20)	Password (40/2)					
				<u>anonymous</u>						
efup gfup	exeFTPUpgrade getFTPUpgrade	Server (64)	Path (64)	Login (12)	Password (24/2)					
				<u>anonymous</u>						
lopk	lstGalOSNMAPublicKeys									
sopk gopk	setGalOSNMAPublicKeys getGalOSNMAPublicKeys	ID <i>ID</i>	Key (213)							
		+ Key0 ... Key15 all								
sou gou	setGalOSNMAUsage getGalOSNMAUsage	<i>PVTLevel</i>	<i>MTRoot (65)</i>	<i>MeasLevel</i>						
		off loose strict		off loose						
sgd gdd	setGeodeticDatum getGeodeticDatum	<i>TargetDatum</i>								
		WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 <u>Default</u> User1 User2								
sgu ggu	setGeoidUndulation getGeoidUndulation	<i>Mode</i>	<i>Undulation</i>							
		<u>auto</u> manual	-250.000 ...0.000 ...250.000 m							
sfno gfno	setGlobalFileNamingOptions getGlobalFileNamingOptions	<i>BusyTag</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		off <u>on</u>								
sga gga	setGNSSAttitude getGNSSAttitude	Source								
		none MovingBase								
sgpf gpgf	setGPIOFunctionality getGPIOFunctionality	GPPin GPPin	Mode	Input	Output					
		+ GP1 + GP2 all	<u>Output</u>	<u>none</u>	<u>LevelLow</u> LevelHigh					
shm ghm	setHealthMask getHealthMask	Engine Engine	Mask							
		+ Tracking + PVT all	off <u>on</u>							
shs ghs	setHttpsSettings getHttpsSettings	Protocol								
		none + <u>HTTP</u> + <u>HTTPS</u> all								
lif	lstInternalFile	File								
		Permissions Identification Debug Error SisError DiffCorrError SetupError IPParameters RxMessages License								
sim gim	setIonosphereModel getIonosphereModel	Model								
		<u>auto</u> off KlobucharGPS SBAS MultiFreq KlobucharBDS								
sipf gipf	setIPFiltering getIPFiltering	Mode	AddrList (252)							
		off <u>on</u>								
sipk gipk	setIPKeepAlive getIPKeepAlive	Enable	IdleTime	Interval	MaxCount					
		off <u>on</u>	<u>15</u> ... 18000 s	<u>1</u> ... 3600 s	<u>1</u> ... <u>15</u> ... 3600					
sipp gipp	setIPPortSettings getIPPortSettings	PlaintextCommmand	FTPControl	SecureCommand	SSHControl					
		<u>1</u> ... <u>28784</u> ... 65535	<u>1</u> ... <u>21</u> ... 65535	<u>1</u> ... <u>28783</u> ... 65535	<u>1</u> ... <u>22</u> ... 65535					
sirs girs	setIPReceiveSettings getIPReceiveSettings	Cd Cd	Port	Mode	TCPAddress (45)					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	0 ... 65535	TCP2Way UDP	0.0.0.0					
sis giss	setIPServerSettings getIPServerSettings	Cd Cd	Port	Mode	UDPAddress (255.255.255.255)					
		+ IPS1 + IPS2 + IPS3 + IPS4 + IPS5 all	0 ... 65535	TCP UDP TCP2Way	255.255.255.255					
sis gis	setIPServices getIPServices	Command	FileTransfer							
		none + secure + plaintext all	none + FTP + SFTP + rsync + SCP all							
sips gips	setIPSettings getIPSettings	Mode	IP (16)	Netmask (16)	Gateway (16)	Domain (63)	DNS1 (16)	DNS2 (16)	MTU	
		DHCP Static	0.0.0.0	255.255.255.0	0.0.0.0		0.0.0.0	0.0.0.0	0 ... 1500	
lbb	lbb									
slbb glbb	setLBandBeams getLBandBeams	Beam Beam	Frequency	Rate	Name (8)	Region (8)	Usage			
		+ User1 + User2 all	1525000000 ... 1559000000 Hz	baud600 baud1200 baud2400 baud4800	Unknown	Unknown	Disabled Enabled			
sics glcs	setLBandCustomServiceID getLBandCustomServiceID	ServiceID (4)	ScramblingVector	NDAUsage						
		0000	0000	off on						
sind glnd	setLBandNTRIPDelivery getLBandNTRIPDelivery	Cd								
		none NTR1 NTR2 NTR3 NTR4								
slsm glsm	setLBandSelectMode getLBandSelectMode	Mode	Service	Beam1	Beam2					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		auto off manual	Inmarsat LBAS2	User1 User2 LBAS2 1 LBAS2 2 LBAS2 3 LBAS2 4 LBAS2 5 LBAS2 6 LBAS2 7 LBAS2 8 LBAS2 9 LBAS2 10 LBAS2 11 LBAS2 12 LBAS2 13 LBAS2 14 LBAS2 15 LBAS2 16 LBAS2 17 LBAS2 18 LBAS2 19 LBAS2 20 LBAS2 21 LBAS2 22 LBAS2 23 LBAS2 24 LBAS2 25 LBAS2 26 LBAS2 27 LBAS2 28 LBAS2 29 LBAS2 30 LBAS2 31 LBAS2 32	User1 User2 LBAS2 1 LBAS2 2 LBAS2 3 LBAS2 4 LBAS2 5 LBAS2 6 LBAS2 7 LBAS2 8 LBAS2 9 LBAS2 10 LBAS2 11 LBAS2 12 LBAS2 13 LBAS2 14 LBAS2 15 LBAS2 16 LBAS2 17 LBAS2 18 LBAS2 19 LBAS2 20 LBAS2 21 LBAS2 22 LBAS2 23 LBAS2 24 LBAS2 25 LBAS2 26 LBAS2 27 LBAS2 28 LBAS2 29 LBAS2 30 LBAS2 31 LBAS2 32					
slm glm	setLEDMode getLEDMode	GPLED	GPLED2							
		DIFFCORLED PVTLED TRACKLED LOGLED RTKLED	DIFFCORLED PVTLED TRACKLED LOGLED RTKLED							
slco glco	setLocalCoordOperation getLocalCoordOperation	OpName (100)	ENHTransfo							
		NETWORK	none It1							
llc	IstLocalCoordOperations	Operation								
		Overview								
login	LogIn	UserName (16)	Password (32/2)	FactoryUserNam	FactoryPasswor					
				RxAdmin	S3pt3ntr10					
logout	LogOut									
smv gmv	setMagneticVariance getMagneticVariance	Mode	Variation							
		auto manual	-180.0 ... 0.0 ...180.0 deg							
emd qmd	exeManageDisk getManageDisk	Disk	Action							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>DSK1</u>	<u>Unmount</u> Mount Format							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
smf gmp	setMarkerParameters getMarkerParameters	<i>MarkerName (60)</i>	<i>MarkerNumber</i>	<i>MarkerType (20)</i>	<i>StationCode (10)</i>	<i>MonumentIdx</i>	<i>ReceiverIdx</i>	<i>CountryCode (3)</i>		
		<u>SEPT</u>	<u>Unknown</u>	<u>Unknown</u>		<u>0 ... 9</u>	<u>0 ... 9</u>			
smrf gmrf	setMeas3MaxRefInterval getMeas3MaxRefInterval	<i>MaxIntrvl</i>								
		OnlyRef msec500 sec1 sec5 sec10 sec30 <u>sec60</u>								
lmd	lstMIBDescription	<i>File (255)</i>								
		Overview SBFTable [command]								
smm gmm	setMultipathMitigation getMultipathMitigation	<i>Code</i>	<i>Carrier</i>							
		off <u>on</u>	off <u>on</u>							
snrc gnrc	setNetworkRTKConfig getNetworkRTKConfig	<i>NetworkType</i>								
		<u>auto</u> VRS								
enoc gnoc	exeNMEAOnce getNMEAOnce	<i>Cd</i>	<i>Messages</i>							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		DSK1 <u>COM1</u> COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 NTR4 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	+ ALM + DTM + GBS + GGA + GLL + <u>GNS</u> + GRS + GSA + GST + GSV + HDT + RMC + ROT + VTG + ZDA + HRP + LLQ + RBP + RBV + RBD + AVR + GGK + GFA + GGQ + LLK + GMP + TFM + SNC + THS							
sno	setNMEAOutput	<i>Stream</i>	<i>Cd</i>	<i>Messages</i>	<i>Interval</i>					
gno	getNMEAOutput	<i>Stream</i>								
		+ Stream1 ... Stream10 all	<u>none</u> DSK1 COM1 COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 NTR4 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	<u>none</u> + ALM + DTM + GBS + GGA + GLL + GNS + GRS + GSA + GST + GSV + HDT + RMC + ROT + VTG + ZDA + HRP + LLQ + RBP + RBV + RBD + AVR + GGK + GFA + GGQ + LLK + GMP + TXTbase + TFM + SNC + THS	<u>off</u> OnChange msec10 msec20 msec40 msec50 msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60					
snp	setNMEAPrecision	<i>NrExtraDigits</i>	<i>Compatibility</i>	<i>LocalDatum</i>	<i>MinStdDev</i>					
gnp	getNMEAPrecision									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		0 ...2 ...3	<u>Nominal</u> Mode1 Mode2	<u>off</u> only	0.000 ...0.001 ...1.000 m					
snti gnti	setNMEATalkerID getNMEATalkerID	<i>TalkerID</i>								
		auto <u>GP</u> GN								
snv gnv	setNMEAVersion getNMEAVersion	<i>Version</i>								
		<u>v3x</u> v4x								
snf gnf	setNotchFiltering getNotchFiltering	<i>Notch</i> <i>Notch</i>	<i>Mode</i>	<i>CenterFreq</i>	<i>Bandwidth</i>					
		+ Notch1 + Notch2 + Notch3 all	auto off manual	<u>1100.000</u> ...1700.000 MHz	30 ...1600 kHz					
snc gnc	setNtpClient getNtpClient	<i>Mode</i>	<i>Server (45)</i>							
		<u>off</u> on	<u>default</u>							
sntp gntp	setNTPServer getNTPServer	<i>Enable</i>								
		<u>off</u> on								
snmp gnmp	setNtripCasterMountPoints getNtripCasterMountPoints	<i>MountPointID</i> <i>MountPointID</i>	<i>Enable</i>	<i>MPName (32)</i>	<i>ExtServer</i>	<i>UserName (20)</i>	<i>Password (40/2)</i>	<i>ClientAuth</i>		
		+ MP1 + MP2 + MP3 all	<u>off</u> on		<u>No</u> Yes			none <u>basic</u>		
smfp gmfp	setNtripCasterMPFormat getNtripCasterMPFormat	<i>MountPointID</i> <i>MountPointID</i>	<i>Format</i>	<i>ManualFt (30)</i>	<i>FtDetails (100)</i>					
		+ MP1 + MP2 + MP3 all	RTCMv2 RTCMv3 CMR NMEA <u>RAW</u> manual							
sncs gncs	setNtripCasterSettings getNtripCasterSettings	<i>Mode</i>	<i>Port</i>	<i>Identifier (100)</i>	<i>TlsPort</i>					
		<u>off</u> on	0 ... <u>2101</u> ...65535	<u>default</u>	0 ... <u>2102</u> ...65535					
sncu gncu	setNtripCasterUsers getNtripCasterUsers	<i>UserID</i> <i>UserID</i>	<i>UserName (20)</i>	<i>Password (40/2)</i>	<i>MountPoints</i>	<i>MaxClients</i>				
		+ User1 + User2 + User3 + User4 + User5 all			<u>none</u> + MP1 + MP2 + MP3 all	1 ... <u>10</u>				
sntg gnlg	setNtripGeneralSettings getNtripGeneralSettings	<i>UserAgent (64)</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>default</u>								
snts gnts	setNtripSettings getNtripSettings	Cd <i>Cd</i>	<i>Mode</i>	<i>Caster (40)</i>	<i>Port</i>	<i>UserName (20)</i>	<i>Password (64/2)</i>	<i>MountPoint (32)</i>	<i>Version</i>	<i>SendGGA</i>
		+ NTR1 + NTR2 + NTR3 + NTR4 all	<u>off</u> Server Client		0 ...2101 ...65535				v1 <u>v2</u>	<u>auto</u> off sec1 sec5 sec10 sec60
Inst	IstNTRIPSourceTable	Caster (40)	<i>Port</i>							
			0 ...2101 ...65535							
sntt gnnt	setNtripTlsSettings getNtripTlsSettings	Cd <i>Cd</i>	<i>Enable</i>	<i>Fingerprint (96)</i>						
		+ NTR1 + NTR2 + NTR3 + NTR4 all	<u>off</u> on							
soc goc	setObserverComment getObserverComment	<i>Comment (120)</i>								
		<u>Unknown</u>								
sop gop	setObserverParameters getObserverParameters	<i>Observer (20)</i>	<i>Agency (40)</i>							
		<u>Unknown</u>	<u>Unknown</u>							
spe gpe	setPeriodicEcho getPeriodicEcho	Cd <i>Cd</i>	<i>Message (201)</i>	<i>Interval</i>						
		+ COM1 + COM2 + COM3 + COM4 all	A:Unknown	off once msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60						
sp2p gp2p	setPointToPoint getPointToPoint	SessionID <i>SessionID</i>	<i>Mode</i>	<i>Cd</i>	<i>ClientIP (20)</i>	<i>ServerIP (20)</i>	<i>Auth</i>	<i>Password (40/2)</i>	<i>ConnectTimeout</i>	<i>ActivityTimeout</i>
		+ P2PP1 all	Off Server	COM1 COM2 COM3 COM4	192.168.50.2	192.168.50.1	None PAP CHAP		60 ...300 s	10 ...600 ...32000 s
spfw gpfw	setPortFirewall getPortFirewall	Interface <i>Interface</i>	<i>OpenPorts</i>	<i>PortList (100)</i>						
		+ Ethernet all	none <u>default</u> all PortList							
epwm gpwm	exePowerMode getPowerMode	Mode								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		<u>StandBy</u>								
spps gpps	setPPSPParameters getPPSPParameters	<i>Interval</i>	<i>Polarity</i>	<i>Delay</i>	<i>TimeScale</i>	<i>MaxSyncAge</i>	<i>PulseWidth</i>			
		off msec10 msec20 msec50 msec100 msec200 msec250 msec500 sec1 sec2 sec4 sec5 sec10 sec30 sec60	Low2High High2Low	-1000000.00 ...0.00 ...1000000.00 ns	GPS Galileo BeiDou GLONASS UTC RxClock	0 ... 60 ... 3600 s	0.000001 ...5.000000 ...1000.000000 ms			
sptp gptp	setPTPServer getPTPServer	<i>Enable</i>								
		off on								
spm gpm	setPVTMode getPVTMode	<i>Mode</i>	<i>RoverMode</i>	<i>RefPos</i>						
		Static <u>Rover</u>	+ <u>StandAlone</u> + <u>SBAS</u> + <u>DGNSS</u> + <u>RTKFloat</u> + <u>RTKFixed</u> + RTK all	<u>auto</u> Geodetic1 Geodetic2 Geodetic3 Geodetic4 Geodetic5 Cartesian1 Cartesian2 Cartesian3 Cartesian4 Cartesian5						
srl grl	setRAIMLevels getRAIMLevels	<i>Mode</i>	<i>Pfa</i>	<i>Pmd</i>	<i>Reliability</i>					
		off <u>on</u> Mode1	-12 ... -4 ... -1	-12 ... -4 ... -1	-12 ... -3 ... -1					
grc	getReceiverCapabilities									
srd grd	setReceiverDynamics getReceiverDynamics	<i>Level</i>	<i>Motion</i>							
		Max High <u>Moderate</u> Low	Static Quasistatic Pedestrian <u>Automotive</u> RaceCar HeavyMachinery UAV Unlimited							
gri	getReceiverInterface	<i>Item</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ RxName + SNMPLanguage + SNMPVersion all								
lrf	lstRecordedFile	Disk	FileName (60)							
		DSK1								
era gra	exeRegisteredApplications getRegisteredApplications	Cd Cd	Application (12)							
		+ COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 all	Unknown							
erf grf	exeRemoveFile getRemoveFile	Disk	FileName (200)							
		DSK1	none all							
ernf grnf	exeResetNavFilter getResetNavFilter	Level								
		+ PVT + AmbRTK all								
erst grst	exeResetReceiver getResetReceiver	Level	EraseMemory							
		Soft Hard Upgrade	none + Config + PVTDData + SatData + TLSCertificate + SISAuthData all							
srxl grxl	setRINEXLogging getRINEXLogging	Cd Cd	FileDuration	ObsInterval	SignalTypes	ExtraObsTypes	RINEXVersion	MixedNav		

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ DSK1 all	none hour1 hour6 hour24 minute15	sec1 sec2 sec5 sec10 sec15 sec30 sec60	none + GPSL1CA + GPSL1PY + GPSL2PY + GPSL2C + GPSL5 + GLOL1CA + GLOL2P + GLOL2CA + GLOL3 + GALE1BC + GALE6BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB1I + BDSB2I + BDSB3I + BDSB1C + BDSB2a + BDSB2b + QZSL1CA + QZSL2C + QZSL5 + QZSL1CB + NAVICL5 all	none + Dx + Sx + Channel all	v211 v304ShortName	off on		
sr2c gr2c	setRTCMv2Compatibility getRTCMv2Compatibility	PRCType	GLOToD	RTKVersion						
		Standard GroupDelay	Tk Tb	v2.1 v2.2orLater						
sr2h gr2h	setRTCMv2EphemerisHoldoff getRTCMv2EphemerisHoldoff	TimeGPS	TimeGLO							
		0 ... 300 s	0 ... 300 s							
sr2f gr2f	setRTCMv2Formatting getRTCMv2Formatting	ReferenceID	GLOToD							
		0 ... 1023	Tk Tb							
sr2i gr2i	setRTCMv2Interval getRTCMv2Interval	Message Message	ZCount							
		+ RTCM1 + RTCM3 + RTCM9 + RTCM16 + RTCM17 + RTCM22 + RTCM23 24 + RTCM31 + RTCM32 all	1 ... 2 ... 1000							
sr2b gr2b	setRTCMv2IntervalObs getRTCMv2IntervalObs	Message Message	Interval							
		+ RTCM18 19 + RTCM20 21 all	1 ... 600 s							
sr2m gr2m	setRTCMv2Message16 getRTCMv2Message16	Message (90)								
		Unknown								
sr2o gr2o	setRTCMv2Output getRTCMv2Output	Cd Cd	Messages							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + NTR4 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + <u>RTCM1</u> + <u>RTCM3</u> + RTCM9 + RTCM16 + <u>RTCM18</u> 19 + <u>RTCM20</u> 21 + <u>RTCM22</u> + <u>RTCM23</u> 24 + <u>RTCM31</u> + RTCM32 + RTCM17 + DGPS + RTK all							
sr2u gr2u	setRTCMv2Usage getRTCMv2Usage	<i>MsgUsage</i>								
		none + <u>RTCM1</u> + <u>RTCM3</u> + <u>RTCM9</u> + RTCM15 + <u>RTCM18</u> 19 + <u>RTCM20</u> 21 + <u>RTCM22</u> + <u>RTCM23</u> 24 + <u>RTCM31</u> + <u>RTCM32</u> + <u>RTCM34</u> + <u>RTCM17</u> + <u>RTCM59</u> all								
sr3t gr3t	setRTCMv3CRSTransfo getRTCMv3CRSTransfo	<i>Mode</i>	<i>TargetName (32)</i>							
		<u>auto</u> manual								
sr3d gr3d	setRTCMv3Delay getRTCMv3Delay	<i>Delay</i>								
		<u>0.0 ... 600.0 s</u>								
sr3f gr3f	setRTCMv3Formatting getRTCMv3Formatting	<i>ReferenceID</i>	<i>MSMSignals</i>	<i>GLL2</i>	<i>RxType (32)</i>	<i>MaxMSMSats</i>				

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		0 ... 4095	+GPSL1CA +GPSL1PY +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +NAVICL5 all	L2CA L2P	default	1 ... 128				
sr3i gr3i	setRTCMv3Interval getRTCMv3Interval	Message Message	Interval							
		+RTCM1001 2 +RTCM1003 4 +RTCM1005 6 +RTCM1007 8 +RTCM1009 10 +RTCM1011 12 +RTCM1013 +RTCM1019 +RTCM1020 +RTCM1029 +RTCM1033 +RTCM1041 +RTCM1042 +RTCM1044 +RTCM1045 +RTCM1046 +RTCM1230 +MSM1 ... MSM7 all	0.1 ... 1.0 ... 600.0 s							
sr3m gr3m	setRTCMv3Message1029 getRTCMv3Message1029	Message (120)								
		Unknown								
sr3o gr3o	setRTCMv3Output getRTCMv3Output	Cd Cd	Messages							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ COM1 + COM2 + COM3 + COM4 + USB1 + USB2 + IP10 ... IP17 + NTR1 + NTR2 + NTR3 + NTR4 + IPS1 + IPS2 + IPS3 + IPS4 + IPS5 + IPR1 + IPR2 + IPR3 + IPR4 + IPR5 all	none + RTCM1001 + RTCM1002 + RTCM1003 + RTCM1004 + RTCM1005 + <u>RTCM1006</u> + RTCM1007 ... RTCM1013 + RTCM1019 + RTCM1020 + RTCM1029 + <u>RTCM1033</u> + RTCM1041 + RTCM1042 + RTCM1044 + RTCM1045 + RTCM1046 + RTCM1071 + RTCM1072 + RTCM1073 + <u>RTCM1074</u> + RTCM1075 + RTCM1076 + RTCM1077 + RTCM1081 + RTCM1082 + RTCM1083 + <u>RTCM1084</u> + RTCM1085 + RTCM1086 + RTCM1087 + RTCM1091 + RTCM1092 + RTCM1093 + <u>RTCM1094</u> + RTCM1095 + RTCM1096 + RTCM1097 + RTCM1101 ... RTCM1107 + RTCM1111 ... RTCM1117 + RTCM1121 + RTCM1122 + RTCM1123 + <u>RTCM1124</u> + RTCM1125 + RTCM1126 + RTCM1127 + RTCM1131 ... RTCM1137 + <u>RTCM1230</u> + MSM1 + MSM2 + MSM3 + MSM4 + MSM5 + MSM6 + MSM7 + Nav all							
sr3u	setRTCMv3Usage	<i>MsgUsage</i>								
gr3u	getRTCMv3Usage									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none + RTCM1001 ... <u>RTCM1013</u> + RTCM1015 + RTCM1016 + RTCM1017 + RTCM1019 ... <u>RTCM1027</u> + RTCM1029 + RTCM1033 + RTCM1037 + RTCM1038 + RTCM1039 + RTCM1041 + RTCM1042 + RTCM1044 + RTCM1045 + RTCM1046 + RTCM1071 ... <u>RTCM1077</u> + RTCM1081 ... <u>RTCM1087</u> + RTCM1091 ... <u>RTCM1097</u> + RTCM1111 ... <u>RTCM1117</u> + RTCM1121 ... <u>RTCM1127</u> + RTCM1230 + MSM1 + MSM2 + MSM3 + MSM4 + MSM5 + MSM6 + MSM7 + Nav all								
ssh gsho	setSatelliteHealthOverride getSatelliteHealthOverride	<i>Measurements</i> none + G01 ... G36 + R01 ... R30 + E01 ... E36 + S120 ... S158 + C01 ... C63 + J01 ... J10 + I01 ... I14 + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS + NAVIC all	<i>PVT</i> none + G01 ... G36 + R01 ... R30 + E01 ... E36 + S120 ... S158 + C01 ... C63 + J01 ... J10 + I01 ... I14 + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS + NAVIC all							
sst gst	setSatelliteTracking getSatelliteTracking	<i>Satellite</i>								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none + G01 ... G36 + R01 ... R30 + E01 ... E36 + S120 ... S158 + C01 ... C63 + J01 ... J10 + I01 ... I14 + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS + NAVIC all								
ssu gsu	setSatelliteUsage getSatelliteUsage	Satellite								
		none + G01 ... G32 + R01 ... R24 + R25 + R26 + R27 + R28 + R29 + R30 + E01 ... E36 + S120 ... S158 + C01 ... C63 + J01 ... J10 + GPS + GLONASS + GALILEO + SBAS + BEIDOU + QZSS all								
ssbc gsbc	setSBASCorrections getSBASCorrections	Satellite	SISMode	NavMode	DO229Version					
		auto EGNOS WAAS MSAS GAGAN SDCM S120 ... S158	Test <u>Operational</u>	EnRoute PrecApp <u>MixedSystems</u>	auto DO229C					
ssgp gsgp	setSBFGroups getSBFGroups	Group Group	Messages							

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ Group1 + Group2 + Group3 + Group4 all	<u>none</u> [SBF List] + Measurements + Meas3 + RawNavBits + GPS + GLO + GAL + GEO + BDS + QZS + NavIC + PVTCart + PVTGeod + PVTExtra + Attitude + Time + Events + DiffCorr + Status + LBand + PostProcess + Rinex + RinexMeas3 + Support							
esoc gsoc	exeSBFOnce getSBFOnce	Cd	Messages							
		DSK1 <u>COM1</u> COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 NTR4 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	[SBF List] + Measurements + Meas3 + GPS + GLO + GAL + GEO + BDS + QZS + NavIC + PVTCart + PVTGeod + PVTExtra + Attitude + Time + Status + LBand + UserGroups + PostProcess + Rinex + RinexMeas3 + Support							
sso gso	setSBFOutput getSBFOutput	Stream <i>Stream</i>	<i>Cd</i>	<i>Messages</i>	<i>Interval</i>					

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ Stream1 Stream10 + Res1 + Res2 + Res3 + Res4 all	... COM1 COM2 COM3 COM4 USB1 USB2 IP10 ... IP17 NTR1 NTR2 NTR3 NTR4 IPS1 IPS2 IPS3 IPS4 IPS5 IPR1 IPR2 IPR3 IPR4 IPR5	<u>none</u> DSK1 + Measurements + Meas3 + RawNavBits + GPS + GLO + GAL + GEO + BDS + QZS + NavIC + PVTCart + PVTGeod + PVTEExtra + Attitude + Time + Event + DiffCorr + Status + LBand + UserGroups + PostProcess + Rinex + RinexMeas3 + Support	<u>none</u> [SBF List] + msec10 msec20 msec40 msec50 msec100 msec200 msec500 sec1 sec2 sec5 sec10 sec15 sec30 sec60 min2 min5 min10 min15 min30 min60					
estm	exeSetTime	<i>Format</i>	<i>TimeSpec (40)</i>							
gstm	getSetTime									
		<u>DateTime</u>								
snho	setSignalHealthOverride	<i>Measurements</i>	<i>PVT</i>							
gnho	getSignalHealthOverride									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		none +GPSL1CA +GPSL1PY +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +QZSL1CB +NAVICL5 +GPS +GLONASS +GALILEO +SBAS +BEIDOU +QZSS +NAVIC all	none +GPSL1CA +GPSL1PY +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +QZSL1CB +NAVICL5 +GPS +GLONASS +GALILEO +SBAS +BEIDOU +QZSS +NAVIC all							
snt	setSignalTracking	Signal								
gnt	getSignalTracking									

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +GPSL1PY +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +QZSL1CB +NAVICL5 +GPS +GLONASS +GALILEO +SBAS +BEIDOU +QZSS +NAVIC all								
snu gnu	setSignalUsage getSignalUsage	PVT	NavData							
		+GPSL1CA +GPSL1PY +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +QZSL1CB +NAVICL5 all	+GPSL1CA +GPSL1PY +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +QZSL1CB +NAVICL5 all							
ssi gsi	setSmoothingInterval getSmoothingInterval	Signal Signal	Interval	Alignment						

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+GPSL1CA +GPSL2PY +GPSL2C +GPSL5 +GLOL1CA +GLOL2P +GLOL2CA +GLOL3 +GALE1BC +GALE6BC +GALE5a +GALE5b +GALE5 +GEOL1 +GEOL5 +BDSB1I +BDSB2I +BDSB3I +BDSB1C +BDSB2a +BDSB2b +QZSL1CA +QZSL2C +QZSL5 +QZSL1CB +NAVICL5 all	0 ... 1000 s	0 ... 1000 s						
sspc gspc	setStaticPosCartesian getStaticPosCartesian	Position <i>Position</i>	<i>X</i>	<i>Y</i>	<i>Z</i>	<i>Datum</i>				
		+ Cartesian1 + Cartesian2 + Cartesian3 + Cartesian4 + Cartesian5 all	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	-8000000.0000 ... 0.0000 ... 8000000.0000 m	WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 User1 User2 Other				
sspg gspg	setStaticPosGeodetic getStaticPosGeodetic	Position <i>Position</i>	<i>Latitude</i>	<i>Longitude</i>	<i>Altitude</i>	<i>Datum</i>				
		+ Geodetic1 + Geodetic2 + Geodetic3 + Geodetic4 + Geodetic5 all	-90.0000000000 ... 0.0000000000 ... 90.0000000000 deg	180.0000000000 ... 0.0000000000 ... 180.0000000000 deg	-1000.0000 ... 0.0000 ... 30000.0000 m	WGS84 ETRS89 NAD83 NAD83_PA NAD83_MA GDA94 GDA2020 User1 User2 Other				
stss gtss	setTimeSyncSource getTimeSyncSource	<i>Source</i>								
		none EventA EventB								
sts gts	setTimingSystem getTimingSystem	<i>System</i>								
		Galileo GPS BeiDou auto								
ltc	lstTLSCertificates	Certificate								

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		[certificate ID]								
stlp gtp	setTrackingLoopParameters getTrackingLoopParameters	Signal <i>Signal</i>	<i>DLLBandwidth</i>	<i>PLLBandwidth</i>	<i>MaxTpDLL</i>	<i>MaxTpPLL</i>	<i>Adaptive</i>			
		+ GPSL1CA + Reserved1 + Reserved2 + GPSL2C + GPSL5 + GLOL1CA + GLOL2P + GLOL2CA + GLOL3 + GALE1BC + GALE6BC + GALE5a + GALE5b + GALE5 + GEOL1 + GEOL5 + BDSB1I + BDSB2I + BDSB3I + BDSB1C + BDSB2a + BDSB2b + QZSL1CA + QZSL2C + QZSL5 + QZSL1CB + NAVICL5 all	0.01 ... 0.25 ... 5.00 Hz	1 ... 15 ... 100 Hz	1 ... 100 ... 500 ms	1 ... 10 ... 200 ms	off on			
stm gtm	setTroposphereModel getTroposphereModel	<i>ZenithModel</i>	<i>MappingModel</i>							
		off Saastamoinen MOPS	Niell MOPS							
stp gtp	setTroposphereParameters getTroposphereParameters	<i>Temperature</i>	<i>Pressure</i>	<i>Humidity</i>						
		-100.0 ... 15.0 ... 100.0 degC	800.00 ... 1013.25 ... 1500.00 hPa	0 ... 50 ... 100 %						
suoc guoc	setUMSDOnConnect getUMSDOnConnect	<i>Mode</i>								
		off on								
suia guia	setUSBInternetAccess getUSBInternetAccess	<i>Enable</i>								
		off on								
sual gual	setUserAccessLevel getUserAccessLevel	UserID <i>UserID</i>	<i>UserName (16)</i>	<i>Password (32)</i>	<i>UserLevel</i>	<i>SSHKey (232)</i>				
		+ User1 User8 all			Viewer User					
sud gud	setUserDatum getUserDatum	Datum <i>Datum</i>	<i>Tx</i>	<i>Ty</i>	<i>Tz</i>	<i>Rx</i>	<i>Ry</i>	<i>Rz</i>	<i>D</i>	

Mnm.	Name	Argument 1	Argument 2	Argument 3	Argument 4	Argument 5	Argument 6	Argument 7	Argument 8	Argument 9
		+ User1 + User2 all	-2000000.00 ...0.00 ...2000000.00 mm	-2000000.00 ...0.00 ...2000000.00 mm	-2000000.00 ...0.00 ...2000000.00 mm	-100.0000 ...0.0000 ...100.0000 mas	-100.0000 ...0.0000 ...100.0000 mas	-100.0000 ...0.0000 ...100.0000 mas	-100.00000 ...0.00000 ...100.00000 ppb	
sudv gudv	setUserDatumVel getUserDatumVel	Datum Datum	TxVel	TyVel	TzVel	RxVel	RyVel	RzVel	DVel	RefYear
		+ User1 + User2 all	-2000.00 ...0.00 ...2000.00 mm/yr	-2000.00 ...0.00 ...2000.00 mm/yr	-2000.00 ...0.00 ...2000.00 mm/yr	-10.0000 ...0.0000 ...10.0000 mas/yr	-10.0000 ...0.0000 ...10.0000 mas/yr	-10.0000 ...0.0000 ...10.0000 mas/yr	-1.00000 ...0.00000 ...1.00000 ppb/yr	1900.00 ...2000.00 ...2100.00 yr
sue gue	setUserEllipsoid getUserEllipsoid	Datum Datum	A	Invf						
		+ User1 + User2 all	6300000.000 ...6378137.000 ...6400000.000 m	290.000000000 ...298.25722356 ...305.00000000						
swbi gwbi	setWBIMitigation getWBIMitigation	Mode								
		off on								

SBF List

ASCIIn	AttCovEuler	AttEuler
BBSamples	BDSAlm	BDSCNav1
BDSCNav2	BDSCNav3	BDSIon
BDSNav	BDSRaw	BDSRawB1C
BDSRawB2a	BDSRawB2b	BDSUtc
BaseStation	BaseVectorCart	BaseVectorGeod
ChannelStatus	Commands	Comment
DOP	DiffCorrIn	DiskStatus
DynDNSStatus	EndOfAtt	EndOfMeas
EndOfPVT	ExtEvent	ExtEventAttEuler
ExtEventBaseVectGeod	ExtEventPVTCartesian	ExtEventPVTGeodetic
GALAlm	GALAuthStatus	GALGstGps
GALLon	GALNav	GALRawCNAV
GALRawFNAV	GALRawINAV	GALSARRLM
GALUtc	GEOAlm	GEOClockEphCovMatrix
GEODegrFactors	GEOFastCorr	GEOFastCorrDegr
GEOIGPMask	GEOIntegrity	GEOIonoDelay
GEOLongTermCorr	GEOMT00	GEONav
GEONetworkTime	GEOPRNMMask	GEORawL1
GEORawL5	GEOServiceLevel	GLOAlm
GLONav	GLORawCA	GLOTime
GPSAlm	GPSCNav	GPSIon
GPSNav	GPSRawCA	GPSRawL2C
GPSRawL5	GPSUtc	Group1
Group2	Group3	Group4
IPStatus	InputLink	LBandBeams
LBandRaw	LBandTrackerStatus	Meas3CN0HiRes
Meas3Doppler	Meas3MP	Meas3PP
Meas3Ranges	MeasEpoch	MeasExtra
NAVICRaw	NTRIPClientStatus	NTRIPServerStatus
NavICLNav	OutputLink	P2PPStatus
PVTCartesian	PVTGeodetic	PVTSupport
PVTSupportA	PosCart	PosCovCartesian
PosCovGeodetic	PosLocal	PosProjected
QZSAlm	QZSNav	QZSRawL1CA
QZSRawL2C	QZSRawL5	QualityInd
RFStatus	RTCMDatum	ReceiverSetup
ReceiverStatus	ReceiverTime	RxMessage
SatVisibility	VelCovCartesian	VelCovGeodetic
xPPSOffset		