










































GND	VCC
SPI_SCK	SPI_MOSI
SPI_MISO	A_SPI_SS_A
UART_TX	UART_RX
IWT_SCL	IWT_SD
SPI_SS_B	IRQ
PWM-	PWM+
GPIO1	GPIO0
ADC-	ADC+
GND	ID

[illegible]

VCC
TDO
RST
BOOT

TMS
TDI
TCK
END

8B05	PB03	PB00	PB13	PE05	PA25	PA10	PD24	PE04	PE03	PE00	PC13	PD30	PA19	PC31	PD25	VIN	END	END	SV0	SV3	RESE	SV3	TAB4
------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	------	-----	-----	-----	-----	-----	------	-----	------

RESET
 SW0
 SWCLK
 SWDIO
 GND

[illegible]