

IRIDIUM DB9F TO DB25F

***SIGNAL* CTS**
J1.8 J2.8
***SIGNAL* DSR**
J1.1 J1.6 J2.19
***SIGNAL* DTR**
J1.4 J2.10 J2.21
***SIGNAL* GND**
J1.5 J2.3 J2.14 J2.17 J2.23 J2.25
***SIGNAL* +12V**
J2.4 J2.16
***SIGNAL* RI**
J1.9 J2.7
***SIGNAL* RTS**
J1.7 J2.22
***SIGNAL* RX**
J1.2 J2.13
***SIGNAL* TX**
J1.3 J2.9

