


ACT 201 H electrical connections

REMOTE CONTROL
connector plug
(Factory wiring)



If the controller is remote controlled, make the various connections on the **REMOTE CONTROL** connector (see B 80).



If the controller unit is used in **local mode**: the pump can only operate **if the plug is connected to the REMOTE CONTROL connector**. (Connector plug delivered with the controller).

