
Precautions before maintenance



It is important to isolate the machine from the electrical power supply source before any intervention inside the equipment (for maintenance reasons).

Before any maintenance operation, check the pumping conditions of the installation: toxicity, possible corrosion of the pumped gases. Depending on the conditions, we recommend:

- to purge the pumping installation with dry nitrogen before any intervention;
- to wear gloves, goggles and a breathing mask, if necessary;
- to ventilate the room well and disassemble the equipment under a suction hood.

After a complete maintenance operation, it is recommended to perform a helium leak test.

Similarly, follow all the safety instructions concerning start-up.