



# OASIS MOORING

## UHF TELEDESIGN RADIO TRAVELER

|                         |                |             |             |                                       |
|-------------------------|----------------|-------------|-------------|---------------------------------------|
| <b>RADIO</b>            | TS4000A05B45SS |             |             |                                       |
| <b>S/N</b>              | 16912 - SMA    |             |             |                                       |
|                         | <b>SPEC</b>    | <b>MEAS</b> | <b>DATE</b> | <b>COMMENTS</b>                       |
| <b>FREQ</b>             | 466.78750      | 466.78756   | 21SEPT04    | RADIO TYPE: 3412 S/N: 29076           |
| <b>P<sub>o</sub></b>    | 2.5W           | 2.5W        | 21SEPT04    | FIRMWARE: rev4.75 BOARD: rev1.02      |
| <b>I<sub>TX</sub></b>   | <2.00A         | 1.44 A      | 21SEPT04    |                                       |
| <b>DEV</b>              | ±3 KHz         | ±3 KHz      | 21SEPT04    |                                       |
| <b>R<sub>SENS</sub></b> | >-105 dBm      | -110 dBm    | 21SEPT04    |                                       |
| <b>I<sub>RX</sub></b>   | <200 ma        | 170 ma      | 21SEPT04    |                                       |
| <b>BENCH TEST</b>       | PASS           |             | 21SEPT04    | #1 OF GRP 1 – DEST ADDR #101 OF GRP 1 |
| <b>CAN #</b>            |                |             | 21SEPT04    | 2004M1                                |
| <b>MOORING</b>          | 2004M1         |             |             |                                       |

### IN OASIS LAB

|                                           |  |  |
|-------------------------------------------|--|--|
| INSTALL IN CAN                            |  |  |
| VISUAL INSPECTION                         |  |  |
| INITIAL CONN WITH "TORO"                  |  |  |
| 1 <sup>ST</sup> SOFTWARE CONN WITH "TORO" |  |  |
| 2 <sup>ND</sup> SOFTWARE CONN WITH "TORO" |  |  |
| 1 <sup>ST</sup> SOFTWARE CONN WITH "TORO" |  |  |
| 2 <sup>ND</sup> SOFTWARE CONN WITH "TORO" |  |  |
| FINAL SOFTWARE CONN WITH "TORO"           |  |  |

### IN BAR

|                                           |  |  |
|-------------------------------------------|--|--|
| 1 <sup>ST</sup> SOFTWARE CONN WITH "TORO" |  |  |
| 2 <sup>ND</sup> SOFTWARE CONN WITH "TORO" |  |  |
| FINAL SOFTWARE CONN WITH "TORO"           |  |  |

### ON DEPLOYMENT VESSEL

|                                           |  |  |
|-------------------------------------------|--|--|
| 1 <sup>ST</sup> SOFTWARE CONN WITH "TORO" |  |  |
| FINAL SOFTWARE CONN WITH "TORO"           |  |  |

### ACCEPTANCE BY MOORING MASTER

NAME: \_\_\_\_\_ TITLE: \_\_\_\_\_ DATE: \_\_\_\_\_