



LP Wizard Installation Instructions

Software Version 10.4

February 2012

**© 2010-2012 Mentor Graphics Corporation
All rights reserved.**

This document contains information that is proprietary to Mentor Graphics Corporation. The original recipient of this document may duplicate this document in whole or in part for internal business purposes only, provided that this entire notice appears in all copies. In duplicating any part of this document, the recipient agrees to make every reasonable effort to prevent the unauthorized use and distribution of the proprietary information.

This document is for information and instruction purposes. Mentor Graphics reserves the right to make changes in specifications and other information contained in this publication without prior notice, and the reader should, in all cases, consult Mentor Graphics to determine whether any changes have been made.

The terms and conditions governing the sale and licensing of Mentor Graphics products are set forth in written agreements between Mentor Graphics and its customers. No representation or other affirmation of fact contained in this publication shall be deemed to be a warranty or give rise to any liability of Mentor Graphics whatsoever.

MENTOR GRAPHICS MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

MENTOR GRAPHICS SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING BUT NOT LIMITED TO LOST PROFITS) ARISING OUT OF OR RELATED TO THIS PUBLICATION OR THE INFORMATION CONTAINED IN IT, EVEN IF MENTOR GRAPHICS CORPORATION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

RESTRICTED RIGHTS LEGEND 03/97

U.S. Government Restricted Rights. The SOFTWARE and documentation have been developed entirely at private expense and are commercial computer software provided with restricted rights. Use, duplication or disclosure by the U.S. Government or a U.S. Government subcontractor is subject to the restrictions set forth in the license agreement provided with the software pursuant to DFARS 227.7202-3(a) or as set forth in subparagraph (c)(1) and (2) of the Commercial Computer Software - Restricted Rights clause at FAR 52.227-19, as applicable.

Contractor/manufacturer is:

Mentor Graphics Corporation
8005 S.W. Boeckman Road, Wilsonville, Oregon 97070-7777.

Telephone: 503.685.7000

Toll-Free Telephone: 800.592.2210

Website: www.mentor.com

SupportNet: supportnet.mentor.com

Send Feedback on Documentation: supportnet.mentor.com/doc_feedback_form

TRADEMARKS: The trademarks, logos and service marks ("Marks") used herein are the property of Mentor Graphics Corporation or other third parties. No one is permitted to use these Marks without the prior written consent of Mentor Graphics or the respective third-party owner. The use herein of a third-party Mark is not an attempt to indicate Mentor Graphics as a source of a product, but is intended to indicate a product from, or associated with, a particular third party. A current list of Mentor Graphics' trademarks may be viewed at: www.mentor.com/trademarks.

End-User License Agreement: You can print a copy of the End-User License Agreement from: www.mentor.com/eula.

Mentor Graphics Application Software

Before You Begin Installation	1
Ordering Licenses	2
Installing and Configuring Licensing	2
Downloading the Software From SupportNet	2
Installing on Windows	3
Support Information	2

For additional reference while loading software, Mentor Graphics provides key system documentation on the install DVD and on SupportNet. Refer to the following manuals:

- *LP Wizard Release Highlights (lpwizard_10_4_rh.pdf)*
- *Licensing Mentor Graphics Software (mgc_licen.pdf)*
- *Release Notes for Licensing Mentor Graphics Software (mgc_lic_rn.pdf)*
- *License Administration Guide (flexnet_admin.pdf)*
- *Managing Mentor Graphics Systems Software: Installation and Licensing (manage_sw_lpwizard.pdf)*. Available at the [LP Wizard Download](#) tab on SupportNet.

Note: The SupportNet web site requires a login and password. To register and obtain a password, go to <http://supportnet.mentor.com/user/register.cfm>. If you have difficulties, email csd_registration@mentor.com. If you are registered, but have forgotten your password, go to http://supportnet.mentor.com/user/forgot_password.cfm.

Before You Begin Installation

The following are pre-requisites to the Mentor Graphics product installation.

1. Order software licenses from Mentor Graphics. Licensing should be installed prior to installing application software.

Note: To make full use of the Mentor Install Program automatic product selection by licenses, set up your software licensing environment before running the Mentor Install Program.
2. LP Wizard requires .NET Framework Version 3.5 to function. You must install .NET 3.5 before or after installing the LP Wizard software. Later versions of .NET (v4.0) are not compatible. .NET Framework Version 3.5 is available from the Microsoft web site.

-
3. Check system requirements. For current system requirements, refer to the SupportNet **Download** tab for this release. The release documents are located in the *release_documents* directory on the application DVD or from SupportNet. Additionally, the following web site on SupportNet lists all supported system configurations:

<http://supportnet.mentor.com/systemreqs/>

Ordering Licenses

New users must order software licenses prior to installing Mentor Graphics software. To order licenses, contact your local Mentor Graphics sales office. They can provide you with information on the number of node-locked and floating licenses your company purchased and any current license sever configurations you may have. You must provide them with:

- Any new license server configuration
- The host ID numbers of client and license server workstations for node-locked licenses
- The host ID number of the license server workstation for all floating licenses

Existing customers are reminded that your licensing report is available at the SupportNet web site (<http://supportnet.mentor.com/myaccount>), off the **Licenses** tab.

Installing and Configuring Licensing

All Mentor Graphics products require licensing to be installed and configured properly before invoking and operating them. It is recommended that licensing be installed before installing applications. For more licensing information, refer to the LP Wizard **Download** tab on SupportNet or the *release_documents* directory at the top level of the DVD/CD for the following documents:

- Chapter 1, “Licensing” in the *Managing Mentor Graphics Systems Software: Installation and Licensing* (*manage_sw_lpwizard.pdf*).
- *Licensing Mentor Graphics Software* manual for detailed licensing information for the system administrator, (*mgc_licen.pdf*)
- *License Administration Guide*, (*flexnet_admin.pdf*)

Downloading the Software From SupportNet

1. Using a web browser, log on to the Mentor Graphics SupportNet website.
2. In the **My Products** field, choose **LP Wizard**.
4. Click the **Downloads** tab.
5. In the **Selected Release** pull-down, select **LP Wizard 10.4** release.

-
6. Read the Software Terms and Conditions and select **I Agree** at the bottom before downloading the software.
 7. In the Product Download windows, select the **FTP Download** button associated with **LP Wizard 10.4**.

Note: The following instructions use WinZip as the extraction utility. If you use a different extraction utility, make appropriate selections to ensure that the directory structure of the Mentor Graphics software is preserved.

- a. In the File Download pop-up, click **Save** to save the .zip file to your machine
- b. In Windows Explorer, right-click the .zip file.
- c. From the pop-up menu, select **Winzip > Extract to...**

Note: The folder you extract the .zip file into becomes your installation source folder. This folder must not have any spaces in its path.

- d. Navigate to the folder to uncompress to (for example, C:\MentorGraphics\LP Wizard).
- e. Select **Use Folder names** and click **Extract**.

The data is extracted to the selected location.

8. Follow the instructions listed in “Installing on Windows”.

Installing on Windows

Note: By default, the Mentor Install Program is installed to C:\MentorGraphics\Install on Windows. If you need to install the Mentor Install Program to an alternate location, see “Selecting an Alternate Location for the Install Program” section in the *Managing Mentor Graphics Systems Software: Installation and Licensing* manual.

1. Navigate to the directory where you downloaded the release to. Double-click **LPWizard_mib.exe** to start the install program.

Alternatively, if you are installing from DVD, insert the disc into your CD-ROM drive. If the installation does not automatically start, select **Start > Run**, specify the CD-ROM drive letter and install executable (for example *D:\LPWizard_mib.exe*) and click **OK**.

Note: Mentor Graphics recommends you have Administrator privileges to install the software products from DVD on Windows systems.

Note: Mentor Graphics highly recommends that you stop all other programs before installing Mentor products.

2. In the Mentor Graphics Install window, click **Install Products**.

Tip: After the Mentor Install Program invokes, instructions for performing each of the following tasks are available in the online help.

-
3. Specify the source location by typing the source path in the source location field or click **Browse** to select the source directory. The default source location is the path where you invoked LPWizard_mib.exe in Windows.

Note: You should not have to change the source – the default will be correct.

4. Type the target path in the target location field or click **Browse** to select the target directory.
5. Click **Next** to display the Product Selection screen.
6. Select the products to install by selecting the appropriate check boxes. The products that have previously been installed at the target folder will display a “target” icon to the right of the product name. Click **Next** to display the License Agreement window.
7. Read the licensing agreement and click **Agree** to accept. The Confirm Selections screen displays.
8. Confirm the product selections by clicking **Install**.
9. Click **Done** when the installation is complete.

Caution: Some software installations launch post-installation processes that may include separate dialogs and command shells. Do not dismiss these dialogs or shells; they will either complete automatically or certain dialogs will require input. If any reboot requests occur during the installation process, respond **No** and reboot after the installation has completed. Once all the post-install processes are complete, the install wizard indicates the overall install process is complete.

Caution: If you choose to run verification on the install, run it immediately after installation and prior to running any of the products as the products can modify the installed files. These modified files could return unsatisfactory installation verification results.

Support Information

If you have questions about this software release, please log in to SupportNet. You may search thousands of technical solutions, view documentation, or open a Service Request online at:

<http://supportnet.mentor.com/>

If your site is under current support and you do not have a SupportNet login, you may easily register for SupportNet by filling out the short form at:

<http://supportnet.mentor.com/user/register.cfm>

All customer support contact information can be found on our web site at:

<http://supportnet.mentor.com/contacts/supportcenters/>