

CCU & Thrudder Compass Calibration Procedure

On-Shore and In-Water

Revision C

Item Number: 09502

EXPORT CONTROLLED – This technology is subject to the U.S. Export Administration Regulations (EAR), (15 C.F.R. Parts 730-774). No authorization from the U.S. Department of Commerce is required for export, re-export, in-country transfer, or access EXCEPT to country group E:1 or E:2 countries/persons per Supp.1 to Part 740 of the EAR.

©2019 Liquid Robotics

Confidential computer software. Valid license from Liquid Robotics, Inc. required for possession, use or copying. Consistent with FAR 12.211 and 12.212, Commercial Computer Software, Computer Software Documentation, and Technical Data for Commercial Items are licensed to the U.S. Government under vendor's standard commercial license.

Trademarks

Liquid Robotics®, Wave Glider®, Wave Glider Management System, WGMS, and SHARC® are worldwide trademarks of Liquid Robotics. Other products and company names mentioned herein may be the trademarks of their respective owners.

Patents

The Wave Glider mechanism is patented under US Patent Number 7,371,136 and other patents pending. All aspects of the Wave Glider product have been developed at private expense by Liquid Robotics.

Warranty

The information contained herein is subject to change without notice. The only warranties for Liquid Robotics, Inc. products and services are set forth in Liquid Robotics Terms and Conditions Articles 11.1 Limited Hardware Warranties, 11.2. Limited Service Warranties, and 11.3 Limitations. Nothing herein should be construed as constituting any additional warranties or representations. Liquid Robotics, Inc. shall not be liable for technical or editorial errors or omissions contained herein.

LIQUID ROBOTICS
A Boeing Company

Liquid Robotics

1329 Moffett Park Drive

Sunnyvale, CA 94089

Phone: +1 408 636 4200

Customer Support: +1 888-574-4574

Fax: +1 408 747 1923

Revision History

Document Part Number	Revision	Publication Date	Changes
09502	A	February 2018	This is the initial release of this document.
09502	B	March 2018	Updated dependencies to indicate the procedure applies only to Regulus 1.1.3.
09502	C	January 2020	Updated to include V300 scripts, as well as compatibility with Regulus 3.2.2

Contents

1	Introduction	5
2	Dependencies	5
2.1	SV3 V100/V200	5
2.1.1	Hardware	5
2.1.2	Software/Firmware	5
2.2	SV3 V300.....	5
2.2.1	Hardware	5
2.2.2	Software/Firmware	5
3	How To Send Write Console Scripts (WGMS)	6
4	On Shore Calibration	7
4.1	SV3 V100/V200 On-Shore.....	7
4.2	SV3 V300 On-Shore	8
5	In Water Calibration.....	9
5.1	SV3 V100/V200 In-Water	9
5.2	SV3 V300 In-Water	10

1 Introduction

There are several Wave Glider subsystems that utilize magnetic compasses. The compasses are sensitive to any nearby ferrous material, as well as local geomagnetic effects. For optimal performance, the compasses must be calibrated to account for those local effects. The two most critical compasses are located in the Sub Thrudder and Float CCU. The Thrudder compass is fundamental to system navigation. This procedure applies to these two compasses.



Note: The system should be in its final physical configuration during calibration.

2 Dependencies

This procedure applies to systems with the following components.

2.1 SV3 V100/V200

*Note: This procedure doesn't apply to all V100's; they must have a Thrudder 1.5 w/ External Compass.

2.1.1 Hardware

Thrudder 1.5: P/N 07555 rev 05

External Compass: P/N 08518 rev 05 or P/N 06737 rev 03

2.1.2 Software/Firmware

Regulus 1.1.3 or 3.2.2

IGM Firmware:

Version: 0x00004CEE, Filename: IGM-07496-0x0008-4CEE, P/N: 08219 Rev E

OR

Version: 0x00004CEE, Filename: IGM-04469-0x0008-4CEE, P/N: 05498 Rev C

2.2 SV3 V300

2.2.1 Hardware

Thrudder 3.0: P/N 08316 rev 04

Float AHRS (Twist Counter): P/N 08997 rev C

2.2.2 Software/Firmware

Regulus 3.2.2

Thrudder F/W: 0x00000049, Filename: Flounder-09946-0049, P/N: 10260 Rev 6

Float AHRS F/W: 0x00000009, Filename: FloatAHRS-08997-0009, P/N: 10326 Rev 02

3 How To Send Write Console Scripts (WGMS)

In order to conduct this calibration procedure, Write Console Scripts will have to be sent to the vehicle. There are various ways these can be sent; the process for doing so on WGMS is shown below.

1. Login to WGMS Org and click Piloting (this example = training.wgms.com)
2. Select vehicle in Vehicle Dropdown list (see image to right)
3. Click on "More Commands" from the Common Commands List in the Dashboard Sidebar (see image to right)
4. The "More Commands..." dialog box will appear. Fill it in as follows (see image below):
 - Command Reason: Enter text reason (e.g. Compass Cal)
 - Command Type: Select "Write Console Script" from dropdown list, will be towards the bottom of the list.
 - Leave Function = 0
 - Type "0" (zero, not the letter O) into Board Address
 - Select appropriate Com Channel (Cell if available)
 - Enter or copy-paste (recommended) script into Script Buffer, don't forget the % character at the beginning of the script.



Note: When copy-pasting scripts, to avoid syntax errors any quotation marks

will need to be retyped in the WGMS dialog box.

The screenshot shows the Liquid Robotics WGMS dashboard. At the top, the 'LIQUID ROBOTICS' logo is visible. Below it, a dropdown menu is set to 'SV3-1034'. A 'Data View' section displays various vehicle metrics: Mode: Set Rudder Position, Ave Speed(kts): 0.03, Last Speed(kts): 0.03, Rudder Pos: 270, Path Heading: 180, and Ave Water Speed(kts): 2.012. Below the data, there are status indicators for Light, P/L1, P/L2, Sub, and P/L3. A sidebar on the right contains a list of commands: 'SV3 Commands', 'Follow Sequential Course', 'Hold Station At Waypoint', 'Follow Custom Course', 'Follow Fixed Heading', 'Set Parameter', 'Comment', and 'More Commands ...' (which is highlighted with a red box). At the bottom of the sidebar are buttons for 'Begin Mission', 'Show System Menus', and a training section for 'Kenny Dewitt' with a 'Sign Out' link.

The screenshot shows the 'More Commands ...' dialog box. It has a title bar 'More Commands ...' and a 'Related Record' section with a dropdown set to 'Simple Command Form'. Below this, there are two tabs: 'Vehicle Command' and 'Related Info'. The 'Vehicle Command' tab is active, showing a form with the following fields: 'Command Reason' (Compass Cal Doc), 'Vehicle' (SV3-1034), 'Command Type' (Write Console Script), 'Command Status' (Created), 'Target Waypoint', 'From Waypoint', 'To Waypoint', 'Heading (deg)', 'Status', 'Course', 'Vehicle Rudder ...', 'Function' (0), 'Board Address' (0), 'File Type' (Unspecified), 'Operation Type' (Current Image), 'Com Channel' (VirtualRelayCell Commu), 'Upload File', 'Part', 'Vehicle File', 'Read File Name', 'Security Manifest', 'Disposition', 'Time Field', and 'Script Buffer' (%insert script text here). At the bottom of the dialog are three buttons: 'Copy ...', 'Send', and 'Cancel'.

4 On Shore Calibration

On Shore calibration must be done with the Wave Glider's Float and Sub co-aligned (typically installed in the vehicle's stand). This procedure should be done away from large metal structures such as buildings or rebar in concrete.

4.1 SV3 V100/V200 On-Shore

1. Retrieve existing calibration parameters from CCU & Thrudder:

```
%amps.portDump("Thrudder-2", 2, 2, 34, 3)
```

```
%amps.portDump("Host", 32, 4, 11, 3)
```

2. Start calibration routines on devices:

```
%amps.writePortField("Thrudder-2", 2, 2, 0, 1128352817)
```

```
%amps.oneShot("Host", 32, 4, 0, "CAL1")
```

3. Rotate the vehicle through two or three complete circles over 1-2 minutes.

4. Stop the Thrudder and CCU calibration routines:

```
%amps.writePortField("Thrudder-2", 2, 2, 0, 1128352816)
```

```
%amps.oneShot("Host", 32, 4, 0, "CAL0")
```

5. With the vehicle on shore with access to the vehicle web page, check the "Overall Vehicle Status" page to verify the float and sub headings are aligned at all cardinal directions (0, 90, 180, 270 degrees). The fields "HeadingHost_32_4" and "HeadingRudder" should be similar and should match the physical heading of the vehicle. If the system is configured with a weather station, the HeadingAirmarWeather value can be used for reference as well.

● heading	Sub: HeadingRudder*, HeadingThrudder-2_2_2, GPSasRudderCompass Float: HeadingHost 32_4, HeadingAirmarWeather*
● HeadingAirmarWeather	Heading 146.7 (turns=-5.592)
● HeadingHost_32_4	Heading 149.0 (turns=27.414)
● HeadingRudder	Heading 143.6 (turns=86.399)
● internetAccessibility	pingInterval=30 min, autostartVPN=enabled, vpnStatus=openv

6. Retrieve the new Thrudder and CCU compass calibration values:

```
%amps.portDump("Thrudder-2", 2, 2, 34, 3)
```

```
%amps.portDump("Host", 32, 4, 11, 3)
```

4.2 SV3 V300 On-Shore

1. Retrieve existing calibration parameters from CCU & Thrudder

```
%amps.portDumpNCData("host", 13, 2, 11, 3)
```

```
%amps.portDumpNCData("thruder-3", 1, 8, 11, 3)
```

2. Start calibration routines on devices

```
%amps.oneShot("host", 13, 2, 0, "CAL1")
```

```
%amps.oneShot("thruder-3", 1, 8, 0, "CAL1")
```

3. Rotate the vehicle through two or three complete circles over 1-2 minutes.

4. Stop calibration routines on devices

```
%amps.oneShot("host", 13, 2, 0, "CAL0")
```

```
%amps.oneShot("thruder-3", 1, 8, 0, "CAL0")
```

5. With the vehicle on shore with access to the vehicle web page, check the "Overall Vehicle Status" page to verify the float and sub headings are aligned at all cardinal directions (0, 90, 180, 270 degrees). The fields "HeadingHost_32_4" and "HeadingRudder" should be similar and should match the physical heading of the vehicle. If the system is configured with a weather station, the HeadingAirmarWeather value can be used for reference as well.

● heading	Sub: HeadingRudder*, HeadingThruder-2_2_2, GPSasRudderCompass Float: HeadingHost_32_4, HeadingAirmarWeather*
● HeadingAirmarWeather	Heading 146.7 (turns=-5.592)
● HeadingHost_32_4	Heading 149.0 (turns=27.414)
● HeadingRudder	Heading 143.6 (turns=86.399)
● internetAccessibility	pingInterval=30 min, autostartVPN=enabled, vpnStatus=openv

6. Retrieve new calibration parameters:

```
%amps.portDumpNCData("host", 13, 2, 11, 3)
```

```
%amps.portDumpNCData("thruder-3", 1, 8, 11, 3)
```

5 In Water Calibration

In Water calibration should be done soon after launch, while the vehicle is navigating properly. The vehicle shall be in an area large enough to complete the calibration without risk of running aground or colliding with other vessels. If you can afford to increase the telemetry report rate, it is recommended to set it to 1-2 minutes while the calibration is taking place, and return it to the on-mission report rate after.

5.1 SV3 V100/V200 In-Water

1. Retrieve existing calibration parameters from CCU & Thrudder

```
%amps.portDump("Thrudder-2", 2, 2, 34, 3)
```

```
%amps.portDump("Host", 32, 4, 11, 3)
```

2. Initiate heading polygon (8 sides, 2 minutes per side, 15 minutes total) –
NOTE: Auto-avoid will not take effect in this navigation mode.

```
%ffn.headingPolygonCommand("2m", 8, 0)
```

3. Start calibration routines on devices:

```
%amps.writePortField("Thrudder-2", 2, 2, 0, 1128352817)
```

```
%amps.oneShot("Host", 32, 4, 0, "CAL1")
```

4. Allow the vehicle navigate through two complete octagons.

5. Stop calibration routines on devices:

```
%amps.writePortField("Thrudder-2", 2, 2, 0, 1128352816)
```

```
%amps.oneShot("Host", 32, 4, 0, "CAL0")
```

6. Perform cardinal heading test (fixed heading navigation 0, 90, 180, 270 degrees for 4 telemetry reports each). In a scenario where there are no currents, the vehicle would travel in the same direction as the given fixed heading. However, currents will skew the path over ground.

```
SV3 Commands -> Services -> Navigator (Expert Commands) ->  
Fixed Heading (sub heading)
```

7. Retrieve the new Thrudder and CCU compass calibration values:

```
%amps.portDump("Thrudder-2", 2, 2, 34, 3)
```

```
%amps.portDump("Host", 32, 4, 11, 3)
```

8. Put vehicle on course.
9. Return the telemetry rate to the on-mission value.

5.2 SV3 V300 In-Water

1. Retrieve existing calibration parameters from CCU & Thrudder

```
%amps.portDumpNCData("host", 13, 2, 11, 3)
```

```
%amps.portDumpNCData("thruder-3", 1, 8, 11, 3)
```

2. Initiate heading polygon (8 sides, 2 minutes per side, 15 minutes total) –
NOTE: Auto-avoid will not take effect in this navigation mode.

```
%ffn.headingPolygonCommand("2m", 8, 0)
```

3. Start calibration routines on devices

```
%amps.oneShot("host", 13, 2, 0, "CAL1")
```

```
%amps.oneShot("thruder-3", 1, 8, 0, "CAL1")
```

4. Allow the vehicle navigate through two complete octagons.

5. Stop calibration routines on devices

```
%amps.oneShot("host", 13, 2, 0, "CAL0")
```

```
%amps.oneShot("thruder-3", 1, 8, 0, "CAL0")
```

6. Perform cardinal heading test (fixed heading navigation 0, 90, 180, 270 degrees for 4 telemetry reports each). In a scenario where there are no currents, the vehicle would travel in the same direction as the given fixed heading. However, currents will skew the path over ground.

```
SV3 Commands -> Services -> Navigator (Expert Commands) ->  
Fixed Heading (sub heading)
```

7. Retrieve new calibration parameters:

```
%amps.portDumpNCData("host", 13, 2, 11, 3)
```

```
%amps.portDumpNCData("thruder-3", 1, 8, 11, 3)
```

8. Put vehicle on course.

9. Return telemetry rate to the on-mission value.