



Sea-Bird Scientific
13431 NE 20th Street
Bellevue, WA 98005
USA

+1 425-643-9866
seabird@seabird.com
www.seabird.com

SENSOR SERIAL NUMBER: 0826
CALIBRATION DATE: 25-Nov-20

SBE 37 TEMPERATURE CALIBRATION DATA
ITS-90 TEMPERATURE SCALE

COEFFICIENTS:

a0 = -4.322642e-005
a1 = 2.833322e-004
a2 = -3.051299e-006
a3 = 1.702259e-007

BATH TEMP (° C)	INSTRUMENT OUTPUT (counts)	INST TEMP (° C)	RESIDUAL (° C)
1.0000	737296.8	1.0000	0.0000
4.5000	630383.2	4.5000	-0.0000
15.0000	401698.3	15.0000	-0.0000
18.5000	347805.9	18.5000	0.0000
24.0000	278989.0	24.0000	-0.0000
29.0000	229698.7	28.9999	-0.0001
32.5000	201133.6	32.5000	0.0000

n = Instrument Output (counts)

Temperature ITS-90 (°C) = $1 / \{a_0 + a_1[\ln(n)] + a_2[\ln^2(n)] + a_3[\ln^3(n)]\} - 273.15$

Residual (°C) = instrument temperature - bath temperature

