

6826

10240

PAUL TUCKER (C)

2C00

2D46

2974

manual bus
setting.

① open dye valves
② screw foot sled

③

④ remove air from
dye injector
line

⑤ leaky dye - strong
check valve

⑥ camera spring
⑦ dye log

call AJA

Wickens screen
when camera pressure
white screen
need to reset to get
area feed

zoom settings for camera calibration

① 0000

② 12C7

③ 2406

~~two other zoom settings for camera calibration~~

~~talk/fund~~

~~pull out checkboard~~

~~dye injector~~

~~wick generator~~

~~LED + PU lights~~

~~TOO - change for video files (Deep PU)~~

~~LACIE RAID USB3 2BIC X2
6TB~~

~~Use Palmer 5 psi check valve Lh or~~

~~talk to T~~

Frank
dave
alana
cakan
bruce

+3??

Deployments folder