

Usage of Type0001 Module

Rev. 1.6

July 30, 2010

1 Introduction

This document describes supplement things to use the module. Some of these are restriction of the current version module.

2 Supported camera

The Type0001 module supports D3(*1), D300(*2), D700(*3), D300S, D3S The module cannot control two or more cameras, can control one camera only.

(*1) D3 camera has 4type, as follows. The 4type will be the same specification, if there are no special explanations. If there is D3 description, that means all D3 camera.

- D3 (Ver.1.0)
- D3 FirmUp1 (Ver.1.1)
- D3 FirmUp2 (Ver.2.0)
- D3 FirmUp3 (Ver.2.02)

(*2) D300 camera has 2type, as follows. The 2type will be the same specification, if there are no special explanations. If there is D300 description, that means all D300 camera.

- D300 (Ver.1.0)
- D300 Firm Up (Ver.1.1)

(*3) D700 camera has 2type, as follows. The 2type will be the same specification, if there are no special explanations. If there is D700 description, that means all D700 camera.

- D700 (Ver.1.0)
- D700 Firm Up (Ver.1.02)

3 Environment

OS type	Version
Windows	Windows XP Home Edition (SP3) / Professional (SP3)
	Windows Vista SP2 32bit/64bit edition (Home Basic / Home Premium / Business / Enterprise / Ultimate)
	(* Works 32 bit application on 64 bit OS.)
	Windows 7 32bit/64bit edition (* Works 32 bit application on 64 bit OS.) (Home Basic/Home Premium/Professional/Enterprise / Ultimate)
Macintosh	Mac OS X 10.4.11
	Mac OS X 10.5.8
	Mac OS X 10.6.4

4 Capabilities

Client should acquire the value of each Capability once now after opening of Source object. (There is no necessity for acquiring the value every time before setting the value.) When the setting of the value is executed by `kNkMAIDCommand_CapSet` now without acquiring the value, the value to which Client did set might not be correctly set to the camera.

4.1 *kNkMAIDCapability_ProgressProc*

The module notifies progress information through `MAIDProgress` function. When the module can't compute how much the task is finished, the module will call `MAIDProgress` function with `ulTotal = 0` and `ulDone = Non-0`. When the task has finished, the module will call function with `ulDone = ulTotal`.

4.2 *kNkMAIDCapability_EventProc*

MAID3.1 specification says that the client doesn't have to set `MAIDEvent` function to `kNkMAIDCapability_EventProc`. But the current module assumes that the client always sets the `MAIDEvent` function. So if the client doesn't set `MAIDEvent` function to `EventProc`, there are following restrictions to use the module.

- 1) The client can't use `kNkMAIDCommand_EnumChildren`.
- 2) The client can't support lens exchange and device turn off and on.
- 3) The module doesn't notify changing of capability value, so the client should keep checking these values.

4.3 *kNkMAIDCapability_Children*

The client may use this capability to enumerate the child objects. The client also can use `kNkMAIDCommand_EnumChildren` for same purpose. If the client doesn't set `MAIDEvent` function to `kNkMAIDCapability_EventProc`, the client should use `kNkMAIDCapability_Chilren` to enumerate the child objects.

4.4 *kNkMAIDCapability_PictureControlData*

The camera decides whether the camera uses the setting value of Picture Control data, or the value that camera decides internally according to the following setting of Picture Control data.

- 1) `QuickAdjustFlag` (Color)

If this value is valid(1), the camera uses only the value of "QuickAdjust".

If this value is invalid(0), the camera uses the following value, "Saturation", "Hue", "Sharpening", "Contrast", "Brightness", "CustomCurveFlag", "CustomCurveData", and does not use the value of "QuickAdjust".

- `CustomCurveFlag`

If this value is "Custom Curve used"(1), the camera does not use "Contrast", "Brightness".

- `Toning` (Monochrome)

If this value is B&W(0), the camera does not use "ToningDensity".

- `Contrast`, `Brightness`, `CustomCurveFlag`, `CustomCurveData`

If the value of `kNkMAIDCapability_Active_D_Lighting` is set to the value except for "Off"(3), the camera does not use "Contrast", "Brightness", "CustomCurveFlag", "CustomCurveData".

4.5 *kNkMAIDCapability_DeleteDramImage*

The timing of deletion for DRAM image is limited to the following 2 cases. The module does not

support the deletion on the timing excluding the following 2 cases.

1. Before receiving kNkMAIDEvent_AddChild for Source Object.
2. After issuing kNkMAIDCapability_Acquire for Image Object,
and before issuing kNkMAIDCommand_Close.

The case 1 example of the command sequence is shown to the following table.

No	Command / Capability / Event	Object Type
1	kNkMAIDCapability_Capture	Source
2	kNkMAIDCommand_Async	Source
3	kNkMAIDEvent_AddPreviewImage	Source
4	kNkMAIDCapability_CurrentPreviewID	Source
5	kNkMAIDCapability_DeleteDramImage	Source

The case 2 example of the command sequence is shown to the following table.

No	Command / Capability / Event	Object Type
1	kNkMAIDCapability_Capture	Source
2	kNkMAIDCapability_Children	Source
3	kNkMAIDCommand_Open	Item
4	kNkMAIDCapability_Children	Item
5	kNkMAIDCommand_Open	Image
6	kNkMAIDCapability_DataProc (Set)	Image
7	kNkMAIDCapability_Acquire	Image
8	kNkMAIDCommand_Async	Image
9	kNkMAIDCommand_Abort	Image
10	kNkMAIDCapability_CurrentPreviewID	Source
11	kNkMAIDCapability_DeleteDramImage	Source
12	kNkMAIDCapability_DataProc (Reset)	Image
13	kNkMAIDCommand_Close	Image
14	kNkMAIDCommand_Close	Item

At the case 2, the execution of kNkMAIDCapability_Acquire is needed before the execution of kNkMAIDCapability_DeleteDramImage. So, in the case of small data size image, JPEG Basic, the all of image data may complete reading by the kNkMAIDCapability_Acquire before issuing of deletion command. In that case, the error doesn't occur when the deletion command is executed, but the image will be saved in client program.

When the callback function was set to kNkMAIDCapability_ProgressProc, the termination of operation will be notified with the parameter of callback function, “ulDone == ulTotal” or “ulDone == ulTotal==0”. But when the client aborts the operation by kNkMAIDCommand_Abort, the termination

of operation will not be notified.

4.6 kNkMAIDCapability_GetPreviewImageLow(Normal)

A Preview data might not be able to be acquired. A Preview data is a specification deleted from the inside of the camera after reading a main image is finished. Current module is a specification that immediately begins the acquisition of a main image regardless of the request of the client when the creation completion notification of a main image is received from the camera.

After module read the image, the image data is deleted from the inside of the camera.

Therefore, the acquisition of a Preview data is not a function secured 100%.

However, if client could read a Preview data even once, the module generates the Preview cache internally, so the client can get data after receiving kNkMAIDEvent_AddChild even, until Item object is closed.

4.7 kNkMAIDCapability_SaveMedia

“0 : Card” is selectable as the value of kNkMAIDCapability_SaveMedia, but in the current module, the normal shooting performance is not secured.

5 Image and Thumbnail Data

An image data file is transferred from the module through MAID Data Delivery Function. (refer to 5.27 File Data Delivery Structure and 10.3 MAID Data Delivery Function in MAID3.DOC)

All thumbnail images are raw byte data in order of RGBRGBRGB.... The pixel order is from left to right and from top to bottom. The size of thumbnail image is fixed as follows.

Width: 160 pixels Height: 120 pixels

6 Connection with camera

If the client sends kNkMAIDCommand_Async to the module, it can know the camera is connected with PC through AddChild event for source object. When the module detects the camera is turned off, the module sends RemoveChild event for the current opened source object.

7 Opening object

The client can open only one object at same object type(eNkMAIDObjectType). (e.g. If there are two source object with different ID, client can open either one at the same time.)

But exceptional case, image and thumbnail object, these are belong to kNkMAIDObjectType_DataObj, can be opened at the same time, from same ID Item object.

8 The restriction while executing Live view.

While the Live view is executing, the use of a lot of capability will become prohibition.

When there is no description that this capability is usable with executing live view on the document “MAID3Type0001.doc”, the use of this capability will become prohibition.

But though the use of this capability is changed to prohibition, the ulVisibility and ulOperations of this capability will not be changed basically and keeps the current settings of ulVisibility and ulOperations. (Capability_AFCapture and Capability_PreCapture, etc. also have a part of

exception.)

The usable capability when Live view is executing is as follows.

Live view mode	capability
Hand-held	kNkMAIDCapability_FocusPreferredArea
	kNkMAIDCapability_AutoFocus
Tripod	kNkMAIDCapability_ContrastAF
	kNkMAIDCapability_MFDriveStep
	kNkMAIDCapability_MFDrive
	kNkMAIDCapability_ContrastAFArea
Hand-held / Tripod	kNkMAIDCapability_LiveViewStatus
	kNkMAIDCapability_LiveViewProhibit
	kNkMAIDCapability_LiveViewImageZoomRate
	kNkMAIDCapability_Capture
	kNkMAIDCapability_GetLiveViewImage

9 The restriction about D3S

When you use D3S camera on Windows XP, Mac OS X 10.5, Explorer(Windows) or Image Capture (Mac OS X 10.5) may not detect the camera properly. If this happens, turn the camera off once and turn it on again.

10 The restriction on Mac OS X 10.6

After connecting your camera to your PC, please wait to start module until the memory card access lamp stops flashing.

11 Structure Member Alignment

The following list is structure member alignment of the module and client. In MAID3.H, there is a comment saying that all alignments are 4byte, but this value depends on platform.

Platform	Alignment
Windows 32bit	2 byte
Macintosh	4 byte

12 Macintosh

Type0001 module for Macintosh(Type0001 Module.bundle) is Universal Binary.

13 History

- Rev.1.6 Jul. 30, 2010
 - 3 Environment...Updated the version of Mac OS X 10.6.
- Rev.1.5 Jan. 12, 2010
 - 2 Supported camera...Added D3 Firm Up 3, D700 Firm Up.
 - 3 Environment...Added edition information of Windows 7.
- Rev.1.4 Oct. 22, 2009
 - 2 Supported camera...Added D3S.
 - 3 Environment...Added Windows Vista 64bit, Windows 7. Mac OS X 10.6.1. Updated the version of Mac OS X 10.5.
 - 4.7 kNkMAIDCapability_SaveMedia...Added the restriction about that when “0 : Card” is set, the normal shooting performance is not secured.
 - 9 The restriction about D3S...Added.
 - 10 The restriction on Mac OS X 10.6...Added.
- Rev.1.3 Aug. 21, 2009
 - Deleted the description concerning D90 from this documents.
 - 2 Supported camera...Deleted D90, added D300S.
 - 3 Environment...Excluded Wndows2000, Mac OS X 10.3.9 from supported OS. Updated the version of Mac OS X 10.5.
 - 4 Capabilities...Added the description that the value acquisition of each Capability that has to be executed only once, before opening of Source object.
 - 4.5 kNkMAIDCapability_DeleteDramImage...Added the description about restriction at the case that the deletion timing 2 is used.
 - 4.6.kNkMAIDCapability_GetPreviewImageLow(Normal)...Added the description that might fail in acquisition according to timing about not only the Normal preview but also the Low preview.
 - Acquiring image...Deleted.
- Rev.1.2 Oct. 16, 2008
 - 2 Supported camera...Added D300 Firm Up, D90.
 - 3 Environment...Update version of Mac OS X 10.5.
 - 4.6 kNkMAIDCapability_GetPreviewImageNormal...Removed the limitation of "windows only".
 - 9. The restriction while executing Live view...Added description about D90.
- Rev.1.1 Jul. 28, 2008
 - 2 Supported camera...Added D700, D3 FirmUp1, D3 FirmUp2.
 - 3 Environment...Added.
 - 4.6 kNkMAIDCapability_GetPreviewImageNormal...Added a limitation only of the

Window version module.

- Rev.1.0 Oct. 25, 2007 First version