




THIS PRINT IS THE PROPERTY OF LEBUS INTERNATIONAL, INC., AND IS ACCEPTED WITH THE CLEAR UNDERSTANDING AND AGREEMENT THAT IT IS TO BE USED ONLY FOR QUDITATION OR MANUFACTURING PURPOSES AT THE DIRECTION OF LEBUS INTERNATIONAL, INC., AND MUST BE RETURNED ON DEMAND, AND FURTHER THAT THIS PRINT WILL NOT BE REPRODUCED, COPIED, OR DUPLICATED IN ANY MANNER WHATSOEVER OR USED FOR ANY OTHER PURPOSE EXCEPT BY PERMISSION OF LEBUS INTERNATIONAL, INC.



1. Measure the drum diameter and width carefully.
2. Measure the sleeve width. It should be approximately 1/32" to 1/16" smaller than the drum width for clearance reasons.
3. Using a flexible tape, measure the ID circumference of the sleeve halves. The two sleeve half ID circumference measurements plus 1/4" to 3/8" should be approximately equal to the drum circumference.
4. Using the provided tapped lifting holes, place the "entry" half of the sleeve in place. The rope entries on the sleeve and the drum must match correctly. A small sample of rope can be used to aid in this alignment.
5. Position the sleeve half around the drum to suit. Keep the clearance gaps at the drum flanges and split lines equal. This assures the sleeve is square to the drum.
6. Using chain(s) and jack(s) force the sleeve down tight against the drum barrel in the area to be bolted. (If sleeve is lockwashed, weld a dog to the sleeve. Then using a wedge, line-up the ends square with the drums flange.) Begin drilling & tapping the drum using the sleeve half as a template starting at the center and working towards the split in either direction moving the jack as you go. The tapped holes in the sleeve are for lifting eyes. Note, they are not to be used to lift the drum.
7. Position the second half such that the groove lands line up with each other. Once again, equalize the clearance gap at the drums ends. Also equalize the split line gap between the sleeve halves.
8. If the sleeve split lines bump up to each other before it is tight against the drum then contact LeBus International for additional information. Do not trim the sleeve in any way before talking with LeBus.
9. Repeat steps 6 & 7 for the second half.

For any questions, please call LeBus at 903-758-5521

REVISIONS			
LTR	DESCRIPTION	BY	DATE



UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. TOLERANCES CASTINGS ±1/8" FABRICATING ±1/8" MACHINING ±.008" FRAXCTIONS .XX ±.008" .XXX ±.004"				CONTR	
				DATE	March 14, 2001
				DRAWN	DAG
				APPROVAL	
				SIZE	B
				CODE IDENT	17798
				DWG NO.	P3287-402B
LEBUS INTERNATIONAL, INC. LONGVIEW, TEXAS					
Installation Instructions for a Bolt-On Split Sleeve without Wear Plates					
SCALE		None	WEIGHT	SHEET	